



JAIPUR ENGINEERING COLLEGE
AND RESEARCH CENTRE

JAIPUR ENGINEERING COLLEGE AND RESEARCH CENTRE

JECRC Campus, Shri Ram ki Nangal, Via-Vatika , Tonk Road, Jaipur

Department of Mechanical Engineering

Name of Subject: Fluid Mechanics and Fluid Machines

Subject Code: 4ME4-05

Year: 2nd Year, 4th Semester



JAIPUR ENGINEERING COLLEGE
AND RESEARCH CENTRE

JAIPUR ENGINEERING COLLEGE AND RESEARCH CENTRE

JECRC Campus, Shri Ram ki Nangal, Via-Vatika , Tonk Road, Jaipur

Department of Mechanical Engineering

Vision and Mission of Institute:

Vision: To become a renowned center of outcome based learning, and work towards academic, professional, cultural and social enrichment of the lives of individuals and communities.

Mission:

M1: Focus on evaluation of learning outcomes and motivate students to inculcate research aptitude by project based learning.

M2: Identify, based on informed perception of Indian, regional and global needs, areas of focus and provide platform to gain knowledge and solutions.

M3: Offer opportunities for interaction between academia and industry.

M4: Develop human potential to its fullest extent so that intellectually capable and imaginatively gifted leaders can emerge in a range of professions.

Vision and Mission of Department:

Vision: The Mechanical Engineering Department strives to be recognized globally for outcome based technical knowledge and to produce quality human resource, who can manage the advance technologies and contribute to society.

Mission:

M1: To impart quality technical knowledge to the learners to make them globally competitive mechanical engineers.

M2: To provide the learners ethical guidelines along with excellent academic environment for a long productive career.

M3: To promote industry-institute relationship.



JAIPUR ENGINEERING COLLEGE
AND RESEARCH CENTRE

JAIPUR ENGINEERING COLLEGE AND RESEARCH CENTRE

JECRC Campus, Shri Ram ki Nangal, Via-Vatika , Tonk Road, Jaipur

Department of Mechanical Engineering

PROGRAM EDUCATIONAL OBJECTIVES (PEOS)

PEO1: To equip graduates with a strong foundation in engineering sciences, with an emphasis on mechanical engineering principles, enabling them to analyze, design, and solve real-world engineering challenges.

PEO2: To prepare graduates with sound scientific and engineering fundamentals to innovate and deliver effective solutions addressing practical challenges in mechanical engineering

PEO3: To inculcate in graduates a professional and ethical attitude, effective communication and teamwork skills, a multidisciplinary approach, entrepreneurial mindset, and the ability to connect engineering solutions with societal and environmental concerns.

PEO4: To provide students with an academic environment that fosters excellence, leadership, adherence to ethical standards, and encourages self-motivated lifelong learning essential for a successful professional career in mechanical

PEO5: To prepare students to excel in industry and higher education by providing quality education grounded in strong technical knowledge and high moral values

Program Specific Outcomes (PSOs)

PSO1: Graduates will be able to design, analyze, and fabricate electric and hybrid vehicles using modern engineering tools and sustainable practices.

PSO2: Graduates will be able to apply design principles and computational techniques, including programming and data structures, to analyze and solve mechanical engineering problems.



JAIPUR ENGINEERING COLLEGE
AND RESEARCH CENTRE

JAIPUR ENGINEERING COLLEGE AND RESEARCH CENTRE

JECRC Campus, Shri Ram ki Nangal, Via-Vatika , Tonk Road, Jaipur

Department of Mechanical Engineering

Program Outcomes (POs)

- PO1: Engineering Knowledge:** Apply knowledge of mathematics, natural science, computing, engineering fundamentals and an engineering specialization as specified in WK1 to WK4 respectively to develop to the solution of complex engineering problems.
- PO2: Problem Analysis:** Identify, formulate, review research literature and analyze complex engineering problems reaching substantiated conclusions with consideration for sustainable development. (WK1 to WK4)
- PO3: Design/Development of Solutions:** Design creative solutions for complex engineering problems and design/develop systems/components/processes to meet identified needs with consideration for the public health and safety, whole-life cost, net zero carbon, culture, society and environment as required. (WK5)
- PO4: Conduct Investigations of Complex Problems:** Conduct investigations of complex engineering problems using research-based knowledge including design of experiments, modelling, analysis & interpretation of data to provide valid conclusions. (WK8).
- PO5: Engineering Tool Usage:** Create, select and apply appropriate techniques, resources and modern engineering & IT tools, including prediction and modelling recognizing their limitations to solve complex engineering problems. (WK2 and WK6)
- PO6: The Engineer and The World:** Analyze and evaluate societal and environmental aspects while solving complex engineering problems for its impact on sustainability with reference to economy, health, safety, legal framework, culture and environment. (WK1, WK5, and WK7).
- PO7: Ethics:** Apply ethical principles and commit to professional ethics, human values, diversity and inclusion; adhere to national & international laws. (WK9)
- PO8: Individual and Collaborative Team work:** Function effectively as an individual, and as a member or leader in diverse/multi-disciplinary teams.
- PO9: Communication:** Communicate effectively and inclusively within the engineering community and society at large, such as being able to comprehend and write effective reports and design documentation, make effective presentations considering cultural, language, and learning differences
- PO10: Project Management and Finance:** Apply knowledge and understanding of engineering management principles and economic decision-making and apply these to one's own work, as a member and leader in a team, and to manage projects and in multidisciplinary environments.
- PO11: Life-Long Learning:** Recognize the need for, and have the preparation and ability for i) independent and life-long learning ii) adaptability to new and emerging technologies and iii) critical thinking in the broadest context of technological change. (WK8)



JAIPUR ENGINEERING COLLEGE
AND RESEARCH CENTRE

JAIPUR ENGINEERING COLLEGE AND RESEARCH CENTRE

JECRC Campus, Shri Ram ki Nangal, Via-Vatika, Tonk Road, Jaipur

Department of Mechanical Engineering

SYLLABUS

Credit: 4
3L+1T+0P

Max. Marks: 100 (IA:30, ETE:70)

End Term Exam: 3 Hours

SN	Contents	Hours
1	Introduction: Objective, scope and outcome of the course.	1
2	Fluid Properties: Units and dimensions- Properties of fluids- mass density, specific weight, specific volume, specific gravity, viscosity, compressibility, vapor pressure, surface tension and capillarity.	2
	Fluid Statics and Flow Characteristics: Basic equation of fluid statics, Manometers, Force on plane areas and curved surfaces, center of pressure, Buoyant force, Stability of floating and submerged bodies. Flow characteristics – concept of control volume – application of continuity equation, energy equation and momentum equation.	5
3	Flow Through Circular Conduits: Hydraulic and energy gradient - Laminar flow through circular conduits and circular annuli-Boundary layer concepts – types of boundary layer thickness – Darcy Weisbach equation –friction factor- Moody diagram-minor losses – Flow through pipes in series and parallel.	8
4	Dimensional Analysis: Need for dimensional analysis – methods of dimensional analysis – Similitude –types of similitude - Dimensionless parameters- application of dimensionless parameters – Model analysis.	8
5	Pumps: Impact of jets - Euler's equation - Theory of roto-dynamic machines – various efficiencies- velocity components at entry and exit of the rotor- velocity triangles - Centrifugal pumps- working principle - work done by the impeller - performance curves - Reciprocating pump- working principle – Rotary pumps –classification.	8
6	Turbines: Classification of turbines – heads and efficiencies – velocity triangles. Axial, radial and mixed flow turbines. Pelton wheel, Francis turbine and Kaplan turbines- working principles - work done by water on the runner – draft tube. Specific speed - unit quantities – performance curves for turbines – governing of turbines.	7
	TOTAL	39

REFERENCE BOOKS (FM&FM)

Text Book

- Frank M. White & Henry Xue, *Fluid Mechanics*, 9th Edition, McGraw-Hill Education, 2021.

Reference Books

- Bruce R. Munson, Theodore H. Okiishi, Wade W. Huebsch & Alric P. Rothmayer, *Fundamentals of Fluid Mechanics*, 9th Edition, John Wiley & Sons, 2024.
- Yunus A. Çengel & John M. Cimbala, *Fluid Mechanics: Fundamentals and Applications*, 4th Edition, McGraw-Hill Education, 2018.
- R. K. Rajput, *Fluid Mechanics and Hydraulic Machines*, S. Chand Publishing, Revised Edition, 2019.



JAIPUR ENGINEERING COLLEGE
AND RESEARCH CENTRE

JAIPUR ENGINEERING COLLEGE AND RESEARCH CENTRE

JECRC Campus, Shri Ram ki Nangal, Via-Vatika , Tonk Road, Jaipur

Department of Mechanical Engineering

COURSE OUTCOME

Subject: Fluid Mechanics and Fluid Machines

Code: 4ME4-05

CO1: Apply principles of fluid properties, fluid statics, and kinematics to solve engineering problems related to forces, pressures, and fluid motion.

CO2: Analyze fluid flow in pipes, channels, and ducts under laminar and turbulent conditions to determine pressure drop, flow rate, and energy losses.

CO3: Evaluate fluid system performance using fundamental equations of fluid flow, including continuity, momentum, and energy, and interpret results for engineering applications.

CO4: Examine the working and performance characteristics of pumps, turbines, and compressors, and recommend theoretical improvements for enhanced efficiency.

CO5: Design and interpret experimental models using similarity laws and scale ratios to simulate prototype behavior.

CO6: Design fluid systems through appropriate selection and performance evaluation of fluid machinery for practical engineering applications.

CO-PO MAPPING

CO	PO1	PO2	PO3	PO4	PO5	PO6	PO7	PO8	PO9	PO10	PO11	PSO1	PSO2
CO1	3	2	1	3	3	2	1	1	2	2	3	1	3
CO2	2	2	2	2	3	1	2	3	2	1	3	1	3
CO3	2	3	3	2	2	2	1	2	3	1	2	1	3
CO4	3	2	2	3	3	2	1	1	3	2	2	1	3
CO5	3	2	3	2	2	2	1	3	3	2	2	2	2
CO6	2	2	2	3	2	2	1	3	2	2	2	2	3



JAIPUR ENGINEERING COLLEGE
AND RESEARCH CENTRE

JAIPUR ENGINEERING COLLEGE AND RESEARCH CENTRE

JECRC Campus, Shri Ram ki Nangal, Via-Vatika , Tonk Road, Jaipur

Department of Mechanical Engineering

Course Plan

Name of the Course: **Fluid Mechanics and Fluid Machines**

Code of the course: **4ME4-05**

Name of Faculty: **Dr. Manoj Gupta**

Course Outcome

CO1: Apply principles of fluid properties, fluid statics, and kinematics to solve engineering problems related to forces, pressures, and fluid motion.

CO2: Analyze fluid flow in pipes, channels, and ducts under laminar and turbulent conditions to determine pressure drop, flow rate, and energy losses.

CO3: Evaluate fluid system performance using fundamental equations of fluid flow, including continuity, momentum, and energy, and interpret results for engineering applications.

CO4: Examine the working and performance characteristics of pumps, turbines, and compressors, and recommend theoretical improvements for enhanced efficiency.

CO5: Design and interpret experimental models using similarity laws and scale ratios to simulate prototype behavior.

CO6: Design fluid systems through appropriate selection and performance evaluation of fluid machinery for practical engineering applications.

Unit	Topic	Lecture	CO	Specific Objectives	Expected Outcomes	Reference
Intro	Introduction, Objectives, Scope & Outcomes	1	CO1	Explain scope	Understand course objectives	White Ch.1
1	Units, Dimensions and Fluid Properties	2	CO1	Explain properties	Differentiate fluid properties	White Ch.1
1	Density, Specific Weight, SG & Viscosity	3	CO1	Explain physical properties	Solve numericals	White Ch.2
1	Compressibility, Vapour Pressure, Surface Tension & Capillarity	4	CO1	Explain behavior	Analyze applications	White Ch.2
1	Fluid Statics & Pressure Measurement	5	CO1	Explain hydrostatics	Solve pressure problems	White Ch.3
1	Pressure on Plane & Curved Surfaces	6	CO1	Evaluate hydrostatic forces	Analyze submerged surfaces	White Ch.3
1	Buoyancy,	7	CO1	Explain	Analyze	White



JAIPUR ENGINEERING COLLEGE
AND RESEARCH CENTRE

JAIPUR ENGINEERING COLLEGE AND RESEARCH CENTRE

JECRC Campus, Shri Ram ki Nangal, Via-Vatika , Tonk Road, Jaipur

Department of Mechanical Engineering

	Floatation & Stability			buoyancy	floating bodies	Ch.3
1	Tutorial-1 (Unit-1 Numericals)	8	CO1	Reinforce concepts	Solve unit problems	Tutorial
2	Control Volume Concept	9	CO3	Explain control volume	Apply CV analysis	White Ch.4
2	Continuity Equation	10	CO3	Explain continuity	Solve continuity problems	White Ch.4
2	Bernoulli Equation	11	CO3	Explain energy equation	Solve Bernoulli problems	White Ch.5
2	Momentum Equation & Applications	12	CO3	Explain momentum	Analyze fluid forces	White Ch.5
2	Laminar Flow through Pipes & Annuli	13	CO2	Explain laminar flow	Determine pressure drop	White Ch.6
2	Boundary Layer Concept	14	CO2	Explain BL	Evaluate thickness	White Ch.7
2	Darcy-Weisbach Equation & Friction Factor	15	CO2	Explain losses	Calculate friction	White Ch.8
2	Moody Diagram, Major & Minor Losses	16	CO2	Interpret Moody chart	Evaluate losses	White Ch.8
2	Tutorial-2 (Pipe Flow Problems)	17	CO2	Integrate pipe flow	Solve numerical problems	Tutorial
3	Pipes in Series & Parallel	18	CO2	Analyze pipe systems	Solve network problems	White Ch.8
3	Dimensional Analysis	19	CO5	Explain dimensional homogeneity	Apply DA	White Ch.9
3	Buckingham π Theorem	20	CO5	Develop π groups	Solve DA problems	White Ch.9
3	Rayleigh Method	21	CO5	Apply Rayleigh method	Solve engineering problems	White Ch.9
3	Similitude & Types of Similarity	22	CO5	Explain similarity	Compare model & prototype	White Ch.9
3	Dimensionless Numbers &	23	CO5	Interpret parameters	Predict prototype	White Ch.9



JAIPUR ENGINEERING COLLEGE
AND RESEARCH CENTRE

JAIPUR ENGINEERING COLLEGE AND RESEARCH CENTRE

JECRC Campus, Shri Ram ki Nangal, Via-Vatika , Tonk Road, Jaipur

Department of Mechanical Engineering

	Model Analysis					
3	Tutorial-3 (Similarity & Model Analysis)	24	CO5	Reinforce concepts	Solve numericals	Tutorial
4	Impact of Jets	25	CO3	Analyze jet impact	Evaluate force	Fluid Machines
4	Euler Equation for Turbomachines	26	CO4	Explain Euler equation	Analyze energy transfer	Fluid Machines
4	Velocity Triangles	27	CO4	Construct velocity triangles	Analyze machines	Fluid Machines
4	Centrifugal Pumps	28	CO4	Explain working	Analyze operation	Fluid Machines
4	Pump Performance Curves & Efficiencies	29	CO4	Evaluate performance	Recommend improvements	Fluid Machines
4	Reciprocating & Rotary Pumps	30	CO4	Compare pumps	Select suitable pumps	Fluid Machines
4	Compressors	31	CO4	Explain compressors	Compare performance	Fluid Machines
4	Tutorial-4 (Pumps & Compressors)	32	CO4	Reinforce concepts	Solve numerical problems	Tutorial
5	Classification of Turbines	33	CO4	Explain turbines	Compare types	Fluid Machines
5	Pelton, Francis & Kaplan Turbines	34	CO4	Explain working	Evaluate performance	Fluid Machines
5	Specific Speed, Unit Quantities & Performance Curves	35	CO6	Evaluate performance	Select machinery	Fluid Machines
5	Governing of Turbines & Selection of Hydraulic Machines	36	CO6	Select machines	Design systems	Fluid Machines
5	Selection of Pumps & Turbines for Applications	37	CO6	Design fluid systems	Recommend machinery	Case Study
5	Integrated Design of Water Supply &	38	CO6	Integrate concepts	Design practical systems	Case Study



JAIPUR ENGINEERING COLLEGE
AND RESEARCH CENTRE

JAIPUR ENGINEERING COLLEGE AND RESEARCH CENTRE

JECRC Campus, Shri Ram ki Nangal, Via-Vatika , Tonk Road, Jaipur

Department of Mechanical Engineering

	Hydropower Systems					
5	Tutorial-5 & Integrated Course Review	39	CO6	Integrate all COs	Apply knowledge	Tutorial

Reference Books

- **Bruce R. Munson, Theodore H. Okiishi, Wade W. Huebsch & Alric P. Rothmayer**, *Fundamentals of Fluid Mechanics*, 9th Edition, John Wiley & Sons, 2024.
- **Yunus A. Çengel & John M. Cimbala**, *Fluid Mechanics: Fundamentals and Applications*, 4th Edition, McGraw-Hill Education, 2018.
- **R. K. Rajput**, *Fluid Mechanics and Hydraulic Machines*, S. Chand Publishing, Revised Edition, 2019.

UNIT-1

INTRODUCTION TO FLUID STATICS

Fluid Mechanics is basically a study of:

- 1) Physical behavior of fluids and fluid systems and laws governing their behavior.
- 2) Action of forces on fluids and the resulting flow pattern.

Fluid is further sub-divided into liquid and gas. The liquids and gases exhibit different characteristics on account of their different molecular structure. Spacing and latitude of the motion of molecules is large in a gas and weak in liquids and very strong in a solid. It is due to these aspects that solid is very compact and rigid in form, liquid accommodates itself to the shape of the container, and gas fills up the whole of the vessel containing it.

Fluid mechanics cover many areas like:

1. Design of wide range of hydraulic structures (dams, canals, weirs etc) and machinery (Pumps, Turbines etc).
2. Design of complex network of pumping and pipe lines for transporting liquids. Flow of water through pipes and its distribution to service lines.
3. Fluid control devices both pneumatic and hydraulic.
4. Design and analysis of gas turbines and rocket engines and air-craft.
5. Power generation from hydraulic, stream and Gas turbines.
6. Methods and devices for measurement of pressure and velocity of a fluid in motion.

UNITS AND DIMENSIONS:

A dimension is a name which describes the measurable characteristics of an object such as mass, length and temperature etc. a unit is accepted standard for measuring the dimension. The dimensions used are expressed in four fundamental dimensions namely Mass, Length, Time and Temperature.

Mass (M) – Kg

Length (L) – m

Time (T) – S

Temperature (t) – °C or K (Kelvin)

1. **Density:** Mass per unit volume= kg/m^3
2. **Newton:** Unit of force expressed in terms of mass and acceleration, according to Newton's 2nd law motion. Newton is that force which when applied to a mass of 1 kg gives an acceleration 1m/Sec^2 . $F=\text{Mass} \times \text{Acceleration} = \text{kg} - \text{m/sec}^2 = \text{N}$.
3. **Pascal:** A Pascal is the pressure produced by a force of Newton uniformly applied over an area of 1 m^2 . Pressure = Force per unit area = $\text{N/ m}^2 = \text{Pascal or } P_a$.
4. **Joule:** A joule is the work done when the point of application of force of 1 Newton is displaced. Work = Force per unit area = $\text{N m} = \text{J or Joule}$.

5. **Watt:** A Watt represents a work equivalent of a Joule done per second.

Power = Work done per unit time = J/ Sec = W or Watt.

Density or Mass Density: The density or mass density of a fluid is defined as the ratio of the mass of the fluid to its volume. Thus the mass per unit volume of the fluid is called density. It is denoted by ρ

The unit of mass density is Kg/m^3

$$\rho = \frac{\text{Mass of fluid}}{\text{Volume of fluid}}$$

The value of density of water is 1000Kg/m^3 .

Specific weight or Specific density: It is the ratio between the weights of the fluid to its volume. The weight per unit volume of the fluid is called weight density and it is denoted by w .

$$w = \frac{\text{Weight of fluid}}{\text{Volume of fluid}} = \frac{\text{Mass of fluid} \times \text{Acceleration due to gravity}}{\text{Volume of fluid}}$$

$$= \frac{\text{Mass of fluid} \times g}{\text{Volume of fluid}} = \rho \times g$$

Specific volume: It is defined as the volume of the fluid occupied by a unit mass or volume per unit mass of fluid is called Specific volume.

$$\text{Specific volume} = \frac{\text{Volume of the fluid}}{\text{Mass of fluid}} = \frac{1}{\frac{\text{Mass of fluid}}{\text{Volume of the fluid}}} = \frac{1}{\rho}$$

Thus the Specific volume is the reciprocal of Mass density. It is expressed as m^3/kg and is commonly applied to gases.

Specific Gravity: It is defined as the ratio of the Weight density (or density) of a fluid to the Weight density (or density) of a standard fluid. For liquids the standard fluid taken is water and for gases the standard liquid taken is air. The Specific gravity is also called relative density. It is a dimensionless quantity and it is denoted by s .

$$S \text{ (for liquids)} = \frac{\text{weight density of liquid}}{\text{weight density of water}}$$

$$S \text{ (for gases)} = \frac{\text{weight density of gas}}{\text{weight density of air}}$$

Weight density of liquid = $S \times \text{weight density of water} = S \times 1000 \times 9.81 \text{ N/m}^3$

Density of liquid = $S \times \text{density of water} = S \times 1000 \text{ Kg/m}^3$

If the specific gravity of fluid is known, then the density of fluid will be equal to specific gravity of the fluid multiplied by the density of water

Example: The specific gravity of mercury is 13.6

Hence density of mercury = $13.6 \times 1000 = 13600 \text{ Kg/m}^3$

VISCOSITY: It is defined as the property of a fluid which offers resistance to the movement of one layer of the fluid over another adjacent layer of the fluid. When the two layers of a fluid, at a distance 'dy' apart, move one over the other at different velocities, say u and u+du. The viscosity together with relative velocities causes a shear stress acting between the fluid layers.

The top layer causes a shear stress on the adjacent lower layer while the lower layer causes a shear stress on the adjacent top layer.

This shear stress is proportional to the rate of change of velocity with respect to y. it is denoted by symbol τ (tau)

$$\tau \propto \frac{du}{dy}$$

$$\tau = \mu \frac{du}{dy}$$

Where μ is the constant of proportionality and is known as the co-efficient of dynamic viscosity or only viscosity. $\frac{du}{dy}$ represents the rate of shear strain or rate of shear deformation or velocity gradient.

From the above equation, we have

$$\mu = \frac{\tau}{\frac{du}{dy}}$$

Thus, viscosity is also defined as the shear stress required producing unit rate of shear strain.

The unit of viscosity in CGS is called poise and is equal to dyne-see/ cm²

KINEMATIC VISCOSITY: It is defined as the ratio between dynamic viscosity and density of fluid. It is denoted by symbol ν (nu)

$$\nu = \frac{\text{viscosity}}{\text{density}} = \frac{\mu}{\rho}$$


The unit of kinematic viscosity is m²/sec

Thus one stoke = cm²/sec = $\frac{1}{100}$ m²/sec = 10⁻⁴ m²/sec

NEWTONS LAW OF VISCOSITY: It states that the shear stress (τ) on a fluid element layer is directly proportional to the rate of shear strain. The constant of proportionality is called the co- efficient of viscosity .It is expressed as:

$$\tau = \mu \frac{du}{dy}$$

Fluids which obey above relation are known as NEWTONIAN fluids and fluids which do not obey the above relation are called NON-NEWTONIAN fluids.



UNITS OF VISCOSITY

The units of viscosity is obtained by putting the dimensions of the quantities in equation

$$\mu = \frac{\frac{\square}{\square \square}}{\frac{\square}{\square}} \quad \text{Shear stress}$$

$$\mu = \frac{\text{Change of velocity change of distance}}{\text{Force/Area}} = \frac{\text{Force/Length}^2}{\frac{(\text{Length}) \times \frac{1}{\text{Time}}}{\text{Length}}} = \frac{\text{Force} \times \text{Time}}{\text{Length}^2}$$

In MKS System Force is represented by (Kg f) and Length by meters (m)

In CGS System Force is represented by dyne and length by cm and

In SI System Force is represented by Newton (N) and Length by meter (m)

$$\text{MKS unit of Viscosity} = \frac{\text{Kg f-sec}}{\text{m}^2}$$

$$\text{CGS Unit of Viscosity} = \frac{\text{dyne} \frac{\text{cm}^2}{\text{sec}}}{\text{cm}^2}$$

$$\text{S I Unit of Viscosity} = \frac{\text{Newton-sec}}{\text{m}^2} = \frac{\text{Ns}}{\text{m}^2}$$

The unit of Viscosity in CGS is called **Poise**, which is equal to $\frac{(\text{dyne-sec})}{\text{cm}^2}$.

The numerical conversion of the unit of viscosity from MKS units to CGS unit is as follows:

$$\frac{\text{One Kg f-sec}}{\text{m}^2} = \frac{9.81 \text{ N-sec}}{\text{m}^2} \quad (1 \text{ Kg f} = 9.81 \text{ Newton})$$

But one Newton = One Kg (mass) $\times$ one $\frac{\text{m}}{\text{sec}^2}$ (Acceleration)

$$\begin{aligned} &= \frac{(1000 \text{ gms} \times 100 \text{ cm})}{\text{sec}^2} \text{ gm-cm} \\ &= 1000 \times 100 \frac{\text{gm-cm}}{\text{sec}^2} \\ &= 1000 \times 100 \text{ dyne} \quad (\text{dyne} = \text{gm} \times \frac{\text{cm}}{\text{sec}^2}) \end{aligned}$$

$$\begin{aligned} \frac{\text{One Kg f-sec}}{\text{m}^2} &= 9.81 \times \frac{100000 \text{ dyne-sec}}{\text{cm}^2} \\ &= 9.81 \times 100000 \frac{\text{dyne-sec}}{\text{cm}^2} = 9.81 \times 100000 \frac{\text{dyne-sec}}{100 \times 100 \times \text{cm}^2} \\ &= 98.1 \frac{\text{dyne-sec}}{\text{cm}^2} \\ &= 98.1 \text{ Poise} \quad (\text{dyne-sec}) = \text{Poise} \end{aligned}$$

$$\frac{\text{One Ns}}{\text{m}^2} = \frac{9.81}{9.81} \text{ Poise} = 10 \text{ Poise}$$

$$\text{Or } 1 \text{ Poise} = \frac{1 \text{ Ns}}{10 \text{ m}^2}$$

VARIATION OF VISCOSITY WITH TEMPERATURE:

Temperature affects the viscosity. The viscosity of liquids decreases with the increase of temperature, while the viscosity of gases increases with the increase of temperature. The viscous forces in a fluid are due to cohesive forces and molecular momentum transfer. In liquids cohesive forces predominate the molecular momentum transfer, due to closely packed molecules and with the increase in temperature, the cohesive forces decrease resulting in decreasing of viscosity. But, in case of gases the cohesive forces are small and molecular momentum transfer predominates with the increase in temperature, molecular momentum transfer increases and hence viscosity increases. The relation between viscosity and temperature for liquids and gases are:

$$\text{i) For liquids } \mu = \mu_0 \frac{1}{1 + \alpha t + \beta t^2}$$

Where, μ = Viscosity of liquid at t °C in Poise.

μ_0 = Viscosity of liquid at 0 °C

α and β are constants for the Liquid.

For Water, $\mu_0 = 1.79 \times 10^{-3}$ poise, $\alpha = 0.03368$ and $\beta = 0.000221$

The above equation shows that the increase in temp. The Viscosity decreases.

$$\text{ii) For gases } \mu = \mu_0 + \alpha t - \beta t^2$$

For air $\mu_0 = 0.000017$, $\alpha = 0.056 \times 10^{-6}$, $\beta = 0.118 \times 10^{-9}$

The above equation shows that with increase of temp. The Viscosity increases.

TYPES of FLUIDS: The fluids may be classified into the following five types.

1. Ideal fluid 2. Real fluid 3. Newtonian fluid 4. Non-Newtonian fluid 5. Ideal plastic fluid


1. **Ideal fluid:** A fluid which is compressible and is having no viscosity is known as ideal fluid. It is only an imaginary fluid as all fluids have some viscosity.

2. **Real fluid:** A fluid possessing a viscosity is known as real fluid. All fluids in actual practice are real fluids.

3. **Newtonian fluid:** A real fluid, in which the stress is directly proportional to the rate of shear strain, is known as Newtonian fluid.

4. **Non-Newtonian fluid:** A real fluid in which shear stress is not proportional to the rate of shear strain is known as Non-Newtonian fluid.

5. **Ideal plastic fluid:** A fluid, in which shear stress is more than the yield value and shear stress is proportional to the rate of shear strain is known as ideal plastic fluid.



SURFACE TENSION:

Surface tension is defined as the tensile force acting on the surface of a liquid in contact with a gas or on the surface behaves like a membrane under tension. The magnitude of this force per unit length of free surface will have the same value as the surface energy per unit area. It is denoted by σ (sigma). In MKS units it is expressed as Kg f/m while in SI units as N/m

Surface Tension on Liquid Droplet:

Consider a small spherical droplet of a liquid of radius 'r' on the entire surface of the droplet, the tensile force due to surface tension will be acting

Let σ = surface tension of the liquid

p = pressure intensity inside the droplet (In excess of outside pressure intensity)

d = Diameter of droplet

Let, the droplet is cut in to two halves. The forces acting on one half (say left half) will be

i) Tensile force due to surface tension acting around the circumference of the cut portion


$$= \sigma \times \text{circumference} = \sigma \times \pi d$$



ii) Pressure force on the area $\frac{\pi d^2}{4} = p \times \frac{\pi d^2}{4}$

These two forces will be equal to and opposite under equilibrium conditions i.e.

$$\frac{\pi d^2}{4} p = \sigma \pi d, \quad p = \frac{4\sigma}{d}, \quad p = \frac{2\sigma}{r}$$



Surface Tension on a Hollow Bubble: A hollow bubble like soap in air has two surfaces in contact with air, one inside and other outside. Thus, two surfaces are subjected to surface tension.

$$\frac{\pi d^2}{4} p = 2(\sigma \pi d) \quad p = \frac{4\sigma}{d}$$

SURFACE TENSION ON A LIQUID JET:

Consider a liquid jet of diameter 'd' length 'L'

Let, p = pressure intensity inside the liquid jet above the outside pressure

σ = surface tension of the liquid


Consider the equilibrium of the semi-jet

Force due to pressure = $p \times \text{area of the semi-jet} = p \times L \times d$

Force due to surface tension = $\sigma \times 2L$

$$p \times L \times d = \sigma \times 2L,$$

$$p = \frac{2\sigma}{d}$$



CAPILLARITY

Capillarity is defined as a phenomenon of rise or fall of a liquid surface in a small tube relative to the adjacent general level of liquid when the tube is held vertically in the liquid. The rise of liquid surface is known as capillary rise, while the fall of the liquid surface is known as capillary depression. It is expressed in terms of 'cm' or 'mm' of liquid. Its value depends upon the specific weight of the liquid, diameter of the tube and surface tension of the liquid.


EXPRESSION FOR CAPILLARY RISE:

Consider a glass tube of small diameter 'd' opened at both ends and is inserted in a liquid; the liquid will rise in the tube above the level of the liquid outside the tube.

Let 'h' be the height of the liquid in the tube. Under a state of equilibrium, the weight of the liquid of height 'h' is balanced by the force at the surface of the liquid in the tube. But, the force at the surface of the liquid in the tube is due to surface tension.

Let σ = surface tension of liquid

Θ = Angle of contact between the liquid and glass tube



The weight of the liquid of height 'h' in the tube

$$= (\text{area of the tube} \times h) \times \rho \times g = \frac{\pi d^2}{4} \times h \times \rho \times g$$

Where ' ρ ' is the density of the liquid.

The vertical component of the surface tensile force = $(\sigma \times \text{circumference}) \times \cos \Theta = \sigma \times \pi d \times \cos \Theta$

For equilibrium, $\frac{\pi d^2}{4} \times h \times \rho \times g = \sigma \pi d \cos \Theta$,
$$h = \frac{\sigma \cos \Theta}{\frac{\pi d^2}{4} \times \rho \times g} = \frac{4 \sigma \cos \Theta}{\pi d \rho g}$$

The value of Θ is equal to '0' between water and clean glass tube, then $\cos \Theta = 1$,
$$h = \frac{4 \sigma}{\pi d \rho g}$$

EXPRESSION FOR CAPILLARY FALL:

If the glass tube is dipped in mercury, the Level of mercury in the tube will be lower than the general level of the outside liquid.

Let, h = height of the depression in the tube. Then, in equilibrium, two forces are acting on the mercury inside the tube. First one is due to the surface tension acting in the downward direction =

$$\sigma \times \pi d \times \cos \Theta$$

The second force is due to hydrostatic force acting upward and is equal to intensity of pressure at a


depth 'h' $\times$ area = $\rho \times \frac{\pi d^2}{4} \times h \times \rho \times g$ ($p = \rho \times h$),

$$\sigma \pi d \cos \Theta = \rho g h \frac{\pi d^2}{4}$$

(The value of Θ for glass and mercury 128°)

$$h = \frac{4 \sigma \cos \Theta}{\rho g \frac{\pi d^2}{4}}$$

$$h = \frac{4 \sigma \cos \Theta}{\rho g \frac{\pi d^2}{4}}$$



VAPOUR PRESSURE AND CAVITATION

A change from the liquid state to the gaseous state is known as Vaporizations. The vaporization (which depends upon the prevailing pressure and temperature condition) occurs because of continuous escaping of the molecules through the free liquid surface.

Consider a liquid at a temp. of 20°C and pressure is atmospheric is confined in a closed vessel. This liquid will vaporize at 100°C , the molecules escape from the free surface of the liquid and get accumulated in the space between the free liquid surface and top of the vessel. These accumulated vapours exert a pressure on the liquid surface. This pressure is known as vapour pressure of the liquid or pressure at which the liquid is converted in to vapours.

Consider the same liquid at 20°C at atmospheric pressure in the closed vessel and the pressure above the liquid surface is reduced by some means; the boiling temperature will also reduce. If the pressure is reduced to such an extent that it becomes equal to or less than the vapour pressure, the boiling of the liquid will start, though the temperature of the liquid is 20°C . Thus, the liquid may boil at the ordinary temperature, if the pressure above the liquid surface is reduced so as to be equal or less than the vapour pressure of the liquid at that temperature.


Now, consider a flowing system, if the pressure at any point in this flowing liquid becomes equal to or less than the vapour pressure, the vapourisation of the liquid starts. The bubbles of these vapours are carried by the flowing liquid in to the region of high pressure where they collapse, giving rise to impact pressure. The pressure developed by the collapsing bubbles is so high that the material from the adjoining boundaries gets eroded and cavities are formed on them. This phenomenon is known as **CAVITATION**.

Hence the cavitations is the phenomenon of formation of vapour bubbles of a flowing liquid in a region where the pressure of the liquid falls below the vapour pressure and sudden collapsing of these vapour bubbles in a region of high pressure,. When the vapour bubbles collapse, a very high pressure is created. The metallic surface, above which the liquid is flowing, is subjected to these high pressures, which cause pitting actions on the surface. Thus cavities are formed on the metallic surface and hence the name is **cavitation**.

ABSOLUTE, GAUGE, ATMOSPHERIC and VACCUM PRESSURES

The pressure on a fluid is measured in two different systems. In one system, it is measured above the absolute zero or complete vacuum and it is called the Absolute pressure and in other system, pressure is measured above the atmospheric pressure and is called Gauge pressure.

1. ABSOLUTE PRESSURE: It is defined as the pressure which is measured with reference to absolute vacuum pressure



2. GAUGE PRESSURE: It is defined as the pressure, which is measured with the help of a pressure measuring instrument, in which the atmospheric pressure is taken as datum. The atmospheric on the scale is marked as zero.

3. VACUUM PRESSURE: It is defined as the pressure below the atmospheric pressure

i) Absolute pressure = Atmospheric pressure + gauge pressure

$$p_{ab} = p_{atm} + p_{guag}$$

ii) Vacuum pressure = Atmospheric pressure - Absolute pressure

The atmospheric pressure at sea level at 15°C is 10.13 N/cm² or 101.3 kN/m² in S I Units and 1.033 Kg f/cm² in M K S System.

The atmospheric pressure head is 760 mm of mercury or 10.33 m of water.

MEASUREMENT OF PRESSURE

The pressure of a fluid is measured by the following devices.

1. Manometers 2. Mechanical gauges.

1. Manometers: Manometers are defined as the devices used for measuring the pressure at a point in a fluid by balancing the column of fluid by the same or another column of fluid. They are classified as:

a) Simple Manometers b) Differential Manometers.

2. Mechanical Gauges: are defined as the devices used for measuring the pressure by balancing the fluid column by the spring or dead weight. The commonly used Mechanical pressure gauges are:

a) Diaphragm pressure gauge

b) Bourdon tube pressure gauge

c) Dead – Weight pressure gauge

d) Bellows pressure gauge.

Simple Manometers: A simple manometer consists of a glass tube having one of its ends connected to a point where pressure is to be measured and the other end remains open to the atmosphere. The common types of simple manometers are:

1. Piezo meter.


2. U-tube manometer.

3. Single column manometer.

1. Piezometer: It is a simplest form of manometer used for measuring gauge pressure. One end of this manometer is connected to the point where pressure is to be measured and other end is open to the atmosphere. The rise of liquid in the Piezometer gives pressure head at that point A.

The height of liquid say water is 'h' in piezometer tube, then

$$\text{Pressure at A} = \rho g h$$



2 U- tube Manometer:

It consists of a glass tube bent in u-shape, one end of which is connected to a point at which pressure is to be measured and other end remains open to the atmosphere. The tube generally contains mercury or any other liquid whose specific gravity is greater than the specific gravity of the liquid whose pressure is to be measured.

a) For Gauge Pressure: Let B is the point at which pressure is to be measured, whose value is p. The datum line A – A

Let h_1 = height of light liquid above datum line

h_2 = height of heavy liquid above datum line

S_1 = sp. gravity of light liquid

ρ_1 = density of light liquid = 1000 S_1

S_2 = sp. gravity of heavy liquid

ρ_2 = density of heavy liquid = 1000 S_2

As the pressure is the same for the horizontal surface. Hence the pressure above the horizontal datum line A – A in the left column and the right column of U – tube manometer should be same.

Pressure above A—A in the left column = $p + \rho_1 g h_1$

$\rho_2 g h_2$ Pressure above A – A in the right column = $\rho_2 g h_2$

Hence equating the two pressures $p + \rho_1 g h_1 = \rho_2 g h_2$

$$p = \rho_2 g h_2 - \rho_1 g h_1$$

(b) For Vacuum Pressure:



For measuring vacuum pressure, the level of heavy fluid in the manometer will be as shown in fig.

Pressure above A A in the left column = $\rho_2 g h_2 + \rho_1 g h_1 + P$

Pressure head in the right column above A A = 0

$$\rho_2 g h_2 + \rho_1 g h_1 + P = 0$$

$$p = - (\rho_2 g h_2 + \rho_1 g h_1)$$



(a) For Gauge Pressure (b) For Vacuum Pressure

SINGLE COLUMN MANOMETER:

Single column manometer is a modified form of a U- tube manometer in which a reservoir, having a large cross sectional area (about. 100 times) as compared to the area of tube is connected to one of the limbs (say left limb) of the manometer. Due to large cross sectional area of the reservoir for any variation in pressure, the change in the liquid level in the reservoir will be very small which may be neglected and hence the pressure is given by the height of the liquid in the other limb. The other limb may be vertical or inclined. Thus, there are two types of single column manometer

1. Vertical single column manometer.
2. Inclined single column manometer.

VERTICAL SINGLE COLUMN MANOMETER:

Let X – X be the datum line in the reservoir and in the right limb of the manometer, when it is connected to the pipe, when the Manometer is connected to the pipe, due to high pressure at A The heavy liquid in the reservoir will be pushed downwards and will rise in the right limb.

Let, Δh = fall of heavy liquid in the reservoir

h_2 = rise of heavy liquid in the right limb

h_1 = height of the centre of the pipe above X – X

p_A = Pressure at A, which is to be measured.

A = Cross- sectional area of the reservoir

a = cross sectional area of the right limb

S_1 = Specific Gravity of liquid in pipe

S_2 = sp. Gravity of heavy liquid in the reservoir and right limb

ρ_1 = density of liquid in pipe

ρ_2 = density of liquid in reservoir

Fall of heavy liquid reservoir will cause a rise of heavy liquid level in the right limb

$$A \times \Delta h = a \times h_2$$

$$\Delta h = \frac{\rho_1 \times h_2}{\rho_2} \quad \text{----- (1)}$$


Now consider the datum line Y – Y

The pressure in the right limb above Y – Y

$$= \rho_2 \times g \times (\Delta h + h_2)$$

Pressure in the left limb above Y – Y

$$= \rho_1 \times g \times (\Delta h + h_1) + P_A$$



Equating the pressures, we have

$$\rho_2 g \times (\Delta h + h_2) = \rho_1 g \times (\Delta h + h_1) + p_A$$

$$p_A = \rho_2 g \times (\Delta h + h_2) - \rho_1 g \times (\Delta h + h_1)$$

$$= \Delta h (\rho_2 g - \rho_1 g) + h_2 \rho_2 g - h_1 \rho_1 g$$

But, from eq (1) $\Delta h = \frac{\rho_1 \times h^2}{\rho_2}$

$$p_A = (\rho_2 g - \rho_1 g) \times \frac{\rho_1 \times h^2}{\rho_2} + h_2 \rho_2 g - h_1 \rho_1 g$$

As the area A is very large as compared to a, hence the ratio $\frac{a}{A}$ becomes very small and can be neglected. Then,

$$p_A = h_2 \rho_2 g - h_1 \rho_1 g \text{----- (2)}$$

INCLINED SINGLE COLUMN MANOMETER:

The manometer is more sensitive. Due to inclination the distance moved by heavy liquid in the right limb will be more.

Let L = length of heavy liquid moved in the right limb

Θ = inclination of right limb with horizontal.

H_2 = vertical rise of heavy liquid in the right limb above X – X


$$= L \sin \Theta$$

From above eq (2), the pressure at A is

$$p_A = h_2 \rho_2 g - h_1 \rho_1 g$$

Substituting the value of h_2

$$p_A = L \sin \Theta \rho_2 g - h_1 \rho_1 g$$



DIFFERENTIAL MANOMETERS:

Differential manometers are the devices used for measuring the difference of pressure between two points in a pipe or in two different pipes. A differential manometer consists of a U-tube, containing heavy liquid, whose two ends are connected to the points, whose difference of pressure is to be measured. The common types of U- tube differential manometers are:

1. U- Tube differential manometer
2. Inverted U- tube differential manometer.

1. U- Tube differential manometer:

- a) Let the two points A and B are at different levels and also contains liquids of different sp.gr.

b) These points are connected to the U – Tube differential manometer.
Let the pressure at A and B are p_A and p_B .

Let h = Difference of mercury levels in the u – tube

y = Distance of centre of B from the mercury level in the right limb

x = Distance of centre of A from the mercury level in the left limb

ρ_1 = Density of liquid A

ρ_2 = Density of liquid B

ρ = Density of heavy liquid or

mercury Taking datum line at X – X

Pressure above X – X in the left limb = $\rho_1 g(h + x) + p_A$ (where p_A = Pressure at A)

Pressure above X – X in the right limb = $\rho g h + \rho_2 g y + p_B$ (where p_B = Pressure at B)

Equating the above two pressures, we have

$$\rho_1 g(h + x) + p_A = \rho g h + \rho_2 g y + p_B$$

$$p_A - p_B = \rho g h + \rho_2 g y - \rho_1 g(h + x)$$

$$= h g (\rho - \rho_1) + \rho_2 g y - \rho_1 g x$$

$$\therefore \text{Difference of Pressures at A and B} = h g (\rho - \rho_1) + \rho_2 g y - \rho_1 g x$$

Let the two points A and B are at the same level and contains the same liquid of density ρ_1

Then pressure above X – X in the right limb = $\rho g h + \rho_1 g x + p_B$

Pressure above X – X in the left limb = $\rho_1 g(h + x) + p_A$

Equating the two pressures



$$\rho g h + \rho_1 g x + p_B = \rho_1 g(h + x) + p_A$$

$$p_A - p_B = \rho g h + \rho_1 g x - \rho_1 g(h + x)$$

$$+ x)$$

$$= g h (\rho - \rho_1)$$

$$\text{Difference of pressure at A and B} = g h (\rho - \rho_1)$$



Inverted U – Tube differential manometer

It consists of a inverted U – tube, containing a light liquid. The two ends of the tube are connected to the points whose difference of pressure is to be measured. It is used for measuring difference of low pressures. Let an inverted U – tube differential manometer connected to the two points A and B. Let pressure at A is more than pressure at B.

Let h_1 = Height of the liquid in the left limb below the datum line X-X

h_2 = Height of the liquid in the right limb.

h = Difference of height of liquid


ρ_1 = Density of liquid A

ρ_2 = Density of liquid B

ρ = Density of light liquid

p_A = Pressure at A

p_B = Pressure at B



Taking $x - x$ as datum line

The pressure in the left limb below $x - x = p_A - \rho_1 g h_1$

Pressure in the right limb below $x - x = p_B - \rho_2 g h_2 - \rho g h$

Equating the above two pressures

$$p_A - \rho_1 g h_1 = p_B - \rho_2 g h_2 - \rho g h$$

$$h p_A - p_B = \rho_1 g h_1 - \rho_2 g h_2 - \rho g h$$

$$g h$$

$$\text{Difference of pressure at A and B} = \rho_1 g h_1 - \rho_2 g h_2 - \rho g h$$

PROBLEMS

1. Calculate the density, specific weight and weight of one liter of petrol of specific gravity = 0.7

Sol: i) Density of a liquid = $S \times \text{Density of water} = S \times 1000 \text{ kg/m}^3$

$$\rho = 0.7 \times 1000$$

$$\rho = 700 \text{ Kg/m}^3$$

ii) Specific weight $w = \rho \times g = 700 \times 9.81 = 6867 \text{ N/m}^3$

iii) Weight (w) Volume = 1 liter = $1 \times 1000 \text{ cm}^3 = \frac{1000 \text{ m}^3}{10^6} = \underline{\underline{0.001 \text{ m}^3}}$

We know that, specific weight $w = \frac{\text{weight of fluid}}{\text{volume of the fluid}}$

Weight of petrol = $w \times \text{volume of petrol}$

$$= w \times 0.001$$

$$= 6867 \times 0.001 = \underline{\underline{6.867 \text{ N}}}$$

2. Two horizontal plates are placed 1.25 cm apart, the space between them being filled with oil of viscosity 14 poises. Calculate shear stress in oil, if the upper plate is moved velocity of m/sec.

Sol: Given distance between the plates $dy = 1.25 \text{ cm} = 0.0125 \text{ m}$

$$\text{Viscosity } \mu = 14 \text{ poise} = \frac{14}{10} \text{ N s/m}^2$$

Velocity of upper plate $u = 2.5 \text{ m/sec}$

$$\text{Shear stress } \tau = \mu \frac{du}{dy}$$

Where $du = \text{change of velocity between plates} = u - 0 = u = 2.5 \text{ m/sec}$

$$\tau = \frac{14}{10} \times \frac{2.5}{0.0125}$$

$$\text{Shear stress } \tau = 280 \text{ N/m}^2$$

3. The dynamic viscosity of oil used for lubrication between a shaft and sleeve is 6 poise. The shaft dia. is 0.4m and rotates at 190 rpm. Calculate the power lost in the bearing for a sleeve length of 90mm. The thickness oil film is 1.5mm

Sol: Given, Viscosity $\mu = 6 \text{ poise} = \frac{6}{10} \frac{\text{N s}}{\text{m}^2} = 0.6$

Dia. of shaft $D = 0.4 \text{ m}$

Speed of shaft $N = 190 \text{ rpm}$

Sleeve length $L = 90 \text{ mm} = 90 \times 10^{-3} \text{ m}$

Thickness of a film $t = 1.5 \text{ mm} = 1.5 \times 10^{-3} \text{ m}$

$$\text{Tangential velocity of shaft} = u = \frac{\pi DN}{60} = \frac{\pi \times 0.4 \times 190}{60} = 3.98 \text{ m/sec}$$

$$\text{Using the relation } \tau = \mu \frac{du}{dy}$$


Where $du = \text{change of velocity} = u - 0 = u = 3.98 \text{ m/sec}$

$$dy = \text{change of distance} = t = 1.5 \times 10^{-3} \text{ m}$$

$$\tau = 0.6 \times \frac{3.98}{1.5 \times 10^{-3}} = 1592 \text{ N/m}^2$$

This is the shear stress on the shaft

$$\begin{aligned} \text{Shear force on the shaft } F &= \text{shear stress} \times \text{area} = 1592 \times \pi DL = 1592 \times \pi \times 0.4 \times 90 \times 10^{-3} \\ &= 180.05 \text{ N} \end{aligned}$$



$$\frac{\text{N s}}{\text{m}^2}$$

$$\text{Torque on the shaft } T = \text{Force} \times \frac{D}{2} = 180.05 \times \frac{0.4}{2} = 36.01 \text{ Nm}$$

$$\text{Power lost} = \frac{2\pi NT}{60} = 36.01 \times \frac{2\pi \times 190}{60} \times 36.01$$

Power lost = 716.48 W

4. A cylinder 0.12m radius rotates concentrically inside a fixed cylinder of 0.13 m radius. Both cylinders are 0.3m long. Determine the viscosity of liquid which fills the space between the cylinders, if a torque of 0.88 Nm is required to maintain an angular velocity of 2π rad / sec.

Sol : Diameter of inner cylinder = 0.24m

Diameter of outer cylinder = 0.26 m

Length of cylinder $L = 0.3 \text{ m}$

Torque $T = 0.88 \text{ NM}$

$\omega = 2\pi \text{ N/60} = 2\pi$

$N = \text{speed} = 60 \text{ rpm}$

Let the viscosity = μ

Tangential velocity of cylinder $u = \frac{\pi DN}{60} = \frac{\pi \times 0.24 \times 60}{60} = 0.7536 \text{ m/sec}$

Surface area of cylinder $A = \pi DL = \pi \times 0.24 \times 0.3 = 0.226 \text{ m}^2$

Now using the relation $\tau = \mu \frac{du}{dy}$

Where $du = u - 0 = 0.7536 \text{ m/sec}$

$$dy = \frac{0.26 - 0.24}{2} = 0.02 = 0.01 \text{ m}$$

$$\tau = \mu \times \frac{0.7536}{0.01}$$

Shear force, $F = \text{shear stress} \times \text{area}$

$$= \mu \times 75.36 \times 0.226 = 17.03 \mu$$

$$\text{Torque } T = F \times D/2 = 17.03 \mu \times \frac{0.24}{2}$$

$$0.88 = \mu \times 2.0436$$

$$\mu = \frac{0.88}{2.0436}$$

$$= 0.4306 \text{ Ns/m}^2$$

$$= 0.4306 \times 10 \text{ poise}$$

Viscosity of liquid = 4.306 poise

5. The right limb of a simple U – tube manometer containing mercury is open to the atmosphere, while the left limb is connected to a pipe in which a fluid of sp.gr.0.9 is flowing. The centre of pipe is 12cm below the level of mercury in the right limb. Find the pressure of fluid in the pipe, if the difference of mercury level in the two limbs is 20 cm.

Given, Sp.gr. of liquid $S_1 = 0.9$

Density of fluid $\rho_1 = S_1 \times 1000 = 0.9 \times 1000 = 900 \text{ kg/m}^3$

Sp.gr. of mercury $S_2 = 13.6$

Density of mercury $\rho_2 = 13.6 \times 1000 = 13600 \text{ kg/m}^3$


Difference of mercury level $h_2 = 20 \text{ cm} = 0.2 \text{ m}$

Height of the fluid from A – A $h_1 = 20 - 12 = 8 \text{ cm} = 0.08 \text{ m}$

Let 'P' be the pressure of fluid in pipe

Equating pressure at A – A, we get

$$p + \rho_1 g h_1 = \rho_2 g h_2$$



$$\begin{aligned}
 p + 900 \times 9.81 \times 0.08 &= 13.6 \times 1000 \times 9.81 \times 0.2 \\
 p &= 13.6 \times 1000 \times 9.81 \times 0.2 - 900 \times 9.81 \times 0.08 \\
 p &= 26683 - 706 \\
 p &= 25977 \text{ N/m}^2 \\
 p &= 2.597 \text{ N/cm}^2
 \end{aligned}$$

Pressure of fluid = 2.597 N/cm²

6. A simple U – tube manometer containing mercury is connected to a pipe in which a fluid of sp.gr. And having vacuum pressure is flowing. The other end of the manometer is open to atmosphere. Find the vacuum pressure in pipe, if the difference of mercury level in the two limbs is 40cm. and the height of the fluid in the left tube from the centre of pipe is 15cm below.

Given,

Sp.gr of fluid $S_1 = 0.8$

Sp.gr. of mercury $S_2 = 13.6$

Density of the fluid $= S_1 \times 1000 = 0.8 \times 1000 = 800$

Density of mercury $= 13.6 \times 1000$

Difference of mercury level $h_2 = 40\text{cm} = 0.4\text{m}$

Height of the liquid in the left limb $= 15\text{cm} = 0.15\text{m}$

Let the pressure in the pipe $= p$

Equating pressures above datum line A-- A

$$\rho_2 g h_2 + \rho_1 g h_1 + P = 0$$


$$P = - [\rho_2 g h_2 + \rho_1 g h_1]$$

$$= - [13.6 \times 1000 \times 9.81 \times 0.4 + 800 \times 9.81 \times 0.15]$$

$$= 53366.4 + 1177.2$$

$$= -54543.6 \text{ N/m}^2$$

P = - 5.454 N/cm²



7. What are the gauge pressure and absolute pressure at a point 3m below the surface of a liquid having a density of $1.53 \times 10^3 \text{ kg/m}^3$? If the atmospheric pressure is equivalent to 750mm of mercury. The specific gravity of mercury is 13.6 and density of water 1000 kg/m^3

Given:

Depth of the liquid, $z_1 = 3\text{m}$

Density of liquid $\rho_1 = 1.53 \times 10^3 \text{ kg/m}^3$

Atmospheric pressure head $z_0 = 750 \text{ mm of mercury} = \frac{750}{1000} = 0.75\text{m of Hg}$

Atmospheric pressure $p_{\text{atm}} = \rho_0 \times g \times z_0$

Where $\rho_0 = \text{density of Hg} = \text{sp.gr. of mercury} \times \text{density of water}$
 $= 13.6 \times 1000 \text{ kg/m}^3$

And $z_0 = \text{pressure head in terms of mercury} = 0.75\text{m of Hg}$

$$\begin{aligned}
 P_{\text{atm}} &= (13.6 \times 1000) \times 9.81 \times 0.75 \text{ N/m}^2 \\
 &= 100062 \text{ N/m}^2
 \end{aligned}$$

Pressure at a point, which is at a depth of 3m from the free surface of the liquid is

$$P = \rho_1 \times g \times z_1 = 1.53 \times 10^3 \times 9.81 \times 3$$

Gauge pressure $P = 45028 \text{ N/m}^2$

$$\begin{aligned}\text{Absolute Pressure} &= \text{Gauge pressure} + \text{Atmospheric pressure} \\ &= 45028 + 100062\end{aligned}$$

$$\text{Absolute Pressure} = 145090 \text{ N/m}^2$$

8. A single column manometer is connected to the pipe containing liquid of sp.gr.0.9. Find the pressure in the pipe if the area of the reservoir is 100 times the area of the tube of manometer. sp.gr. of mercury is 13.6. Height of the liquid from the centre of pipe is 20cm and difference in level of mercury is 40cm.

Given,

$$\text{Sp.gr. of liquid in pipe} \quad S_1 = 0.9$$

$$\text{Density} \quad \rho_1 = 900 \text{ kg/m}^3$$

$$\text{Sp.gr. of heavy liquid} \quad S_2 = 13.6$$

$$\text{Density} \quad \rho_2 = 13600$$

$$\frac{\text{Area of reservoir}}{\text{Area of right limb}} = \frac{A}{a} = 100$$


$$\text{Height of the liquid} \quad h_1 = 20\text{cm} = 0.2\text{m}$$

$$\text{Rise of mercury in the right limb} \quad h_2 = 40\text{cm} = 0.4\text{m}$$

Pressure in pipe A

$$\begin{aligned}p_A &= \frac{A}{a} \times h_1 (\rho_2 g - \rho_1 g) + h_2 \rho_2 g - h_1 \rho_1 g \\ &= \frac{1}{100} \times 0.4 [13600 \times 9.81 - 900 \times 9.81] + 0.4 \times 13600 \times 9.81 - 0.2 \times 900 \times 9.81 \\ &= \frac{0.4}{100} [133416 - 8829] + 53366.4 - 1765.8 \\ &= 533.664 + 53366.4 - 1765.8 \\ &= 52134 \text{ N/m}^2\end{aligned}$$

$$\text{Pressure in pipe A} = 5.21 \text{ N/cm}^2$$



9. A pipe contains an oil of sp.gr.0.9. A differential manometer is connected at the two points A and B shows a difference in mercury level at 15cm. find the difference of pressure at the two points.

$$\text{Given: Sp.gr. of oil } S_1 = 0.9: \text{density } \rho_1 = 0.9 \times 1000 = 900 \text{ kg/}$$

$$\text{m}^3 \text{ Difference of level in the mercury } h = 15\text{cm} = 0.15 \text{ m}$$

$$\text{Sp.gr. of mercury} = 13.6, \text{ Density} = 13.6 \times 1000 = 13600 \text{ kg/m}^3$$


$$\begin{aligned}\text{The difference of pressure } p_A - p_B &= g \times h \times (\rho_2 - \rho_1) \\ &= 9.81 \times 0.15 (13600 - 900)\end{aligned}$$

$$p_A - p_B = 18688 \text{ N/m}^2$$

10. A differential manometer is connected at two points A and B. At B air pressure is 9.81 N/cm^2 . Find absolute pressure at A.

$$\text{Density of air} = 0.9 \times 1000 = 900 \text{ kg/m}^3$$

$$\text{Density of mercury} = 13.6 \times 10^3 \text{ kg/m}^3$$



Let pressure at A is p_A

Taking datum as X – X

Pressure above X – X in the right limb

$$= 1000 \times 9.81 \times 0.6 + p_B = 5886 + 98100 = 103986$$

Pressure above X – X in the left limb

$$= 13.6 \times 10^3 \times 9.81 \times 0.1 + 0900 \times 9.81 \times 0.2 + p_A$$

$$= 13341.6 + 1765.8 + p_A$$

Equating the two pressures heads

$$103986 = 13341.6 + 1765.8 + p_A$$

$$= 15107.4 + p_A$$

$$p_A = 103986 - 15107.4$$

$$= 88878.6 \text{ N/m}^2$$

$$\underline{p_A = 8.887 \text{ N/cm}^2}$$

11. Water is flowing through two different pipes to which an inverted differential manometer having an oil of sp.gr. 0.8 is connected. The pressure head in the pipe A is 2m of water. Find the pressure in the pipe B for the manometer readings shown in fig.

Given: Pressure head at A = $\frac{p_A}{\rho g} = 2 \text{ m of water}$

$$p_A = \rho \times g \times 2 = 1000 \times 9.81 \times 2 = 19620 \text{ N/m}^2$$

Pressure below X – X in the left limb

$$= p_A - \rho_1 g h_1$$

$$= 19620 - 1000 \times 9.81 \times 0.3 = 16677 \text{ N/m}^2$$

Pressure below X – X in the right limb

$$= p_B - 1000 \times 9.81 \times 0.1 - 800 \times 9.81 \times 0.12$$


$$= p_B - 981 - 941.76 = p_B - 1922.76$$

Equating the two pressures, we get,

$$16677 = p_B - 1922.76$$


$$p_B = 16677 + 1922.76$$

$$\underline{p_B = 18599.76 \text{ N/m}^2}$$



12. A different manometer is connected at two points A and B of two pipes. The pipe A contains liquid of sp.gr. = 1.5 while pipe B contains liquid of sp.gr. = 0.9. The pressures at A and B are 1 kgf/cm² and 1.80 Kg f/cm² respectively. Find the difference in mercury level in the differential manometer.

Sp.gr. of liquid at A $S_1 = 1.5$



Sp.gr. of liquid at B $S_2 = 0.9$

Pressure at A $p_A = 1 \text{ kgf/cm}^2 = 1 \times 10^4 \times \text{kg/m}^2 = 1 \times 10^4 \times 9.81 \text{ N/m}^2$

Pressure at B $p_B = 1.8 \text{ kgf/cm}^2 = 1.8 \times 10^4 \times 9.81 \text{ N/m}^2$ [1kgf = 9.81 N]

Density of mercury = $13.6 \times 1000 \text{ kg/m}^3$

Taking X – X as datum line

Pressure above X – X in left limb

$$= 13.6 \times 1000 \times 9.81 \times h + 1500 \times 9.81(2+3) + (9.81 \times 10^4)$$

Pressure above X – X in the right limb = $900 \times 9.81(h + 2) + 1.8 \times 9.81 \times 10^4$

Equating the two pressures, we get

$$13.6 \times 1000 \times 9.81h + 1500 \times 9.81 \times 5 + 9.81 \times 10^4 = 900 \times 9.81(h + 2) + 1.8 \times 9.81 \times 10^4$$

Dividing both sides by 1000×9.81

$$13.6h + 7.5 + 10 = 0.9(h+2) + 18$$

$$(13.6 - 0.9)h = 1.8 + 18 - 17.5 = 19.8 - 17.5 = 2.3$$

$$h = \frac{2.3}{12.7} = 0.181\text{m}$$

$$\mathbf{h = 18.1 \text{ cm}}$$

FLUID KINEMATICS


Kinematics is defined as a branch of science which deals with motion of particles without considering the forces causing the motion. The velocity at any point in a flow field at any time is studied in this. Once the velocity is known, then the pressure distribution and hence the forces acting on the fluid can be determined.

Stream line: A stream line is an imaginary line drawn in a flow field such that the tangent drawn at any point on this line represents the direction of velocity vector. From the definition it is clear that there can be no flow across stream line. Considering a particle moving along a stream line for a very short distance 'ds' having its components dx, dy and dz, along three mutually perpendicular co-ordinate axes. Let the components of velocity vector V_s along x, y and z directions be u, v and w respectively. The time taken by the fluid particle to move a distance 'ds' along the stream line with a velocity V_s is:


$$\frac{ds}{V_s} \quad \text{Which is same as } \frac{ds}{V_s} = \frac{dx}{u} = \frac{dy}{v} = \frac{dz}{w}$$

Hence the differential equation of the stream line may be written as:

$$\frac{dx}{u} = \frac{dy}{v} = \frac{dz}{w}$$



Path line: A path line is locus of a fluid particle as it moves along. In other words a path line is a curve traced by a single fluid particle during its motion. A stream line at time t_1 indicating the velocity vectors for particles A and B. At times t_2 and t_3 the particle A occupies the successive positions. The line containing these various positions of A represents its **Path line**




Streak line: When a dye is injected in a liquid or smoke in a gas, so as to trace the subsequent motion of fluid particles passing a fixed point, the path followed by dye or smoke is called the **streak line**. Thus the streak line connects all particles passing through a given point.

In steady flow, the stream line remains fixed with respect to co-ordinate axes. Stream lines in steady flow also represent the path lines and streak lines. In unsteady flow, a fluid particle will not, in general, remain on the same stream line (except for unsteady uniform flow). Hence the stream lines and path lines do not coincide in unsteady non-uniform flow.

Instantaneous stream line: in a fluid motion which is independent of time, the position of stream line is fixed in space and a fluid particle following a stream line will continue to do so. In case of time dependent flow, a fluid particle follows a stream line for only a short interval of time, before changing over to another stream line. The stream lines in such cases are not fixed in space, but change with time. The position of a stream line at a given instant of time is known as **Instantaneous stream line**. For different instants of time, we shall have different Instantaneous stream lines in the same space. The Stream line, Path line and the streak line are one and the same, if the flow is steady.

Stream tube: If stream lines are drawn through a closed curve, they form a boundary surface across which fluid cannot penetrate. Such a surface bounded by stream lines is known as **Stream tube**.

From the definition of stream tube, it is evident that no fluid can cross the bounding surface of the stream tube. This implies that the quantity of fluid entering the stream tube at one end must be the same as the quantity leaving at the other end. The Stream tube is assumed to be a small cross-sectional area, so that the velocity over it could be considered uniform.



CLASSIFICATION OF FLOWS

The fluid flow is classified as:

- i) Steady and unsteady flows.
- ii) Uniform and Non-uniform flows.
- iii) Laminar and Turbulent flows.
- iv) Compressible and incompressible flows.
- v) Rotational and Ir-rotational flows.
- vi) One, two and three dimensional flows.

i) Steady and Un-steady flows: Steady flow is defined as the flow in which the fluid characteristics like velocity, pressure, density etc. at a point do not change with time.

Thus for a steady flow, we have

$$\frac{\partial V}{\partial t_{x,y,z}} = 0, \quad \frac{\partial p}{\partial t_{x,y,z}} = 0, \quad \frac{\partial \rho}{\partial t_{x,y,z}} = 0$$

Un-Steady flow is the flow in which the velocity, pressure, density at a point changes with respect to time. Thus for un-steady flow, we have

$$\frac{\partial V}{\partial t_{x,y,z}} \neq 0, \quad \frac{\partial p}{\partial t_{x,y,z}} \neq 0, \quad \frac{\partial \rho}{\partial t_{x,y,z}} \neq 0$$

ii) Uniform and Non-uniform flows:

Uniform flow is defined as the flow in which the velocity at any given time does not change with respect to space. (i.e. the length of direction of flow)

For uniform flow $\frac{\partial V}{\partial s_{t=\text{const}}} = 0$

Where $\square\square$ = Change of velocity

$\square s$ = Length of flow in the direction of – S

Non-uniform is the flow in which the velocity at any given time changes with respect to space.

For Non-uniform flow $\frac{\partial V}{\partial s_{t=\text{const}}} \neq 0$

iii) Laminar and turbulent flow:

Laminar flow is defined as the flow in which the fluid particles move along well-defined paths or stream line and all the stream lines are straight and parallel. Thus the particles move in laminas or layers gliding smoothly over the adjacent layer. This type of flow is also called streamline flow or viscous flow.

Turbulent flow is the flow in which the fluid particles move in a zigzag way. Due to the movement of fluid particles in a zigzag way, the eddies formation takes place, which are responsible for high energy loss. For a pipe flow, the type of flow is determined by a non-

Dimensional number $\frac{VD}{\square}$ called the Reynolds number.

Where D = Diameter of pipe.

V = Mean velocity of flow in pipe.

ν = Kinematic viscosity of fluid.

If the Reynolds number is less than 2000, the flow is called Laminar flow.

If the Reynolds number is more than 4000, it is called Turbulent flow.

If the Reynolds number is between 2000 and 4000 the flow may be Laminar or Turbulent flow.

iv) Compressible and Incompressible flows:

Compressible flow is the flow in which the density of fluid changes from point to point or in other words the density is not constant for the fluid.

For compressible flow $\rho \neq \text{Constant}$.

Incompressible flow is the flow in which the density is constant for the fluid flow. Liquids are generally incompressible, while the gases are compressible.

For incompressible flow $\rho = \text{Constant}$.

v) Rotational and Irrotational flows:

Rotational flow is a type of flow in which the fluid particles while flowing along stream lines also rotate about their own axis. And if the fluid particles, while flowing along stream lines, do not rotate about their own axis, the flow is called Ir-rotational flow.

vi) One, Two and Three - dimensional flows:

One dimensional flow is a type of flow in which flow parameter such as velocity is a function of time and one space co-ordinate only, say 'x'. For a steady one- dimensional flow, the velocity is a function of one space co-ordinate only. The variation of velocities in other two mutually perpendicular directions is assumed negligible.

Hence for one dimensional flow $u = f(x)$, $v = 0$ and $w = 0$

Where u, v and w are velocity components in x, y and z directions respectively.

Two – dimensional flow is the type of flow in which the velocity is a function of time and two space co-ordinates, say x and y. For a steady two-dimensional flow the velocity is a function of two space co-ordinates only. The variation of velocity in the third direction is negligible.

Thus for two dimensional flow $u = f_1(x, y)$, $v = f_2(x, y)$ and $w = 0$.

Three – dimensional flow is the type of flow in which the velocity is a function of time and three mutually perpendicular directions. But for a steady three-dimensional flow, the fluid parameters are functions of three space co-ordinates (x, y, and z) only.

Thus for three- dimensional flow $u = f_1(x, y, z)$, $v = f_2(x, y, z)$, $w = f_3(x, y, z)$.

Rate of flow or Discharge (Q)

It is defined as the quantity of a fluid flowing per second through a section of pipe or channel. For an incompressible fluid (or liquid) the rate of flow or discharge is expressed as the volume of the liquid flowing cross the section per second. or compressible fluids, the rate of flow is usually expressed as the weight of fluid flowing across the section.

Thus i) For liquids the unit of Q is m³/sec or Litres/sec. ii)

For gases the unit of Q is Kg f/sec or Newton/sec.

$$\text{The discharge } Q = A \times V$$

Where,

A = Area of cross-section of pipe.

V = Average velocity of fluid across the section.

CONTINUITY EQUATION

The equation based on the principle of conservation of mass is called Continuity equation. Thus for a fluid flowing through the pipe at all cross- sections, the quantity of fluid per second is constant. Consider two cross- sections of a pipe.

Let V_1 = Average velocity at cross- section 1-1

ρ_1 = Density of fluid at section 1-1

A_1 = Area of pipe at section 1-1


And V_2 , ρ_2 , A_2 are the corresponding values at section 2—2

Then the rate flow at section 1-1 = $\rho_1 A_1 V_1$

Rate of flow at section 2—2 = $\rho_2 A_2 V_2$

According to law of conservation of mass

Rate of flow at section 1---1 = Rate of flow at section 2---2



$$\rho_1 A_1 V_1 = \rho_2 A_2 V_2$$

This equation is applicable to the compressible as well as incompressible fluids and is called “**Continuity equation**”. If the fluid is incompressible, then $\rho_1 = \rho_2$ and the continuity equation reduces to

$$A_1 V_1 = A_2 V_2$$

CONTINUITY EQUATION IN THREE DIMENSIONAL FLOW

Consider a fluid element of lengths dx , dy and dz in the direction of x , y and z . Let u , v and w are the inlet velocity components in x , y and z directions respectively.

Mass of fluid entering the face ABCD per second

$$= \rho \times \text{velocity in } x\text{-direction} \times \text{Area of ABCD}$$

$$= \rho \times u \times (dy \times dz)$$

Then the mass of fluid leaving the face EFGH per second

$$= \rho \times u \times (dy \times dz) + \frac{\partial}{\partial x} \rho u \, dy \, dz \, dx$$

Gain of mass in x -direction

= Mass through ABCD – Mass through EFGH per second.

$$= \rho u \, dy \, dz - \rho u \, dy \, dz - \frac{\partial}{\partial x} \rho u \, dy \, dz \, dx$$

$$= -\frac{\partial}{\partial x} \rho u \, dy \, dz \, dx$$

$$= -\frac{\partial}{\partial x} \rho u \, dx \, dy \, dz \quad (1)$$

Similarly the net gain of mass in y -direction.

$$= -\frac{\partial}{\partial y} \rho v \, dx \, dy \, dz \quad (2)$$

In z -direction

$$= -\frac{\partial}{\partial z} (\rho w) \, dx \, dy \, dz \quad (3)$$

$$\text{Net gain of mass} = -\frac{\partial}{\partial x} \rho u + \frac{\partial}{\partial y} \rho v + \frac{\partial}{\partial z} \rho w \, dx \, dy \, dz \quad (4)$$

Since mass is neither created nor destroyed in the fluid element, the net increase of mass per unit time in the fluid element must be equal to the rate of increase of mass of fluid in the element. But the mass of fluid in the element is $\rho \, dx \, dy \, dz$ and its rate of increase with time is $\frac{\partial}{\partial t} (\rho \, dx \, dy \, dz)$ or $\frac{\partial \rho}{\partial t} \, dx \, dy \, dz$. (5)

Equating the two expressions (4) & (5)

$$-\left(\frac{\partial}{\partial x} \rho u + \frac{\partial}{\partial y} \rho v + \frac{\partial}{\partial z} \rho w\right) dx \, dy \, dz = \frac{\partial \rho}{\partial t} \, dx \, dy \, dz$$

$$\frac{\partial \rho}{\partial t} + \frac{\partial}{\partial x} \rho u + \frac{\partial}{\partial y} \rho v + \frac{\partial}{\partial z} \rho w = 0 \quad (6)$$


This equation is applicable to

- i) Steady and unsteady flow
- ii) Uniform and non-uniform flow, and
- iii) Compressible and incompressible flow.

For steady flow $\frac{\partial \rho}{\partial t} = 0$ and hence equation (6) becomes

$$\frac{\partial}{\partial x} \rho u + \frac{\partial}{\partial y} \rho v + \frac{\partial}{\partial z} \rho w = 0 \quad (7)$$

If the fluid is incompressible, then ρ is constant and the above equation becomes



$$\frac{\partial \rho}{\partial t} + \frac{\partial (\rho u)}{\partial x} + \frac{\partial (\rho v)}{\partial y} + \frac{\partial (\rho w)}{\partial z} = 0 \quad (8)$$

This is the continuity equation in three - dimensional flow.

FLUID DYNAMICS

A fluid in motion is subjected to several forces, which results in the variation of the acceleration and the energies involved in the flow of the fluid. The study of the forces and energies that are involved in the fluid flow is known as Dynamics of fluid flow.

The various forces acting on a fluid mass may be classified as:

1. Body or volume forces
2. Surface forces
3. Line forces.

Body forces: The body forces are the forces which are proportional to the volume of the body.

Examples: Weight, Centrifugal force, magnetic force, Electromotive force etc.

Surface forces: The surface forces are the forces which are proportional to the surface area which may include pressure force, shear or tangential force, force of compressibility and force due to turbulence etc.

Line forces: The line forces are the forces which are proportional to the length.

Example is surface tension.

The dynamics of fluid flow is governed by Newton's second law of motion which states that the resultant force on any fluid element must be equal to the product of the mass and acceleration of the element and the acceleration vector has the direction of the resultant vector. The fluid is assumed to be incompressible and non-viscous.

$$\sum F = M \cdot a$$

Where $\sum F$ represents the resultant external force acting on the fluid element of mass **M** and **a** is total acceleration. Both the acceleration and the resultant external force must be along same line of action. The force and acceleration vectors can be resolved along the three reference directions x, y and z and the corresponding equations may be expressed as ;

$$\sum F_x = M \cdot a_x$$

$$\sum F_y = M \cdot a_y$$

$$\sum F_z = M \cdot a_z$$

Where $\sum F_x$, $\sum F_y$ and $\sum F_z$ are the components of the resultant force in the x, y and z directions respectively, and a_x , a_y and a_z are the components of the total acceleration in x, y and z directions respectively.

FORCES ACTING ON FLUID IN MOTION:

The various forces that influence the motion of fluid are due to gravity, pressure, viscosity, turbulence and compressibility.

The gravity force F_g is due to the weight of the fluid and is equal to Mg . The gravity force per unit volume is equal to " ρg ".

The pressure force F_p is exerted on the fluid mass, if there exists a pressure gradient between the two points in the direction of the flow.

The viscous force F_v is due to the viscosity of the flowing fluid and thus exists in case of all real fluids.

The turbulent flow F_t is due to the turbulence of the fluid flow.

The compressibility force F_c is due to the elastic property of the fluid and it is important only for compressible fluids.

If a certain mass of fluid in motion is influenced by all the above forces, then according to Newton's second law of motion

$$\text{The net force } F_x = M \cdot a_x = (F_g)_x + (F_p)_x + (F_v)_x + (F_t)_x + (F_c)_x$$

i) if the net force due to compressibility (F_c) is negligible, the resulting net force

$$F_x = (F_g)_x + (F_p)_x + (F_v)_x + (F_t)_x \text{ and the equations of motions are called}$$

Reynolds's equations of motion.

ii) For flow where (F_t) is negligible, the resulting equations of motion are known as

Navier – Stokes equation.

iii) If the flow is assumed to be ideal, viscous force (F_v) is zero and the equations of motion are known as **Euler's equation of motion.**

EULER'S EQUATION OF MOTION

In this equation of motion the forces due to gravity and pressure are taken in to consideration. This is derived by considering the motion of the fluid element along a stream-line as:

Consider a stream-line in which flow is taking place in s- direction. Consider a cylindrical element of cross-section dA and length ds .


The forces acting on the cylindrical element are:

1. Pressure force $p dA$ in the direction of flow.

2. Pressure force $\left(p + \frac{\partial p}{\partial s} ds\right) dA$

3. Weight of element $\rho g dA \cdot ds$

Let θ is the angle between the direction of flow and the line



of action of the weight of the element.

The resultant force on the fluid element in the direction of S must be equal to the mass of fluid element $\times$ acceleration in the direction of s.

$$\rho A ds - \rho A ds + \frac{\partial p}{\partial s} \rho A ds - \rho A ds \cos \theta$$

$$= \rho A ds \times a_s \quad (1)$$

Whereas is the acceleration in the direction of s.

Now $a_s = \frac{dv}{dt}$ where „v“ is a function of s and t.

$$= \frac{\partial v}{\partial t} + v \frac{\partial v}{\partial s} = \frac{\partial v}{\partial t} + \frac{v}{v} \frac{\partial v}{\partial s}$$

If the flow is steady, then $\frac{\partial v}{\partial t} = 0$

$$a_s = \frac{v}{v} \frac{\partial v}{\partial s}$$

Substituting the value of a_s in equation (1) and simplifying, we get

$$-\frac{\partial p}{\partial s} ds dA - \rho g ds dA \cos \theta = \rho A ds \times \frac{\partial v}{\partial s}$$

Dividing by $\rho dA ds$ $-\frac{1}{\rho} \frac{\partial p}{\partial s} - g \cos \theta = \frac{v}{v} \frac{\partial v}{\partial s}$

,

$$-\frac{1}{\rho} \frac{\partial p}{\partial s} + g \cos \theta + \frac{v}{v} \frac{\partial v}{\partial s} = 0$$

But we have $\cos \theta = \frac{dz}{ds}$

$$-\frac{1}{\rho} \frac{\partial p}{\partial s} + g \frac{dz}{ds} + \frac{v}{v} \frac{\partial v}{\partial s} = 0$$

$$\frac{1}{\rho} \frac{\partial p}{\partial s} + \frac{v}{v} \frac{\partial v}{\partial s} + \frac{dz}{ds} = 0$$

$\therefore$ This equation is known as Euler's equation of motion.

BERNOULLI'S EQUATION FROM EULER'S EQUATION

Bernoulli's equation is obtained by integrating the Euler's equation of motion as

$$\frac{1}{\rho} \frac{\partial p}{\partial s} + \frac{v}{v} \frac{\partial v}{\partial s} + \frac{dz}{ds} = 0$$

If the flow is incompressible, ρ is constant and

$$\frac{p}{\rho} + gz + \frac{v^2}{2} = \text{constant}$$

$$\frac{p}{\rho g} + z + \frac{v^2}{2g} = \text{constant}$$

$$\frac{p}{\rho g} + \frac{v^2}{2g} + z = \text{constant}$$

The above equation is Bernoulli's equation in which

$\frac{p}{\rho g}$ = Pressure energy per unit weight of fluid or pressure head.

$\frac{v^2}{2g}$ = Kinetic energy per unit weight of fluid or Kinetic head.

z = Potential energy per unit weight of fluid or Potential head.

The following are the assumptions made in the derivation of Bernoulli's equation.

- i. The fluid is ideal. i.e. Viscosity is zero.
- ii. The flow is steady.
- iii. The flow is incompressible.
- iv. The flow is irrotational.

MOMENTUM EQUATION

It is based on the law of conservation of momentum or on the momentum principle, which states that the net force acting on a fluid mass equal to the change in the momentum of the flow per unit time in that direction. The force acting on a fluid mass „ m „ is given by Newton's second law of motion.

$$F = m \times a$$

Where 'a' is the acceleration acting in the same direction as force

F. But $\square = \frac{\square \square}{\square \square}$

$$\square = \square \frac{\square}{\square} = \frac{\square \square \square}{\square} \quad (\text{Since } m \text{ is a constant and can be taken inside differential})$$

$$\square = \frac{\square \square \square}{\square \square} \quad \text{is known as the momentum principle.}$$

$F \cdot dt = d(mv)$ _____ Is known as the impulse momentum equation.
It states that the impulse of a force F acting on a fluid mass m in a short interval of time dt is equal to the change of momentum $d(mv)$ in the direction of force.

Force exerted by a flowing fluid on a pipe-bend:

The impulse momentum equation is used to determine the resultant force exerted by a flowing fluid on a pipe bend.

Consider two sections (1) and (2) as above

Let v_1 = Velocity of flow at section (1)

P_1 = Pressure intensity at section (1)

A_1 = Area of cross-section of pipe at section (1)

And V_2, P_2, A_2 are corresponding values of Velocity, Pressure, Area at section (2)

Let F_x and F_y be the components of the forces exerted by the flowing fluid on the bend in x and y directions respectively. Then the force exerted by the bend on the fluid in the directions of x and y will be equal to F_x and F_y but in the opposite directions. Hence the component of the force exerted by the bend on the fluid in the x – direction = $-F_x$ and in the direction of $y = -F_y$. The other external forces acting on the fluid are $p_1 A_1$ and $p_2 A_2$ on the sections (1) and (2) respectively. Then the momentum equation in x -direction is given by

Net force acting on the fluid in the direction of x = Rate of change of momentum in x –direction

$$\begin{aligned} p_1 A_1 - p_2 A_2 \cos \theta - F_x &= (\text{Mass per second}) (\text{Change of velocity}) \\ &= \rho Q (\text{Final velocity in } x\text{-direction} - \text{Initial velocity in } x\text{-direction}) \\ &= \rho Q (V_2 \cos \theta - V_1) \\ F_x &= \rho Q (V_1 - V_2 \cos \theta) + p_1 A_1 - p_2 A_2 \cos \theta \quad \text{_____ (1)} \end{aligned}$$

Similarly the momentum equation in y -direction gives


$$\begin{aligned} 0 - p_2 A_2 \sin \theta - F_y &= \rho Q (V_2 \sin \theta - 0) \\ F_y &= \rho Q (-V_2 \sin \theta) - p_2 A_2 \sin \theta \quad \text{_____ (2)} \end{aligned}$$

Now the resultant force (F_R) acting on the bend

$$F_R = \sqrt{\quad^2 + \quad^2}$$

And the angle made by the resultant force with the horizontal direction is given by

$$\tan \theta = \frac{\quad}{\quad}$$



PROBLEMS

1. The diameter of a pipe at sections 1 and 2 are 10 cm and 15cm respectively. Find the discharge through pipe, if the velocity of water flowing through the pipe at section 1 is 5m/sec. determine the velocity at section 2.


Given:

At section 1,

$$D_1 = 10\text{cm} = 0.1\text{m}$$

$$A_1 = \frac{\pi}{4} D_1^2 = \frac{\pi}{4} (0.1)^2 = 0.007854 \text{ m}^2$$

$$V_1 = 5\text{m/sec}$$



At section 2, $D_2 = 15\text{cm} = 0.15\text{m}$

$$A_2 = \frac{\pi}{4} (0.15)^2 = 0.01767 \text{ m}^2$$

Discharge through pipe $Q = A_1 \times V_1$

$$= 0.007854 \times 5 = 0.03927 \text{ m}^3/\text{sec}$$

We have

$$A_1 V_1 = A_2 V_2$$

$$V_2 = \frac{A_1 V_1}{A_2} = \frac{0.007854 \times 5.0}{0.01767} = 2.22 \text{ m/sec}$$

2. Water is flowing through a pipe of 5cm dia. Under a pressure of 29.43N/cm^2 and with mean velocity of 2 m/sec. find the total head or total energy per unit weight of water at a cross-section, which is 5m above datum line.

Given: dia. Of pipe = 5cm = 0.05m

$$\text{Pressure } P = 29.43\text{N/cm}^2 = 29.43 \times 10^4\text{N/m}^2$$

$$\text{Velocity } V = 2 \text{ m/sec}$$

$$\text{Datum head } Z = 5\text{m}$$

Total head = Pressure head + Kinetic head + Datum head

$$\text{Pressure head} = \frac{29.43 \times 10^4}{1000 \times 9.81} = 30 \text{ m}$$

$$\text{Kinetic head} = \frac{V^2}{2 \times 9.81} = \frac{2^2}{2 \times 9.81} = 0.204 \text{ m}$$

Datum head = $Z = 5\text{m}$

$$\frac{V^2}{2g} + \frac{V^2}{2g} + Z = 30 + 0.204 + 5 = 35.204\text{m}$$

Total head = 35.204m

3. A pipe through which water is flowing is having diameters 20cms and 10cms at cross-sections 1 and 2 respectively. The velocity of water at section 1 is 4 m/sec. Find the velocity head at section 1 and 2 and also rate of discharge?


Given: $D_1 = 20\text{cms} = 0.2\text{m}$

$$A_1 = \frac{\pi}{4} \times 0.2^2 = 0.0314\text{m}^2$$

$$V_1 = 4\text{ m/sec}$$

$$D_2 = 10\text{ cm} = 0.1\text{ m}$$

$$A_2 = \frac{\pi}{4} \times 0.1^2 = 0.007854\text{m}^2$$



i) Velocity head at section 1 $\frac{V_1^2}{2g} = \frac{4 \times 4}{2 \times 9.81}$

$$0.815\text{m}$$

ii) Velocity head at section 2 $\frac{V_2^2}{2g}$

To find V_2 , apply continuity equation $A_1 V_1 = A_2 V_2$
 $0.0314 \times 4 = 0.007854 \times V_2$
 $V_2 = \frac{0.0314 \times 4}{0.007854} = 16\text{ m/sec}$

Velocity head at section 2

$$\frac{V_2^2}{2g} = \frac{16 \times 16}{2 \times 9.81} = 13.047\text{m}$$

iii) Rate of discharge

$$Q = A_1 V_1 = A_2 V_2$$

$$= 0.0314 \times 4 = 0.1256\text{ m}^3/\text{sec}$$

Q = 125.6 Liters/sec

4. Water is flowing through a pipe having diameters 20cms and 10cms at sections 1 and 2 respectively. The rate of flow through pipe is 35 liters/sec. The section 1 is 6m above the datum and section 2 is 4m above the datum. If the pressure at section 1 is 39.24N/cm^2 . Find the intensity of pressure at section 2?

Given: At section 1 $D_1 = 20\text{cm} = 0.2\text{m}$

$$A_1 = \frac{\pi}{4} \times 0.2^2 = 0.0314\text{m}^2$$

$$P_1 = 39.24\text{N/cm}^2 = 39.24 \times 10^4\text{N/m}^2$$

$$10^4\text{N/m}^2$$

$$Z_1 = 6\text{m}$$


At section 2 $D_2 = 10\text{cm} = 0.1\text{m}$

$$A_2 = \frac{\pi}{4} \times 0.1^2 = 0.007854\text{m}^2$$

$$Z_2 = 4\text{m},$$

$$P_2 = ?$$

Rate of flow $Q = 35\text{ lt/sec} = (35/1000)\text{ m}^3/\text{sec} = 0.035\text{ m}^3/\text{sec}$



$$Q = A_1 V_1 = A_2 V_2$$

$$\frac{Q}{A_1} = \frac{Q}{A_2} = \frac{0.035}{0.0314} = 1.114\text{ m/sec}$$

$$\frac{Q}{A_2} = \frac{Q}{A_1} = \frac{0.035}{0.007854} = 4.456\text{ m/sec}$$

Applying Bernoulli's equation at sections 1 and 2

$$\frac{p_1}{\rho} + \frac{v_1^2}{2} + z_1 = \frac{p_2}{\rho} + \frac{v_2^2}{2} + z_2$$

$$\frac{39.24 \times 10^4}{9810} + \frac{1000 \times 9.81}{2 \times 9.81} + \frac{1.114^2}{2 \times 9.81} + 6 = \frac{p_2}{9810} + \frac{4.456^2}{2 \times 9.81} + 4$$

$$40 + 0.063 + 6 = \frac{p_2}{9810} + 1.102 + 4$$

$$46.063 = \frac{p_2}{9810} + 5.102$$

$$\frac{p_2}{9810} = 46.063 - 5.102 = 41.051$$

$$P_2 = 41.051 \times 9810 = 402710 \text{ N/m}^2$$

$$P_2 = 40.271 \text{ N/cm}^2$$

5) Water is flowing through a pipe having diameter 300mm and 200mm at the bottom and upper end respectively. The intensity of pressure at the bottom end is 24.525N/cm² and the pressure at the upper end is 9.81N/cm². Determine the difference in datum head if the rate of flow through is 40lit/sec?

Given:

section 1 $D_1 = 300 \text{ mm} = 0.3 \text{ m}$


$$A_1 = \frac{\pi}{4} \times (0.3)^2 = 0.07065 \text{ m}^2$$

$$P_1 = 24.525 \text{ N/cm}^2 = 24.525 \times 10^4 \text{ N/m}^2$$

Section 2 $D_2 = 200 \text{ mm} = 0.2 \text{ m}$

$$A_2 = \frac{\pi}{4} \times (0.2)^2 = 0.0314 \text{ m}^2$$

$$P_2 = 9.81 \text{ N/cm}^2 = 9.81 \times 10^4 \text{ N/m}^2$$



Rate of flow

$$Q = 40 \text{ lit/Sec} = 40/1000 = 0.04 \text{ m}^3/\text{sec}$$

$$Q = A_1 V_1 = A_2 V_2$$

$$V_1 = \frac{Q}{A_1} = \frac{0.04}{0.07065} = 0.566 \text{ m/sec}$$

$$V_2 = \frac{Q}{A_2} = \frac{0.04}{0.0314} = 1.274 \text{ m/sec}$$

Applying Bernoulli's equation at sections 1 and 2

$$\frac{p_1}{\rho} + \frac{v_1^2}{2} + z_1 = \frac{p_2}{\rho} + \frac{v_2^2}{2} + z_2$$

$$\frac{24.525 \times 10^4}{9810} + \frac{0.566^2}{2 \times 9.81} + z_1 = \frac{9.81 \times 10^4}{9810} + \frac{1.274^2}{2 \times 9.81} + z_2$$

$$\frac{1000 \times 9.81}{2 \times 9.81} + \frac{\square}{1} = \frac{1000 \times 9.81}{2 \times 9.81} + \frac{\square}{2}$$

.

$$25 + 0.32 + Z_1 = 10 + 1.623 + Z_2$$

$$Z_2 - Z_1 = 25.32 - 11.623 = 13.697 \text{ or say } 13.70\text{m}$$

The difference in datum head = $Z_2 - Z_1 = 13.70\text{m}$

6) The water is flowing through a taper pipe of length 100m having diameters 600mm at the upper end and 300mm at the lower end, at the rate of 50lts/sec. the pipe has a slope of 1 in 30. Find the pressure at the lower end, if the pressure at the higher level is 19.62N/cm^2 ?


Given: Length of pipe $L = 100\text{m}$
Dia. At the upper end $D_1 = 600\text{mm} = 0.6\text{m}$

$$A_1 = \frac{\pi}{4} \times 0.6^2 = 0.2827\text{m}^2$$

$$P_1 = 19.62\text{N/cm}^2 = 19.62 \times 10^4 \text{ N/m}^2$$

Dia. at the lower end $D_2 = 300\text{mm} = 0.3\text{m}$

$$A_2 = \frac{\pi}{4} \times 0.3^2 = 0.07065\text{m}^2$$



$$\text{Rate of flow } Q = 50 \text{ Lts/sec} = \frac{50}{1000} = 0.05 \text{ m}^3/\text{sec}$$

Let the datum line is passing through the centre of the lower end. Then $Z_2 = 0$

$$\text{As slope is 1 in 30 means } \sin \theta = \frac{1}{30} \times 100 = \sin^{-1} \frac{10}{3}$$

We also know that $Q = A_1 V_1 = A_2 V_2$

$$V_1 = \frac{Q}{A_1} = \frac{0.05}{0.2827} = 0.177\text{m/sec}$$

$$V_2 = \frac{Q}{A_2} = \frac{0.05}{0.07065} = 0.707\text{m/sec}$$

Applying Bernoulli's equation at sections 1 and 2

$$\frac{P_1}{\rho g} + \frac{V_1^2}{2g} + Z_1 = \frac{P_2}{\rho g} + \frac{V_2^2}{2g} + Z_2$$

$$\frac{19.62 \times 10^4}{1000 \times 9.81} + \frac{0.177^2}{2 \times 9.81} + \frac{10}{3} = \frac{P_2}{1000 \times 9.81} + \frac{0.707^2}{2 \times 9.81} + 0$$

$$20 + 0.001596 + 3.334 = \frac{P_2}{9810} + 0.0254$$

$$23.335 = \frac{P_2}{9810} + 0.0254$$

$$\frac{P_2}{9810} = 23.335 - 0.0254 = 23.31$$

$$P_2 = 23.31 \times 9810 = 228573 \text{ N/m}^2$$

$$P_2 = 22.857 \text{ N/cm}^2$$

7) A 45° reducing bend is connected to a pipe line, the diameters at inlet and out let of the bend being 600mm and 300mm respectively. Find the force exerted by the water on the bend, if the intensity of pressure at the inlet to the bend is 8.829 N/cm^2 and rate of flow of water is 600 Lts/sec.

Given: Angle of bend $\theta = 45^\circ$

$$\text{Dia. at inlet } D_1 = 600 \text{ mm} = 0.6 \text{ m}$$

$$A_1 = \frac{\pi}{4} (0.6)^2 = 0.2827 \text{ m}^2$$

$$\text{Dia. at out let } D_2 = 300 \text{ mm} = 0.3 \text{ m}$$

$$A_2 = \frac{\pi}{4} (0.3)^2 = 0.07065 \text{ m}^2$$

$$\text{Pressure at inlet } P_1 = 8.829 \text{ N/cm}^2 = 8.829 \times 10^4 \text{ N/m}^2$$


$$Q = 600 \text{ Lts/sec} = 0.6 \text{ m}^3/\text{sec}$$

$$V_1 = \frac{Q}{A_1} = \frac{0.6}{0.2827} = 2.122 \text{ m/sec}$$

$$V_2 = \frac{Q}{A_2} = \frac{0.6}{0.07065} = 8.488 \text{ m/sec}$$

Applying Bernoulli's equation at sections 1 and 2, we get

$$\frac{P_1}{\rho g} + \frac{V_1^2}{2g} + Z_1 = \frac{P_2}{\rho g} + \frac{V_2^2}{2g} + Z_2$$



$$\frac{P_1}{\rho g} + \frac{V_1^2}{2g} + Z_1 = \frac{P_2}{\rho g} + \frac{V_2^2}{2g} + Z_2$$

$$\frac{8.829 \times 10^4}{1000 \times 9.81} + \frac{2.122^2}{2 \times 9.81} = \frac{P_2}{1000 \times 9.81} + \frac{8.488^2}{2 \times 9.81}$$

$$9 + 0.2295 = \frac{P_2}{9810} + 3.672$$

$$\frac{P_2}{9810} = 9.2295 - 3.672 = 5.5575 \text{ m of water}$$

$$P_2 = 5.5575 \times 9810 = 5.45 \times 10^4 \text{ N/m}^2$$

Force exerted on the bend in X and Y – directions

$$\begin{aligned} F_x &= Q (V_1 - V_2 \cos \theta) + P_1 A_1 - P_2 A_2 \cos \theta \\ &= 1000 \times 0.6 (2.122 - 8.488 \cos 45^\circ) + 8.829 \times 10^4 \times 0.2827 - 5.45 \times 10^4 \times 0.07065 \times \cos 45^\circ \\ &= -2327.9 + 24959.6 - 2720.3 = 24959.6 - 5048.2 = 19911.4 \text{ N} \end{aligned}$$

$$F_x = 19911.4 \text{ N}$$

$$\begin{aligned} F_y &= Q (-V_2 \sin \theta) - P_2 A_2 \sin \theta \\ &= 1000 \times 0.6 (-8.488 \sin 45^\circ) - 5.45 \times 10^4 \times 0.07068 \sin 45^\circ \\ &= -3601.1 - 2721.1 = -6322.2 \text{ N} \end{aligned}$$

(- ve sign means F_y is acting in the down ward direction)

$$F_y = -6322.2 \text{ N}$$

$$\text{Therefore the Resultant Force } F_R = \sqrt{F_x^2 + F_y^2} = \sqrt{(19911.4)^2 + (-6322.2)^2} = 20890.9 \text{ N}$$

$$F_R = 20890.9 \text{ N}$$

The angle made by resultant force with X – axis is $\tan \theta = \frac{F_y}{F_x}$

$$= (6322.2/19911.4) = 0.3175$$

$$\theta = \tan^{-1} 0.3175 = 17.5^\circ$$

UNIT-3

ANALYSIS OF PIPE FLOW

Boundary Layer Characteristics

The concept of boundary layer was first introduced by a German scientist, Ludwig Prandtl, in the year 1904. Although, the complete descriptions of motion of a viscous fluid were known through Navier-Stokes equations, the mathematical difficulties in solving these equations prohibited the theoretical analysis of viscous flow. Prandtl suggested that the viscous flows can be analyzed by dividing the flow into two regions; one close to the solid boundaries and other covering the rest of the flow. Boundary layer is the regions close to the solid boundary where the effects of viscosity are experienced by the flow. In the regions outside the boundary layer, the effect of viscosity is negligible and the fluid is treated as inviscid. So, the boundary layer is a buffer region between the wall below and the inviscid free-stream above. This approach allows the complete solution of viscous fluid flows which would have been impossible through Navier-Stokes equation. The qualitative picture of the boundary-layer growth over a flat plate is shown in Fig. 1.




Fig. 1: Representation of boundary layer on a flat plate.

A laminar boundary layer is initiated at the leading edge of the plate for a short distance and extends to downstream. The transition occurs over a region, after certain length in the downstream followed by fully turbulent boundary layers. For common calculation purposes, the transition is usually considered to occur at a distance where the Reynolds number is about 500,000. With air at standard conditions, moving at a velocity of 30m/s, the transition is expected to occur at a distance of about 250mm. A typical boundary layer flow is characterized by certain parameters as given below;

Boundary layer thickness: It is known that no-slip conditions have to be satisfied at the solid surface: the fluid must attain the zero velocity at the wall. Subsequently, above the wall, the effect of viscosity tends to reduce and the fluid within this layer will try to approach the free stream velocity. Thus, there is a velocity gradient that develops within the fluid layers inside the small regions near to solid surface. The *boundary layer thickness* is defined as the distance from the surface to a point where the velocity is reaches 99% of the free stream velocity. Thus, the velocity profile merges smoothly and asymptotically into the free stream as shown in Fig. 2.





Fig. 5.7.3: (a) Boundary layer thickness; (b) Free stream flow (no viscosity);
(c) Concepts of displacement thickness.

Fig. 2: (a) Boundary layer thickness; (b) Free stream flow (no viscosity);
(c) Concepts of displacement thickness.

CLOSED CONDUIT FLOW:

REYNOLDS EXPERIMENT: It consists of a constant head tank filled with water, a small tank containing dye, a horizontal glass tube provided with a bell-mouthed entrance and a regulating valve. The water was made to flow from the tank through the glass tube into the atmosphere and the velocity of flow was varied by adjusting the regulating valve. The liquid dye having the same specific weight as that of water was introduced into the flow at the bell-mouth through a small tube



From the experiments it was disclosed that when the velocity of flow was low, the dye remained in the form of a straight line and stable filament passing through the glass tube so steady that it scarcely seemed to be in motion with increase in the velocity of flow a critical state was reached at which the filament of dye showed irregularities and began to waver. Further increase in the velocity of flow the fluctuations in the filament of dye became more intense and ultimately the dye diffused over the entire cross-section of the tube, due to intermingling of the particles of the flowing fluid

Reynolds deduced from his experiments that at low velocities the intermingling of the fluid particles was absent and the fluid particles moved in parallel layers or lamina, sliding past the adjacent lamina but not mixing with them. This is the laminar flow. At higher velocities the dye filament diffused through the tube it was apparent that the intermingling of fluid particles was occurring in other words the flow was turbulent. The velocity at which the flow changes from the laminar to turbulent for the case of a given fluid at a given temperature and in a given pipe is known as Critical Velocity. The state of flow in between these types of flow is known as transitional state or flow in transition.

Reynolds discovered that the occurrence of laminar and turbulent flow was governed by the relative magnitudes of the inertia and the viscous forces. At low velocities the viscous forces become predominant and flow is viscous. At higher velocities of flow the inertial forces predominate over viscous forces. Reynolds related the inertia to viscous forces and arrived at a dimensionless parameter.

$$\frac{\text{inertia force}}{\text{viscous force}} = \frac{\rho V L}{\mu}$$

According to Newton's 2nd law of motion, the inertia force F_i is given by

$$\begin{aligned} F_i &= \text{mass} \times \text{acceleration} \\ &= \rho \times \text{volume} \times \text{acceleration} \quad \rho = \text{mass density} \\ &= \rho \times L^3 \times \frac{V}{T^2} = \rho L^2 V^2 \quad \text{----- (1)} \quad L = \text{Linear dimension} \end{aligned}$$

Similarly viscous force F_v is given by Newton's 2nd law of velocity as

$$\begin{aligned} F_v &= \tau \times \text{area} \quad \tau = \text{shear stress} \\ &= \mu \frac{dv}{dy} \times L^2 = \mu V L \quad \text{----- (2)} \quad V = \text{Average Velocity of flow} \\ &\quad \mu = \text{Viscosity of fluid} \end{aligned}$$

$$R \text{ or } N_e = \frac{\rho L^2 V^2}{\mu V L} = \frac{\rho V L}{\mu}$$

In case of pipes $L = D$

$$\text{In case of flow through pipes} \quad = \frac{\rho D V}{\mu} \quad \text{or} \quad \frac{\rho V D}{\mu}$$

Where μ/ρ = kinematic viscosity of the flowing liquid ν

The Reynolds number is a very useful parameter in predicting whether the flow is laminar or turbulent.


$Re < 2000$ viscous / laminar flow

$Re \rightarrow 2000$ to 4000 transient flow

$Re > 4000$ Turbulent flow

FRICTIONAL LOSS IN PIPE FLOW - DARCY WEISBACK EQUATION

When a liquid is flowing through a pipe, the velocity of the liquid layer adjacent to the pipe wall is zero. The velocity of liquid goes on increasing from the wall and thus velocity gradient and hence shear stresses are produced in the whole liquid due to viscosity. This viscous action causes loss of energy, which is known as frictional loss.



Consider a uniform horizontal pipe having steady flow. Let 1-1, 2-2 are two sections of pipe.

Let P_1 = Pressure intensity at section 1-1

V_1 = Velocity of flow at section 1-1

L = Length of pipe between section 1-1 and 2-2

d = Diameter of pipe

f = Fractional resistance for unit wetted area per a unit velocity
 h_f = Loss of head due to friction

And P_2, V_2 = are values of pressure intensity and velocity at section 2-2

Applying Bernoulli's equation between sections 1-1 and 2-2

Total head at 1-1 = total head at 2-2 + loss of head due to friction between 1-1 and 2-2

$$\frac{P_1}{\rho g} + \frac{V_1^2}{2g} + Z_1 = \frac{P_2}{\rho g} + \frac{V_2^2}{2g} + Z_2 + h_f$$

$Z_1 = Z_2$ as pipe is horizontal

$V_1 = V_2$ as dia. of pipe is same at 1-1 and 2-2

$$\frac{P_1}{\rho g} = \frac{P_2}{\rho g} + h_f \quad \text{Or}$$

$$\boxed{}_{} = \frac{\boxed{}}{\boxed{}\boxed{}} - \frac{\boxed{}}{\boxed{}\boxed{}} \quad \text{---(1)}$$

But h_f is head is lost due to friction and hence the intensity of pressure will be reduced in the direction flow by frictional resistance.

Now, Frictional Resistance = Frictional resistance per unit wetted area per unit velocity
 $\times \text{Wetted Area} \times (\text{velocity})^2$

$$\Delta_1 = \Delta' \times \Delta \Delta \Delta \times \Delta^2 \quad [\because \text{Wetted area} = \Delta \Delta \times \Delta, \text{Velocity} = V = V_1 = V_2]$$

$$\Delta_1 = \Delta' \times \Delta \Delta \Delta^2 \text{_____} (2) \quad [\because \Delta d = \text{perimeter} = p]$$

The forces acting on the fluid between section 1-1 and 2-2 are

Pressure force at section 1-1 = $P_1 \times A$ where A = area of pipe

Pressure force at section 2-2 = $P_2 \times A$

Frictional force = F_1

Resolving all forces in the horizontal direction, we have

$$P_1 A - P_2 A - F_1 = 0$$

$$(P_1 - P_2)A = F_1 = \Delta' \times \Delta \times \Delta \times \Delta^2 \quad \text{from equation - (2)}$$

$$P_1 - P_2 = \frac{\Delta' \times \Delta \times \Delta \times \Delta^2}{A} \quad \text{But from equation (1) } P_1 - P_2 = \rho g h_f$$

Equating the value of $P_1 - P_2$, we get

$$\rho g h_f = \frac{\Delta' \times \Delta \times \Delta \times \Delta^2}{A}$$

$$\Delta \Delta = \frac{f'}{pg} \times \frac{P}{A} \times L \times V^2 \text{_____} (3)$$

In the equation (3) $\frac{P}{A} = \frac{\text{Wetted Perimeter}}{\text{Area}} = \frac{\pi d}{\frac{\pi d^2}{4}} = \frac{4}{d}$

$$\Delta \Delta = \frac{\Delta'}{pg} \times \frac{4}{d} \times \Delta \times \Delta^2 = \frac{\Delta'}{pg} \times \frac{4 \Delta \Delta^2}{d}$$

Putting Δ'
 Δ

$$\frac{\Delta}{\Delta} = \frac{f}{2} \quad \text{Where } f \text{ is known as co-efficient of friction.}$$

$$\text{Equation (4) becomes as } \frac{h_f}{L} = \frac{4f}{2g} \times \frac{V^2}{2g}$$

$$\frac{h_f}{L} = \frac{4f}{2g} \times \frac{V^2}{2g}$$

This Equation is known as Darcy – Weisbach equation, commonly used for finding loss of head due to friction in pipes

Then f is known as a friction factor or co-efficient of friction which is a dimensionless quantity. f is not a constant but, its value depends upon the roughness condition of pipe surface and the Reynolds number of the flow.

MINOR LOSSES IN PIPES:

The loss of energy due to friction is classified as a major loss, because in case of long pipe lines it is much more than the loss of energy incurred by other causes.

The minor losses of energy are caused on account of the change in the velocity of flowing fluids (either in magnitude or direction). In case of long pipes these losses are quite small as compared with the loss of energy due to friction and hence these are termed as „minor losses „

Which may even be neglected without serious error However in short pipes these losses may sometimes outweigh the friction loss. Some of the losses of energy which may be caused due to the change of velocity are:

1 Loss of energy due to sudden enlargement $= \frac{V_1^2 - V_2^2}{2g}$

2 Loss of energy due to sudden contraction $= 0.5 \frac{V_2^2}{2g}$

3 Loss of energy at the entrance to a pipe $= 0.5 \frac{V^2}{2g}$

4 Loss of energy at the exit from a pipe $= \frac{V^2}{2g}$

5 Loss of energy due to gradual contraction or enlargement $= \frac{K(V_1 - V_2)^2}{2g}$


6 Loss of energy in the bends $= \frac{K V^2}{2g}$

7 Loss of energy in various pipe fittings $= \frac{K V^2}{2g}$

$$= \frac{\square\square^2}{2\square}$$

1. LOSS OF HEAD DUE TO SUDDEN ENLARGEMENT

Consider a liquid flowing through a pipe which has sudden enlargement. Consider two sections 1-1 and 2-2 before and after enlargement. Due to sudden change of diameter of the pipe from D_1 to D_2 , The liquid flowing from the smaller pipe is not able to follow the abrupt change of the boundary. Thus the flow separates from the boundary and turbulent eddies are formed. The loss of head takes place due to the formation of these eddies.



Let $\square' =$ Pressure intensity of the liquid eddies on the area $(A_2 - A_1)$

$h_e =$ loss of head due to the sudden enlargement.

Applying Bernoulli's equation at section 1-1 and 2-2

$$\frac{\square_1}{\square\square} + \frac{\square_1^2}{2\square} + \square_1 = \frac{\square_2}{\square\square} + \frac{\square_2^2}{2\square} + \square_2 + \text{Loss of head due to sudden enlargement}$$

But $z_1 = z_2$ as pipe is horizontal

$$\frac{\square_1}{\square\square} + \frac{\square_1^2}{2\square} = \frac{\square_2}{\square\square} + \frac{\square_2^2}{2\square} + \square$$

Or
$$\square = \frac{\square_1}{\square\square} - \frac{\square_2}{\square\square} + \frac{\square_1^2}{2\square} - \frac{\square_2^2}{2\square} \quad \text{---(1)}$$

The force acting on the liquid in the control volume in the direction of flow

$$\square\square = \square_1\square_1 + \square' \square_2 - \square_1 - \square_2\square_2$$

But experimentally it is found that $\square' = \square_1$

$$\square\square = \square_1\square_1 + \square_1 \square_2 - \square_1 - \square_2\square_2$$

$$= \square_1\square_2 - \square_2\square_2$$

$$= \square_1 - \square_2 \square_2 \quad \text{---(2)}$$

Momentum of liquid/ second at section 1-1 = mass $\times$ velocity

$$= \square\square_1\square_1 \times \square_1$$

$$= \square\square_1\square_1^2$$

Momentum of liquid/ second at section 2-2 $\square\square_2\square_2 \times \square_2 = \square\square_2\square_2^2$

$$\text{Change of momentum/second} = \rho_2 A_2 v_2^2 - \rho_1 A_1 v_1^2 \text{-----(3)}$$

But from continuity equation, we have

$$A_1 V_1 = A_2 V_2$$

Or
$$V_1 = \frac{A_2 V_2}{A_1}$$

$$\begin{aligned} \therefore \text{Change of momentum/sec} &= \frac{A_2 V_2^2}{2} - \frac{A_1 V_1^2}{2} \times \frac{A_2 V_2}{A_1} \times \frac{1}{V_1} \\ &= \frac{A_2 V_2^2}{2} - \frac{A_1 V_1^2}{2} \\ &= \frac{A_2 V_2^2}{2} - \frac{A_1 V_1^2}{2} \quad (4) \end{aligned}$$

Now the net force acting on the control volume in the direction of flow must be equal to rate of change of momentum per second. Hence equating equation (2) and equation (4)

$$\begin{aligned} p_1 A_1 - p_2 A_2 &= \frac{A_2 V_2^2}{2} - \frac{A_1 V_1^2}{2} \\ \frac{p_1 A_1 - p_2 A_2}{A_1} &= \frac{A_2 V_2^2}{2} - \frac{A_1 V_1^2}{2} \end{aligned}$$

Dividing both sides by „g“ we have
$$\frac{p_1 A_1 - p_2 A_2}{A_1 g} = \frac{A_2 V_2^2}{2g} - \frac{A_1 V_1^2}{2g}$$


Or
$$\frac{p_1}{\rho g} - \frac{p_2}{\rho g} = \frac{A_2 V_2^2}{2g} - \frac{A_1 V_1^2}{2g}$$

Substituting in equation (1)

$$\begin{aligned} \frac{p_1}{\rho g} - \frac{p_2}{\rho g} &= \frac{A_2 V_2^2}{2g} - \frac{A_1 V_1^2}{2g} + \frac{A_2 V_2^2}{2g} - \frac{A_1 V_1^2}{2g} \\ &= \frac{A_1^2 V_1^2 + A_2^2 V_2^2 - 2A_1 A_2 V_1 V_2}{2g} \\ &= \frac{A_1^2 - A_2^2}{2g} \end{aligned}$$

2. LOSS OF HEAD DUE TO SUDDEN CONTRACTION

Consider a liquid flowing in a pipe, which has a sudden contraction in area. Consider two sections 1-1 and 2-2 before and after contraction. As the liquid flows from larger pipe to smaller pipe, the area of flow goes on decreasing and becomes minimum at section C - C. This section is called Vena-contracta. After section C-C, a sudden enlargement of area takes place. The loss of head due to sudden contraction is actually due to sudden enlargement of area from vena-contracta to smaller pipe.



Let A_c = Area of flow at section C - C

V_c = Velocity of flow at section C - C

A_2 = Area of flow at section 2 - 2

V_2 = Velocity of flow at section 2 - 2

h_c = Loss of head due to sudden contraction

Now, h_c = Actual loss of head due to sudden enlargement from section C - C to section 2-2 is

$$h_c = \frac{V_c^2 - V_2^2}{2g} = \frac{V_c^2}{2g} \left(1 - \frac{A_c^2}{A_2^2} \right) \quad (1)$$

From continuity equation, we have

$$A_c V_c = A_2 V_2 \quad \text{Or} \quad \frac{V_c}{V_2} = \frac{A_2}{A_c} = \frac{1}{C_c} \quad \therefore V_c = \frac{V_2}{C_c}$$

Substituting the value of $\frac{V_c}{V_2}$ in equation (1)

$$h_c = \frac{V_2^2}{2g} \left(\frac{1}{C_c^2} - 1 \right) = \frac{V_2^2}{2g} \left(\frac{1}{C_c^2} - 1 \right) \quad \text{Where } k = \frac{1}{C_c^2} - 1$$

If the value of C_c is assumed to be equal to 0.62, then

$$\frac{1}{C_c^2} - 1 = \frac{1}{0.62^2} - 1 = 0.375$$

Then h_c becomes as

$$h_c = \frac{V_2^2}{2g} \times 0.375 = 0.375 \frac{V_2^2}{2g}$$

If the value of C_c is not given, then the head loss due to contraction is taken as

$$h_c = 0.5 \frac{V_2^2}{2g}$$

3. LOSS OF HEAD AT THE ENTRANCE OF A PIPE

This is the loss of energy which occurs when a liquid enters a pipe which is connected to a large tank or reservoir. This loss is similar to the loss of head due to sudden contraction. This loss depends on the form of entrance. For a sharp edge entrance, this loss is slightly more than a rounded or bell mouthed entrance. In practice the value of loss of head at the entrance. In practice the value of loss of head at the entrance (inlet) of a pipe with sharp cornered entrance is taken as $0.5 \frac{v^2}{2g}$ where v = velocity of liquid in pipe. This loss is denoted by h_f

$$h_f = 0.5 \frac{v^2}{2g}$$

4. LOSS OF HEAD AT THE EXIT OF A PIPE

This loss of head (or energy) due to the velocity of the liquid at the out let of the pipe, which is dissipated either in the form of a free jet (if the out let of the pipe is free) or it is lost in the tank or reservoir. This loss is equal to $\frac{V^2}{2g}$, where V is the velocity of liquid at the out let of the pipe. This loss is denoted by h_o .

$$h_o = \frac{V^2}{2g} \quad V = \text{velocity at outlet of the pipe}$$

5. LOSS OF HEAD DUE TO OBSTRUCTION IN A PIPE

Whenever there is an obstruction in a pipe, the loss of energy takes place due to reduction of the area of the cross section of the pipe at the place where obstruction is present. There is a sudden enlargement of the area of flow beyond the obstruction due to which loss of head takes place.


Consider a pipe of area of cross-section A having an obstruction

Let a = max. Area of obstruction

A = Area of pipe

V = velocity of liquid in pipe

Then $(A - a)$ = Area of flow of liquid at section 1-1



As the liquid flows and passes through section 1-1, a vena-contracta is formed beyond section 1-1- after which the stream of liquid widens again and velocity of flow at section on 2-2 become uniform and equal to velocity, v in the pipe. This situation is similar to the flow of liquid through sudden enlargement.

Let V_c = velocity of liquid at vena-contracta

Then loss of head due to obstruction = loss of head due to enlargement from vena-contracta to section 2-2

$$= \frac{V_c^2 - V^2}{2g} \quad (1)$$

From continuity equation we have $a_c V_c = A V$ (2)

Where a_c = Area of cross section at vena-contracta

If C_c = co-efficient of contraction

$$\text{Then } a_c = C_c (A - a)$$

Substituting this value in equation (2) $C_c (A - a) V_c = A V$

$$\therefore V_c = \frac{A V}{C_c (A - a)}$$

Substituting this value of V_c in equation (1)

$$\text{Head loss due to obstruction} = \frac{V_c^2 - V^2}{2g} = \frac{\left(\frac{A V}{C_c (A - a)}\right)^2 - V^2}{2g} = \frac{V^2}{2g} \left[\frac{A^2}{C_c^2 (A - a)^2} - 1 \right]$$

6. LOSS OF HEAD DUE TO BEND IN PIPE:

When there is a bend in a pipe, the velocity flow changes, due to which separation of the flow from the boundary and also formation of eddies takes place, thus the energy is lost.

Loss of head in pipe due to bend is expressed as

$$h_b = \frac{V^2}{2g}$$

Where, h_b = Loss of head due to bend, V = Velocity of flow, k = Co-efficient of bend.

The value of k depends on

1. Angle of bend,
2. Radius of curvature of bend,
3. Diameter of pipe.

7. LOSS OF HEAD IN VARIOUS PIPE FITTINGS:

The loss of head in various pipe fittings such as valves, couplings etc. is expressed as

$$h_b = \frac{k V^2}{2g}$$

Where V = Velocity of flow, k = co-efficient of pipe fitting.

LOSS OF ENERGY DUE TO GRADUAL CONTRACTION OR ENLARGEMENT:

The loss of energy can be considerably reduced if in place of a sudden contraction or sudden enlargement a gradual contraction or gradual enlargement is provided. This is because in gradual contraction or enlargement the velocity of flow is gradually increased or reduced, the formation of eddies responsible for dissipation of energy are eliminated.

The loss of head in gradual contraction or gradual enlargement is expressed as


$$h_c = \frac{K (V_1 - V_2)^2}{2g}$$

Where K is a co-efficient and V_1 and V_2 are the mean velocities at the inlet and the outlet. The value of K depends on the angle of convergence or divergence and on the ratio of the upstream and the downstream cross-sectional areas. For gradual contraction the value of K is very small even for larger values of the angle of convergence. For gradual contraction without sharp corners the loss of energy caused is so small that it may be neglected.

For gradual enlargement the value of K depends on the angle of divergence.

The value of K increases as the angle of divergence increases for a given ratio of the cross-sectional areas at the inlet and at the outlet. In the case of gradual enlargement, except for very small angles of divergence, the flow of fluid is always subjected to separation from the boundaries and consequent formation of the eddies resulting in loss of energy. Therefore in the case of gradual enlargement the loss of energy can't be completely eliminated.

PIPES IN SERIES:



If a pipe line connecting two reservoirs is made up of several pipes of different diameters d_1 , d_2 , d_3 , etc. and lengths L_1 , L_2 , L_3 etc. all connected in series (i.e. end to end), then the difference in the liquid surface levels is equal to the sum of the head losses in all the sections. Further the discharge through each pipe will be same.

$$H = \frac{0.5v^2}{2g} + \frac{4fL_1v^2}{2gd_1} + \frac{0.5v^2}{2g} + \frac{4fL_2v^2}{2gd_2} + \frac{0.5v^2}{2g} + \frac{4fL_3v^2}{2gd_3}$$

Also
$$v = \frac{Q}{A_1} = \frac{Q}{A_2} = \frac{Q}{A_3}$$

However if the minor losses are neglected as compared with the loss of head due to friction in each pipe, then

$$H = \frac{4fL_1v^2}{2gd_1} + \frac{4fL_2v^2}{2gd_2} + \frac{4fL_3v^2}{2gd_3}$$

The above equation may be used to solve the problems of pipe lines in series. There are two types of problems which may arise for the pipe lines in series. Viz.


- Given a discharge Q to determine the head H and
- Given H to determine discharge Q .

If the co-efficient of friction is same for all the pipes i.e. $f_1 = f_2 = f_3$, then

$$H = \frac{4fL_1v^2}{2gd_1} + \frac{4fL_2v^2}{2gd_2} + \frac{4fL_3v^2}{2gd_3}$$

PIPES IN PARALLEL:

When a main pipeline divides in to two or more parallel pipes, which may again join together downstream and continue as main line, the pipes are said to be in parallel. The pipes are connected in parallel in order to increase the discharge passing through the main. It is analogous to parallel electric current in which the drop in potential and flow of electric current can be compared to head loss and rate of discharge in a fluid flow respectively.



The rate of discharge in the main line is equal to the sum of the discharges in each of the parallel pipes.

$$\text{Thus } Q = Q_1 + Q_2$$


The flow of liquid in pipes (1) and (2) takes place under the difference of head between the sections A and B and hence the loss of head between the sections A and B will be the same whether the liquid flows through pipe (1) or pipe (2). Thus if D_1 , D_2 and L_1 , L_2 are the diameters and lengths of the pipes (1) and (2) respectively, then the velocities of flow V_1 and V_2 in the two pipes must be such as to give

$$\frac{f L_1 Q_1^2}{2 D_1^5} = \frac{f L_2 Q_2^2}{2 D_2^5}$$

Assuming same value of f for each parallel pipe

$$\frac{L_1 Q_1^2}{D_1^5} = \frac{L_2 Q_2^2}{D_2^5}$$

HYDRAULIC GRADIENT LINE AND TOTAL ENERGY LINE:



Consider a long pipe line carrying liquid from a reservoir A to reservoir B. At several points along the pipeline let piezo meters be installed. The liquid will rise in the piezometers to certain heights corresponding to the pressure intensity at each section. The height of the liquid surface above the axis of the pipe in the piezometer at any section will be equal to the pressure head (p/w) at that section. On account of loss of energy due to friction, the pressure head will decrease gradually from section to section of pipe in the direction of flow. If the pressure heads at the different sections of the pipe are plotted to scale as vertical ordinates above the axis of the pipe and all these points are joined by a straight line, a sloping line is obtained, which is known as Hydraulic Gradient Line (H.G.L.).

Since at any section of pipe the vertical distance between the pipe axis and Hydraulic gradient line is equal to the pressure head at that section, it is also known as pressure line. Moreover if Z is the height of the pipe axis at any section above an arbitrary datum, then the vertical height of the Hydraulic gradient line above the datum at that section of pipe represents the piezometric head equal to $(p/w + z)$. Sometimes the Hydraulic gradient line is also known as piezometric head line.

At the entrance section of the pipe for some distance the Hydraulic gradient line is not very well defined. This is because as liquid from the reservoir enters the pipe, a sudden drop in pressure head takes place in this portion of pipe. Further the exit section of pipe being submerged, the pressure head at this section is equal to the height of the liquid surface in the reservoir B and hence the hydraulic gradient line at the exit section of pipe will meet the liquid surface in the reservoir B.

If at different sections of pipe the total energy (in terms of head) is plotted to scale as vertical ordinate above the assumed datum and all these points are joined, then a straight sloping line will be obtained and is known as energy grade line or Total energy line (T.E.L.). Since total energy at any section is the sum of the pressure head (p/w), datum head z and velocity head $\frac{V^2}{2g}$ and the vertical distance between the datum and hydraulic grade line is

2

2□

equal to the piezometric head ($p/w + z$), the energy grade line will be parallel to the hydraulic grade line, with a vertical distance between them equal to $\frac{V^2}{2g}$

2π . at the entrance section of the

pipe there occurs some loss of energy called “Entrance loss” equal to $h_L = 0.5 \frac{V^2}{2g}$ and hence

the energy grade line at this section will lie at a vertical depth equal to $0.5 \frac{V^2}{2g}$ below the

liquid surface in the reservoir A. Similarly at the exit section of pipe, since there occurs an exit loss equal to $h_L = \frac{V^2}{2g}$. The energy gradient line at this section will lie at a vertical

distance equal to $\frac{V^2}{2g}$ above the liquid surface in the reservoir B. Since at any section of pipe


the vertical distance between the energy grade line and the horizontal line drawn through the liquid surface in reservoir A will represent the total loss of energy incurred up to that section.

If the pipe line connecting the two reservoirs is horizontal, then the datum may be assumed to be along the pipe axis only. The piezometric head and the pressure head will then become the same.

If a pipe line carrying liquid from reservoir A discharges freely in to the atmosphere at its exit end, the hydraulic grade line at the exit end of the pipe will pass through the centre line of the pipe, since the pressure head at the exit end of the pipe will be zero (being atmospheric). The energy grade line will again be parallel to the hydraulic grade line and it will be at a vertical distance of $\frac{V^2}{2g}$ above the Hydraulic grade line

PITOT – TUBE

A Pitot tube is a simple device used for measuring the velocity of flow. The basic principle used in this is that if the velocity of flow at a particular point is reduced to zero, which is known as stagnation point, the pressure there is increased due to conversion of the kinetic energy in to pressure energy and by measuring the increase in pressure energy at this point, the velocity of flow may be determined.



Simplest form of a pitot tube consists of a glass tube, large enough for capillary effects to be negligible and bent at right angles. A single tube of this type is used for

measuring the velocity of flow in an open channel. The tube is dipped vertically in the flowing stream of fluid with its open end A directed to face the flow and other open end projecting above the fluid surface in the stream. The fluid enters the tube and the level of the

fluid in the tube exceeds that of the fluid surface in the surrounding stream. This is so because

the end A of the tube is a stagnation point, where the fluid is at rest, and the fluid approaching end A divides at this point and passes around tube. Since at stagnation point the kinetic energy is converted into pressure energy, the fluid in the tube rises above the surrounding fluid surface by a height, which corresponds to the velocity of flow of fluid approaching end A of the tube. The pressure at the stagnation point is known as stagnation pressure.

Consider a point 1 slightly upstream of end A and lying along the same horizontal plane in the flowing stream of velocity V . Now if the point 1 and A are at a vertical depth of h_0 from the free surface of fluid and h is the height of the fluid raised in the pitot tube above the free surface of the liquid. Then by applying Bernoulli's equation between the point 1 and A, neglecting loss of energy, we get

$$\frac{p_1}{\rho} + \frac{V_1^2}{2} = \frac{p_A}{\rho} + \frac{V_A^2}{2}$$

$(h_0 + h)$ is the stagnation pressure head at a point A, which consists of static pressure head h_0 and dynamic pressure head h . Simplifying the expression,

$$\frac{V^2}{2} = \frac{p_A - p_1}{\rho} \quad \text{Or} \quad V = \sqrt{2 \frac{p_A - p_1}{\rho}} \quad (1)$$

This equation indicates that the dynamic pressure head h is proportional to the square of the velocity of flow close to end A.

Thus the velocity of flow at any point in the flowing stream may be determined by dipping the Pitot tube to the required point and measuring the height „ h “ of the fluid raised in the tube above the free surface. The velocity of flow given by the above equation (1) is more than actual velocity of flow as no loss of energy is considered in deriving the above equation.

When the flow is highly turbulent the Pitot tube records a higher value of h , which is higher than the mean velocity of flow. In order to take into account the errors due to the above factors, the actual velocity of flow may be obtained by introducing a co-efficient C or C_v called Pitot tube co-efficient. So the actual velocity is given by

$$V = C \sqrt{2 \frac{p_A - p_1}{\rho}} \quad (\text{Probable value of } C \text{ is } 0.98)$$

When a pitot tube is used for measuring the velocity of a flow in a pipe, the Pitot tube may be inserted in a pipe. Since pitot tube measures the stagnation pressure head (or the total head) at its dipped end, the static pressure head is also required to be measured at the same section, where tip of pitot tube is held, in order to determine the dynamic pressure head „ h “. For measuring the static pressure head a pressure tap is provided at this section to which a piezo meter may be connected. Alternatively a dynamic pressure head may also be determined directly by connecting a suitable differential manometer between the pitot tube and pressure tap.

Consider point 1 slightly up stream of the stagnation point 2.

Applying Bernoulli's equation between the points 1 and 2, we get

$$\frac{p_1}{\rho} + \frac{V_1^2}{2} = \frac{p_2}{\rho} \quad (2)$$

Where P_1 and P_2 are the pressure intensities at points 1 and 2, V is velocity of flow at point 1 and γ is the specific weight of the fluid flowing through the pipe. P_1 is the static pressure and P_2 is the stagnation pressure. The equation for the pressure through the manometer in meters of water may be written as,

$$\frac{\gamma}{\gamma_m} \left(\frac{P_2}{\gamma} + \frac{\rho V^2}{2} \right) + \frac{\gamma}{\gamma_m} \left(\frac{P_1}{\gamma} + \frac{\rho V^2}{2} \right) = \frac{\gamma}{\gamma_m} \left(\frac{P_2}{\gamma} + \frac{\rho V^2}{2} \right) \quad (3)$$

Where s and s_m are the specific gravities of the fluid flowing in the pipe and the manometric liquid respectively. By simplifying


$$\frac{P_2}{\gamma} - \frac{P_1}{\gamma} = \frac{\rho V^2}{2} - 1$$

After substituting for $\left(\frac{P_2}{\gamma} - \frac{P_1}{\gamma} \right)$ in the equation (2) and solving for V

$$= \frac{\gamma}{2 \gamma_m} \left(\frac{\rho V^2}{\gamma} - 1 \right)$$

VENTURI METER

A venturi meter is a device used for measuring the rate of flow of fluid through a pipe. The basic principle on which venturi meter works is that by reducing the cross-sectional area of the flow passage, a pressure difference is created and the measurement of the pressure difference enables the determination of the discharge through the pipe.



A venturi meter consists of (1) an inlet section, followed by a converging cone (2) a cylindrical throat and (3) a gradually divergent cone. The inlet section of venturi meter is the same diameter as that of the pipe which is followed by a convergent cone. The convergent cone is a short pipe, which tapers from the original size of the pipe to that of the throat of the venturi meter. The throat of the venturi meter is a short parallel – sided tube having its cross-sectional area smaller than that of the pipe. The divergent cone of the venturi meter is a gradually diverging pipe with its cross-sectional area increasing from that of the throat to the original size of the pipe. At the inlet section and the throat i.e sections 1 and 2 of the venturi meter pressure gauges are provided.

The convergent cone of the venturi meter has a total included angle of $21^\circ + 1^\circ$ and its length parallel to the axis is approx. equal to $2.7(D-d)$, where D is the dia. of pipe at inlet section and d is the dia. of the throat. The length of the throat is equal to d . The divergent cone has a total included angle 5° to 15° , preferably about 6° . This results in the convergent cone of the venturi meter to be of smaller length than its divergent cone. In the convergent cone the fluid is being accelerated from the inlet section 1 to the throat section 2, but in the divergent cone the fluid is retarded from the throat section 2 to the end section 3 of the venturi meter. The acceleration of the flowing fluid may be allowed to take place rapidly in a relatively small length without resulting in loss of energy. However if the retardation of the flow is allowed to take place rapidly in small length, then the flowing fluid will not remain in contact with the boundary of the diverging flow passage or the flow separates from the walls and eddies are formed and consequent energy loss. Therefore to avoid flow separation and consequent energy loss, the divergent cone is made longer with a gradual divergence. Since separation may occur in the divergent cone this portion is not used for discharge measurement.

Since the cross-sectional area of the throat is smaller than the cross-sectional area of the inlet section, the velocity of flow at the throat will become greater than that at inlet section, according to continuity equation. The increase in the velocity of flow at the throat results in the decrease in the pressure. As such a pressure difference is developed between the inlet section and the throat section of the venturi meter. The pressure difference between these sections can be determined either by connecting differential manometer or pressure gauges. The measurement of the pressure difference between these sections enables the rate of flow of fluid to be calculated. For greater accuracy the cross-sectional area of the throat is reduced so that the pressure at the throat is very much reduced. But if the cross-sectional area

of the throat is reduced so much that pressure drops below the vapour pressure of the flowing liquid. The formation of vapour and air pockets results in cavitation, which is not desirable. Therefore in order to avoid cavitation to occur, the diameter of the throat can be reduced to 1/3 to 3/4 of pipe diameter, more commonly the diameter of the throat is 1/2 of pipe diameter.

Let a_1 and a_2 be the cross-section areas at inlet and throat sections, at which P_1 and P_2 the pressures and velocities V_1 and V_2 respectively. Assuming the flowing fluid is incompressible and there is no loss of energy between section 1 and 2 and applying Bernoulli's equation between sections 1 and 2, we get,

$$\frac{P_1}{\rho} + \frac{V_1^2}{2} + Z_1 = \frac{P_2}{\rho} + \frac{V_2^2}{2} + Z_2$$

Where ρ is the specific weight of flowing fluid.

If the venturi meter is connected in a horizontal pipe, then $Z_1 = Z_2$, then

$$\frac{P_1}{\rho} + \frac{V_1^2}{2} = \frac{P_2}{\rho} + \frac{V_2^2}{2}$$

$$\frac{P_1}{\rho} - \frac{P_2}{\rho} = \frac{V_2^2}{2} - \frac{V_1^2}{2}$$

In the above expression $\frac{P_1}{\rho} - \frac{P_2}{\rho}$ is the difference between the pressure heads

at section 1 and 2, is known as venturi head and is denoted by h

$$h = \frac{P_1}{\rho} - \frac{P_2}{\rho}$$

$$P_1 - P_2 = \rho h$$

$$\frac{P_1}{\rho} - \frac{P_2}{\rho} = \frac{V_2^2}{2} - \frac{V_1^2}{2}$$

$$\rho h = \frac{V_2^2}{2} - \frac{V_1^2}{2}$$

$$h = \frac{V_2^2 - V_1^2}{2}$$

$$h = \frac{V_2^2 - V_1^2}{2}$$

$$h = \frac{V_2^2 - V_1^2}{2}$$

$$\therefore V_2 = \frac{1}{\sqrt{1 - \frac{A_2^2}{A_1^2}}} \sqrt{2gh}$$


$$C_d = \frac{Q}{Q_{th}} = \frac{A_2 V_2}{A_1 \sqrt{2gh}}$$

C_d = Co-efficient of discharge < 1

ORIFICE METER

An orifice meter is a simple device for measuring the discharge through pipes. Orifice meter also works on the same principle as that of venturimeter i.e by reducing cross-sectional area of the flow passage, a pressure difference between the two sections is developed and the measurement of the pressure difference enables the determination of the discharge through the pipe. Orifice meter is a cheaper arrangement and requires smaller length and can be used where space is limited.

An orifice meter consists of a flat circular plate with a circular hole called orifice, which is concentric with the pipe axis. The thickness of the plate t is less than or equal to 0.05



times the diameter of pipe. From the upstream face of the plate the edge of the orifice is made flat for a thickness 0.02 times the diameter of pipe and the remaining thickness the plate is beveled with the bevel angle 45°. The diameter of the orifice is kept at 0.5 times the diameter of pipe. Two pressure taps are provided one at section 1 on upstream side of the orifice plate and other at section 2 on the downstream side of the orifice plate. The upstream tap is located at a distance of 0.9 to 1.1 times the pipe diameter from the orifice plate. The position of downstream pressure tap, however depends on the ratio of the orifice diameter and the pipe diameter. Since the orifice diameter is less than pipe diameter as the fluid flows through the orifice, the flowing stream converges, which results in the acceleration of the flowing fluid in accordance with the consideration of continuity. The effect of convergence of flowing stream extends up to a certain distance upstream from the orifice plate and therefore the pressure tap on the upstream side is provided away from the orifice plate at a section where this effect is non-existent. However on the downstream side the pressure tap is provided quite close to the orifice plate at a section where the converging jet of fluid has the smallest cross-sectional area (which is known as veena- contracta) resulting in the max. velocity of flow and consequently the min. pressure at this section. Therefore a max. Pressure difference exists between the section 1 and 2, which is measured by connecting a differential manometer between the pressure taps at these sections or connecting separate pressure gauges. The jet of fluid coming out of the orifice gradually expands from the veena-contracta to again fill the pipe. In case of an orifice meter an abrupt change in the cross-sectional area of the flow passage is provided and there being no gradual change in the cross-sectional area of flow passage as in the case of venturimeter, there is a greater loss of energy in an orifice meter.

Let p_1, p_2 and v_1, v_2 be the pressures and velocities at sections 1 and 2 respectively. Then for an incompressible fluid, applying Bernoulli's equation between section 1 and 2 and neglecting losses, we have

$$\begin{aligned}
 \frac{p_1}{\rho} + \frac{v_1^2}{2} + \frac{z_1}{2} &= \frac{p_2}{\rho} + \frac{v_2^2}{2} + \frac{z_2}{2} \\
 \text{Or } \frac{p_1}{\rho} + \frac{v_1^2}{2} &= \frac{p_2}{\rho} + \frac{v_2^2}{2} \quad \text{--- (1)}
 \end{aligned}$$

Where h is the difference between piezo metric heads at sections 1 and 2. However if the orifice meter is connected in a horizontal pipe, then $z_1 = z_2$, in which case h will represent the pressure head difference between sections 1 and 2. From equation (1) we have

$$v_2 = \sqrt{2gh + v_1^2} \quad (2)$$

In deriving the above expression losses have not been considered, this expression gives the theoretical velocity of flow at section 2. To obtain actual velocity, it must be multiplied by a factor C_v , called co-efficient of velocity, which is defined as the ratio between the actual velocity and theoretical velocity. Thus actual velocity of flow at section 2 is obtained as

$$v_2 = C_v \sqrt{2gh + v_1^2} \quad (3)$$

Further if a_1 and a_2 are the cross-sectional areas of pipe at section 1 and 2,

By continuity equation $Q = a_1 v_1 = a_2 v_2$ (4)

The area of jet a_2 at section 2 (i.e. at vena-contracta) may be related to the area of orifice a_0 by the following expression

$a_2 = C_c a_0$ where C_c is known as co-efficient of contraction, which is defined as the ratio between the area of the jet at vena-contracta and the area of orifice. Thus introducing the value of a_2 in equation (4), we get

$$a_1 v_1 = C_c a_0 \sqrt{2gh + v_1^2} \quad (5)$$

$$\text{Solving for } v_2, \text{ we get } v_2 = \frac{v_1}{\sqrt{1 - C_c^2 \frac{a_0^2}{a_1^2}}}$$

$$\text{Now } Q = a_2 v_2 = C_c a_0 v_2 \text{ and } a_1 v_1 = a_2 v_2$$

$$Q = \frac{C_c a_0 v_1}{\sqrt{1 - C_c^2 \frac{a_0^2}{a_1^2}}} = \frac{C_c a_0 v_1}{\sqrt{1 - C_c^2 \frac{a_0^2}{a_1^2}}}$$

Where C_d is the co-efficient of discharge of the orifice.

Simplifying the above expression for the discharge through the orifice meter by using a co-efficient C expressed as

$$Q = \frac{C_c a_0 v_1}{\sqrt{1 - C_c^2 \frac{a_0^2}{a_1^2}}}$$

$$\text{So that } Q = \frac{C_c a_0 v_1}{\sqrt{1 - C_c^2 \frac{a_0^2}{a_1^2}}} = \frac{C_c a_0 v_1}{\sqrt{1 - C_c^2 \frac{a_0^2}{a_1^2}}}$$

$$Q = C_c a_0 v_1 \frac{1}{\sqrt{1 - C_c^2 \frac{a_0^2}{a_1^2}}}$$

This gives the discharge through an orifice meter and is similar to the discharge through venturimeter. The co-efficient C may be considered as the co-efficient of discharge of an orifice meter. The co-efficient of discharge for an orifice meter is smaller than that for a venturimeter. This is because there are no gradual converging and diverging flow passages as in the case of venturimeter, which results in a greater loss of energy and consequent reduction of the co-efficient of discharge for an orifice meter.

PROBLEMS ON FLOW THROUGH PIPES

1. At a sudden enlargement of a water main from 240mm to 480mm diameter, the hydraulic gradient rises by 10mm. Estimate the rate of flow.

Given: Dia. of smaller pipe $D_1 = 240\text{mm} = 0.24\text{m}$

$$\text{Area } A_1 = \frac{\pi}{4} D_1^2 = \frac{\pi}{4} (0.24)^2$$

Dia. of larger pipe $D_2 = 480\text{mm} = 0.48\text{m}$

$$\text{Area } A_2 = \frac{\pi}{4} D_2^2 = \frac{\pi}{4} (0.48)^2$$

Rise of hydraulic gradient i.e. $\frac{p_1}{\rho g} + \frac{V_1^2}{2g} + Z_1 - \left(\frac{p_2}{\rho g} + \frac{V_2^2}{2g} + Z_2 \right) = 10\text{mm} = \frac{10}{1000} = \frac{1}{100}$

Let the rate of flow = Q

Applying Bernoulli's equation to both sections i.e smaller and larger sections

$$\frac{p_1}{\rho g} + \frac{V_1^2}{2g} + Z_1 = \frac{p_2}{\rho g} + \frac{V_2^2}{2g} + Z_2 + \text{Head loss due to enlargement} \quad (1)$$

But head loss due to enlargement,
$$= \frac{V_1 - V_2}{2g} \quad (2)$$

From continuity equation, we have $A_1 V_1 = A_2 V_2$

$$\frac{\pi}{4} D_1^2 V_1 = \frac{\pi}{4} D_2^2 V_2 \quad \Rightarrow \quad V_1 = \frac{D_2^2}{D_1^2} V_2 = \frac{0.48^2}{0.24^2} V_2 = 4 V_2$$

Substituting this value in equation (2), we get

$$h_e = \frac{4V_2 - V_2}{2g} = \frac{3V_2}{2g} = \frac{9V_2^2}{2g}$$

Now substituting the value of h_e and V_1 in equation (1)

$$\frac{p_1}{\rho g} + \frac{4V_2^2}{2g} + Z_1 = \frac{p_2}{\rho g} + \frac{V_2^2}{2g} + Z_2 + \frac{9V_2^2}{2g}$$

$$\frac{p_1}{\rho g} + \frac{16V_2^2}{2g} + Z_1 - \frac{p_2}{\rho g} - Z_2 = \frac{V_2^2}{2g} + \frac{9V_2^2}{2g}$$

$$\frac{p_1}{\rho g} + Z_1 - \frac{p_2}{\rho g} - Z_2 = \frac{10V_2^2}{2g}$$

But Hydraulic gradient rise = $\frac{p_2}{\rho g} + Z_2 - \frac{p_1}{\rho g} - Z_1 = \frac{1}{100} \text{ m}$

$$\frac{6V_2^2}{2g} = \frac{1}{100} \quad \Rightarrow \quad V_2^2 = \frac{2 \times 9.81}{6 \times 100} = 0.1808 = 0.181 \text{ m}^2/\text{s}^2$$

Discharge $Q = A_2 V_2 = \frac{\pi}{4} D_2^2 V_2$

$$= \frac{\pi}{4} (0.48)^2 \times 0.181 = 0.03275 \text{ m}^3/\text{sec}$$

$$= \underline{32.75\text{Lts/sec}}$$

2. A 150mm dia. pipe reduces in dia. abruptly to 100mm dia. If the pipe carries water at 30lts/sec, calculate the pressure loss across the contraction. Take co-efficient of contraction as 0.6

Given: Dia. of larger pipe $D_1 = 150\text{mm} = 0.15\text{m}$

$$\text{Area of larger pipe } A_1 = \frac{\pi}{4} (0.15)^2 = 0.01767\text{m}^2$$

Dia. of smaller pipe $D_2 = 100\text{mm} = 0.10\text{m}$

$$\text{Area of smaller pipe } A_2 = \frac{\pi}{4} (0.10)^2 = 0.007854\text{m}^2$$

Discharge $Q = 30 \text{ lts/sec} = 0.03\text{m}^3/\text{sec}$

Co-efficient of contraction $C_C = 0.6$

From continuity equation, we have $Q = A_1 V_1 = A_2 V_2$

$$V_1 = \frac{Q}{A_1} = \frac{0.03}{0.01767} = 1.697 \text{ m/sec}$$

$$V_2 = \frac{Q}{A_2} = \frac{0.03}{0.007854} = 3.82 \text{ m/sec}$$

Applying Bernoulli's equation before and after contraction

$$\frac{P_1}{\rho g} + \frac{V_1^2}{2g} + Z_1 = \frac{P_2}{\rho g} + \frac{V_2^2}{2g} + Z_2 + h_c \quad (1)$$

But $Z_1 = Z_2$ and h_c the head loss due to contraction is given by the equation

$$h_c = \frac{V_2^2}{2g} \left(\frac{1}{C_C} - 1 \right)^2 = \frac{3.82^2}{2 \times 9.81} \left(\frac{1}{0.6} - 1 \right)^2 = 0.33$$

Substituting these values in equation (1), we get

$$\frac{P_1}{\rho g} + \frac{1.697^2}{2 \times 9.81} = \frac{P_2}{\rho g} + \frac{3.82^2}{2 \times 9.81} + 0.33$$

$$\frac{P_1}{\rho g} + 0.1467 = \frac{P_2}{\rho g} + 0.7438 + 0.33$$

$$\frac{P_1}{\rho g} - \frac{P_2}{\rho g} = 0.7438 + 0.33 - 0.1467 = 0.9271 \text{ m}$$

$$P_1 - P_2 = \rho g \times 0.9271 = 1000 \times 9.81 \times 0.9271 = 0.909 \times 10^4 \text{ N/m}^2$$

$$= 0.909 \text{ N/cm}^2$$

Pressure loss across contraction = $P_1 - P_2 = 0.909\text{N/cm}^2$

3. Water is flowing through a horizontal pipe of diameter 200mm at a velocity of 3m/sec. A circular solid plate of diameter 150mm is placed in the pipe to obstruct the flow. Find the loss of head due to obstruction in the pipe, if $C_C = 0.62$.

Given: Diameter of pipe $D = 200\text{mm} = 0.2\text{m}$

Velocity $V = 3\text{m/sec}$

$$\text{Area of pipe } A = \frac{\pi}{4} D^2 = \frac{\pi}{4} (0.2)^2 = 0.03141\text{m}^2$$

Diameter of obstruction $d = 150\text{mm} = 0.15\text{m}$

$$\text{Area of obstruction } a = \frac{\pi}{4} (0.15)^2 = 0.01767\text{m}^2$$

$$C_C = 0.62$$

$$\begin{aligned} \text{The head loss due to obstruction} &= \frac{V^2}{2g} \left[\frac{1}{C_C^2} - 1 \right] \\ &= \frac{3 \times 3}{2 \times 9.81} \left[\frac{1}{0.62^2} - 1 \right] \\ &= \frac{9}{19.62} [3.687 - 1] \\ &= \underline{\underline{3.311\text{m}}} \end{aligned}$$

Problems on Pitot tube

1. A pitot tube is placed in the centre of a 300mm pipe line has one end pointing upstream and other perpendicular to it. The mean velocity in the pipe is 0.80 of the central velocity. Find the discharge through the pipe, if the pressure difference between the two orifices is 60mm of water. Co-efficient of Pitot tube $C_V = 0.98$

Given: Diameter of pipe = 300mm = 0.3m

Difference of pressure head $h = 60\text{mm of water} = 0.06\text{m of water}$

Mean velocity $\bar{V} = 0.80 \times \text{central velocity}$

$$\text{Central velocity} = \bar{V} \times \frac{1}{C_V} = 0.98 \times \frac{2 \times 9.81 \times 0.06}{1} = 1.063 \text{ m/sec}$$

$$\text{Mean velocity} = 0.8 \times 1.063 = 0.8504\text{m/sec}$$

$$\text{Discharge } Q = \text{Area of pipe} \times \text{Mean velocity} = A \times \bar{V}$$

$$= \frac{\pi}{4} (0.3)^2 \times 0.8504$$

$$= \underline{\underline{0.06\text{m}^3/\text{sec}}}$$

2. Find the velocity of flow of an oil through a pipe, when the difference of mercury level in a differential U-tube manometer connected to the two tappings of the pitot tube is 100mm. Co-efficient of pitot tube $C = 0.98$ and sp.gr.of oil $= 0.8$.

Given: Difference of mercury level $x = 100\text{mm} = 0.1\text{m}$

Sp.gr. of oil $= 0.8$, $C_V = 0.98$

$$\text{Difference of pressure head} = \frac{x}{S_m} - 1 = \frac{0.1 \times 13.6}{0.8} - 1$$

$$= 1.6 \text{ m of oil}$$

$$\text{Velocity of flow} = C_V \sqrt{2 \times g \times h} = 0.98 \sqrt{2 \times 9.81 \times 1.6} = 5.49\text{m/sec}$$

$$= 5.49\text{m/sec}$$

3. A pitot tube is used to measure the velocity of water in a pipe. The stagnation pressure head is 6m and static pressure head is 5m. Calculate the velocity of flow. Co-efficient of pitot tube is 0.98.

Given: Stagnation pressure head $h_s = 6\text{m}$

Static pressure head $h_t = 5\text{m}$

$$h = h_s - h_t = 6 - 5 = 1\text{m}$$

$$\text{Velocity of flow } V = C_V \sqrt{2 \times g \times h}$$

$$= 0.98 \sqrt{2 \times 9.81 \times 1}$$

$$= 4.34 \text{ m/sec}$$

4. A submarine moves horizontally in a sea and has its axis 15m below the surface of the water. A pitot tube is properly placed just in front of the submarine and along its axis is connected to the two limbs of a U- tube containing mercury. The difference of mercury level is found to be 170mm. Find the speed of the sub-marine. Specific gravity of mercury is 13.6 and sea water is 1.026 with respect to fresh water.

Given: Difference of mercury level $= 170\text{mm} = 0.17\text{m}$

Specific gravity of mercury $S_m = 13.6$,

Specific gravity of sea water $S_o = 1.026$

$$\frac{x}{S_m} = \frac{h}{S_o} - 1 = 0.17 \times \frac{13.6}{1.026} - 1 = 3.0834$$

$$V = \sqrt{2 \times g \times h} = \sqrt{2 \times 9.81 \times 3.0834}$$

$$= 6.393 \text{ m/sec}$$

$$= \frac{6.393 \times 60 \times 60}{1000}$$

$$= 23.01 \text{ km / hr}$$

5. A pitot tube is inserted in a pipe of 300mm diameter. The static pressure in the pipe is 100mm of mercury (Vacuum). The stagnation pressure at the centre of the pipe is recorded by Pitot tube is 0.981N/cm². Calculate the rate of flow of water through the pipe. The mean velocity of flow is 0.85 times the central velocity $C_v = 0.98$

Given: Diameter of pipe $d = 0.3\text{m}$

$$\text{Area of pipe } a = \frac{\pi}{4} (0.3)^2 = 0.07068\text{m}^2$$

$$\text{Static pressure head} = 100\text{mm of mercury} = \frac{100}{1000} \times 13.6 = 1.36\text{m of water}$$

$$\text{Stagnation pressure head} = \frac{0.981 \times 10^4}{1000} \times 9.81 = 9.81$$

□

1000

$h = \text{Stagnation pressure head} -$

$$\text{static pressure head} = 9.81 - 1.36 = 8.45\text{m}$$

$$\text{Velocity at centre} = C_v \sqrt{2gh} = 0.98 \sqrt{2 \times 9.81 \times 8.45}$$

$$= 0.98 \times 13.1 = 12.838\text{m/sec}$$

$$\text{Mean velocity } \bar{C} = 0.85 \times 12.838 = 10.912\text{m/sec}$$

$$\text{Rate of flow of water} = \bar{C} \times \text{Area of pipe}$$

$$= 10.912 \times 0.07068$$


$$= 0.7715\text{m}^3/\text{sec}$$

Unit-IV

Flow in Open Channel

Concept of Uniform Flow

- Uniform flow is referring the steady uniform flow
- Steady flow is characterized by no changes in time.
- Uniform flow is characterized by the water cross section and depth remaining constant over a certain **reach** of the channel.
- For any channel of given roughness, cross section and slope, there exists one and only one water depth, called the **normal depth**, at which the flow will be uniform.
- Uniform equilibrium flow can occur only in a straight channel with a constant channel slope and cross-sectional shape, and a constant discharge.
- The energy grade line S_f , water surface slope S_w and channel bed slope S_0 are all parallel, i.e. $S_f = S_w = S_0$




- For steady uniform channel flow, channel slope, depth and velocity all remain constant along the channel

Establishment of Uniform Flow

- When flow occurs in an open channel, resistance is encountered by the water as it flows downstream
- A uniform flow will be developed if the resistance is balanced by the gravity forces.
- If the water enters into a channel slowly, the velocity and the resistance are small, and the resistance is outbalanced by the gravity forces, resulting in an accelerating flow in the upstream reach.


- The velocity and the resistance will gradually increase until a balance between resistance and gravity forces is reached. At this moment and afterward the flow becomes uniform.

- The upstream reach that is required for the establishment of uniform flow is known as the **transitory zone**.



The Chezy Formula

Consider the following stretch of channel



- By definition there is no acceleration in uniform flow
- By applying the momentum equation to control volume encompassing sections 1 and 2, distance L apart as shown in the figure.

$$P_1 - W \sin \theta - F_f - P_2 = M_2 - M_1 \text{-----} (4.1)$$

Where: P_1 and P_2 are the pressure forces and M_1 and M_2 are the momentum fluxes at section 1 and 2 respectively

W = weight to fluid in the control volume and

F_f = shear force at the boundary

Since the flow is uniform $P_1 = P_2$ and $M_1 = M_2$ also $W = \gamma AL$ and $F_f = \tau_0 PL$

Where τ_0 = average shear stress on the wetted perimeter of length P

γ = unit weight of water

Replacing $\sin \theta$ by S_0 (bottom slope) equation (4.1) become

$$\gamma A L S_0 = \tau_0 P L \Rightarrow \tau_0 = \gamma \frac{A}{P} S_0 = \gamma R S_0 \text{-----} (4.2)$$

Where $R = A/P$ = hydraulic radius, which is a length parameter accounting for the shape of the channel. And it plays a very important role in developing flow equations which are common to all shapes of channels.

Expressing the average shear stress $\tau_0 = k \rho V^2$, where k = a coefficient which depends on the nature of the surface and flow parameters. Equation (4.2) can be written as

$$k \rho V^2 = \gamma R S_0 \Rightarrow V = C \sqrt{R S_0} \text{-----} (4.3)$$

Where $C = \sqrt{\frac{\gamma}{\rho k}}$ = a coefficient which depends on the nature of the surface

Equation (4.3) is known as ***Chezy formula*** and the coefficient C is known as the ***chezy coefficient***.

We remember that for pipe flow, the Darcy –Weisbach equation is

$$h_f = f \frac{L V^2}{D 2 g}$$

Where h_f = head loss due to friction in a pipe of diameter D and length L
 f = Darcy-Weisbach friction factor

For smooth pipes, f is found to be a function of the Reynolds number ($Re = \frac{VD}{\nu}$) only.

For rough turbulent flows, f is a function of the relative roughness (ϵ/D) and types of roughness, which independent of the Reynolds number.

So for the case of Open Channel, we can be considered to be a conduit cut into two. The hydraulics radius would then be appropriate length parameter and prediction of friction factor f . So equation of head loss due to friction is written as

$$h_f = f \frac{L}{4R} \frac{V^2}{2g} \Rightarrow V = \sqrt{\frac{8g}{f}} \cdot \sqrt{R} \cdot \sqrt{h_f/L} \quad \text{----- (4.4)}$$

Note that for uniform flow in an open channel $h_f/L = \text{slope of the energy line} = S_f = S_0$, it may be seen that equation (4.4) is the same as Chezy formula, equation (4.3). with

$$C = \sqrt{8g/f} \quad \text{----- (4.5)}$$

Equation (4.5) be use to develop different charts and empirical formulas that relate C with Re .

$$\left(Re = \frac{4RV}{\nu} \right) \text{ and } \left(\frac{4R}{\epsilon_s} \right)$$

$$\frac{1}{\sqrt{f}} = 1.80 \log \frac{1}{Re - 1.5146} \quad \text{----- (4.6)}$$

And
$$\frac{1}{\sqrt{f}} = 1.14 - 2.0 \log \left(\frac{4R}{\epsilon_s} + \frac{21.25}{Re^{0.9}} \right) \quad \text{----- (4.7)}$$

Equation (4.7) is valid for $5000 \leq Re \leq 10^8$ and $10^{-6} < \epsilon_s/4R < 10^{-2}$

Generally, the open channels that are encountered in the field are very large in size and also in the magnitude of roughness elements. Due to scarcity of reliable experimental or field data on channels covering a wide range of parameters, values of ϵ_s are not available to the same degree of confidence as for pipe materials. However, the following table will give the estimated values of ϵ_s for some common open channel surfaces.

Table 4. values of ϵ_s for some common open channel surfaces

S.No	Surface	Equivalent Roughness (ϵ_s) in mm
1	Glass	3×10^{-4}
2	Very smooth concrete surface	0.15 – 0.30
3	Rough concrete	3.0 - 4.5
4	Earth Channels (straight, uniform)	3.0
5	Rubble masonry	6.0
6	Untreated channel	3.0 -10.0

Example 4.1: A 2.0m wide rectangular channel carries water at 20°C at a depth of 0.5m. The channel is laid on a slope of 0.0004. Find the hydrodynamic nature of the surface if the channel is made of

- Very smooth concrete
- Rough concrete
- Estimate the discharges in the channel in both case using chezy formula with Dancy-Weisbach f.

Solution:

$$B=2.0\text{m}$$

$$R = A/P = (0.5 \times 2)/(2 + 2 \times 0.5) = 0.33\text{m}$$

$$Y=0.5\text{m}$$

$$\tau_o = \gamma R S_o = (9.81 \times 10^3) \times 0.333 \times 0.0004 = 1.308 \text{N/m}^2$$

$$S_o = 0.0004$$

$$v_* = \text{shear velocity} = \sqrt{\tau_o/\rho} = \sqrt{(1.308/10^3)} = 0.03617 \text{m/sec}$$

$$T = 20^\circ\text{C}$$

$$\text{Kinematic viscosity } (\nu) @ 20^\circ\text{C} = 10^{-6} \text{m}^2/\text{s}$$

a). For a smooth concrete surface

from the Equivalent roughness table, $\epsilon_s = 0.25\text{mm} = 0.00025\text{m}$

$$\epsilon_s v_*/\nu = (0.00025 \times 0.03617)/(10^{-6}) = 9.04 > 4 \text{ but less than } 60 \Rightarrow \text{Transition}$$

b) for a rough concrete

From the Equivalent roughness table, $\epsilon_s = 3.5\text{mm} = 0.0035\text{m}$

$$\epsilon_s v_*/\nu = (0.0035 \times 0.03617)/(10^{-6}) = 126.6 > 60 \Rightarrow \text{Rough}$$

c). case (i) = smooth concrete channel

$$\epsilon_s = 0.25\text{mm} \text{ and } \epsilon_s/4R = (0.25)/(4 \times 0.33 \times 10^3) = 1.894 \times 10^{-4}$$

$$\frac{1}{\sqrt{f}} = 1.14 - 2.0 \log \left(\frac{\epsilon_s}{4R} + \frac{21.25}{\text{Re}^{0.9}} \right)$$

Since Re is known we use the moody chart or iterative trial and error methods, we get

$$f = 0.0145$$

$$C = \sqrt{(8g/f)} = \sqrt{(8 \times 9.81/0.0145)} = 73.6$$

$$V = C\sqrt{(RS_0)} = 73.6 \times \sqrt{(0.333 \times 0.0004)} = 0.850 \text{ m/s}$$

$$Q = AV = (2 \times 0.5) \times 0.850 = \underline{0.85 \text{ m}^3/\text{se}}$$

Case (ii) Rough concrete Channel

$$\epsilon_s = 3.5 \text{ mm and } \epsilon_s/4R = (3.5)/(4 \times 0.33 \times 10^3) = 2.625 \times 10^{-3}$$

$$f = 0.025$$

$$C = \sqrt{(8g/f)} = \sqrt{(8 \times 9.81/0.025)} = 56.0$$

$$V = C\sqrt{(RS_0)} = 56 \times \sqrt{(0.333 \times 0.0004)} = 0.647 \text{ m/s}$$

$$Q = AV = (2 \times 0.5) \times 0.647 = \underline{0.647 \text{ m}^3/\text{se}}$$

The MANNING'S Formula

The simplest resistance formula and the most widely used equation for the mean velocity calculation is the **Manning equation** which has been derived by Robert Manning (1890) by analyzing the experimental data obtained from his own experiments and from those of others. His equation is,

$$V = \frac{1}{n} R^{2/3} S_o^{1/2} \text{ ----- (4.8)}$$

Where V = mean velocity

R = Hydraulic Radius

So = channel slope

n = Manning's roughness coefficient

if we equating Equations. (4.3) and (4.8), we get

$$CR^{1/2} S_o^{1/2} = \frac{1}{n} R^{2/3} S_o^{1/2}$$

$$C = \frac{R^{1/6}}{n} \text{(4.9)}$$

Similarly we can be equating equations (4.5) and (4.9) we get

$$\sqrt{\frac{8g}{f}} = \frac{R^{1/6}}{n} \Rightarrow f = \left(\frac{n^2}{R^{1/3}} \right) (8g) \text{ ----- (4.10)}$$

From equation (4.10) we see $f \propto \left(\frac{n^2}{R^{1/3}} \right)$, it follows that $n \propto \varepsilon_s^{1/6}$. If so the both

Manning's formula and Darcy – Weisbach formula represent rough turbulent flow at $\frac{\varepsilon v_*'}{v} > 60$

OTHERS RESISTANCE FORMULAE

Several forms for the chezy coefficient C have been proposed by different investigators in the past. Some of them are in use for problems in open channel flow.

1. Pavlovsk formula: $C = \frac{R^x}{n}$ in which $x = 2.5 \sqrt{n} - 0.13 - 0.75 \sqrt{R} (\sqrt{n} - 0.10)$ and

n= manning's coefficient. This formula appears to be in use in Russia

2. Bazin's formula $C = \frac{87.0}{1 + M/R}$, in which M = a coefficient dependent on the surface roughness

3. Ganguillet and Kutter Formula $C = \frac{23 + \frac{1}{n} + \frac{0.00155}{S_o}}{1 + \left[23 + \frac{0.00155}{S_o} \right] \frac{n}{\sqrt{R}}}$, in which n= manning's

coefficient

MANNING'S Roughness Coefficient (n)

In applying the Manning equation, the greatest difficulty lies in the determination of the roughness coefficient, n; there is no exact method of selecting the n value. Selecting a value of n actually means to estimate the resistance to flow in a given channel, which is really a matter of intangibles.(Chow, 1959) .To experienced engineers, this means the exercise of engineering judgment and experience; for a new engineer, it can be no more than a guess and different individuals will obtain different results.

Factors Affecting Manning's Roughness Coefficient

It is not uncommon for engineers to think of a channel as having a single value of n for all occasions. Actually, the value of n is highly variable and depends on a number of factors. The factors that exert the greatest influence upon the roughness coefficient in both artificial and natural channels are described below.

a) Surface Roughness: The surface roughness is represented by the size and shape of the grains of the material forming the wetted perimeter. This usually considered the only factor

in selecting the roughness coefficient, but it is usually just one of the several factors. Generally, fine grains result in a relatively low value of n and coarse grains in a high value of n .

- b) **Vegetation:** Vegetation may be regarded as a kind of surface roughness, but it also reduces the capacity of the channel. This effect depends mainly on height, density, and type of vegetation.
- c) **Channel Irregularity:** Channel irregularity comprises irregularities in wetted perimeter and variations in cross-section, size, and shape along the channel length.
- d) **Channel Alignment:** Smooth curvature with large radius will give a relatively low value of n , whereas sharp curvature with severe meandering will increase n .
- e) **Silting and Scouring:** Generally speaking, silting may change a very irregular channel into a comparatively uniform one and decrease n , whereas scouring may do the reverse and increase n .
- f) **Obstruction:** The presence of logjams, bridge piers, and the like tends to increase n .
- g) **Size and Shape of the Channel:** There is no definite evidence about the size and shape of the channel as an important factor affecting the value of n .
- h) **Stage and Discharge:** The n value in most streams decreases with increase in stage and discharge.
- i) **Seasonal Change:** Owing to the seasonal growth of aquatic plants, the value of n may change from one season to another season.

Determination of Manning's Roughness Coefficient

a. Cowan Method

Taking into account primary factors affecting the roughness coefficient, Cowan (1956) developed a method for estimating the value of n . The value of n may be computed by,

$$n = (n_0 + n_1 + n_2 + n_3 + n_4) \times m \text{----- (4.11)}$$

Where: n_0 is a basic value for straight, uniform, smooth channel in the natural materials involved,

n_1 is a value added to n_0 to correct for the effect of surface irregularities,

n_2 is a value for variations in shape and size of the channel cross-section,

n_3 is a value of obstructions,

n_4 is a value for vegetation and flow conditions, and

m is a correction factor for meandering of channel.

These coefficients are given in Table (4.2) depending on the channel characteristics. (French,1994).
Table 4.2: Values of the manning's coefficients of Cowan Method

Channel conditions		Values	
Material involved	Earth	n_0	0.020
	Rock cut		0.025
	Fine gravel		0.024
	Coarse gravel		0.028
Degree of irregularity	Smooth	n_1	0.000
	Minor		0.005
	Moderate		0.010
	Severe		0.020
Variations of channel cross section	Gradual	n_2	0.000
	Alternating occasionally		0.005
	Alternating frequently		0.010-0.015
Relative effect of obstructions	Negligible	n_3	0.000
	Minor		0.010-0.015
	Appreciable		0.020-0.030
	Severe		0.040-0.060
Vegetation	Low	n_4	0.005-0.010
	Medium		0.010-0.025
	High		0.025-0.050
	Very high		0.050-0.100
	Minor		1.000

b. Empirical Formulae for n

Many empirical formulae have been presented for estimating manning's coefficient n in natural streams. These relate n to the bed-particle size. (Subramanya, 1997). The most popular one under this type is the Strickler formula,

$$n = \frac{d_{50}^{1/6}}{21.1} \dots\dots\dots (4.12)$$


Where d_{50} is in meters and represents the particle size in which 50 per cent of the bed material is finer. For mixtures of bed materials with considerable coarse-grained sizes,

$$n = \frac{d_{90}^{1/6}}{26} \dots\dots\dots (4.13)$$

Where d_{90} = size in meters in which 90 per cent of the particles are finer than d_{90} . This equation is reported to be useful in predicting n in mountain streams paved with coarse gravel and cobbles.

c. Equivalent Roughness

In some channels different parts of the channel perimeter may have different roughnesses. Canals in which only the sides are lined, laboratory flumes with glass walls and rough beds, rivers with sand bed in deepwater portion and flood plains covered with vegetation, are some typical examples. For such channels it is necessary to determine an equivalent roughness coefficient that can be applied to the entire cross-sectional perimeter in using the Manning's formula. This **equivalent roughness**, also called the **composite roughness**, represents a weighted average value for the roughness coefficient, n .



A large number of formulae, proposed by various investigators for calculating equivalent roughness of multi-roughness channel are available in literature. All of them are based on some assumptions and approximately effective to the same degree. We see the derivation of one of the common formula called Horton's Method and present others as table below.

Horton's method of Equivalent Roughness Estimation:

Consider a channel having its perimeter composed of N types rough nesses. $P_1, P_2, \dots, P_N$ are the lengths of these N parts and $n_1, n_2, \dots, n_N$ are the respective roughness coefficients as presented in the above figure.

Let each part P_i be associated with a partial area A_i such that,

$$\sum_{i=1}^N A_i = A_1 + A_2 + \dots + A_i + \dots + A_N = A = \text{Total area}$$

It is assumed that the mean velocity in each partial area is the mean velocity V for the entire area of flow,

$$V_1 = V_2 = \dots = V_i = \dots = V_N = V$$

By the Manning's equation,

$$S_0^{1/2} = \frac{V_1 n_1}{R_1^{2/3}} = \frac{V_2 n_2}{R_2^{2/3}} = \dots = \frac{V_i n_i}{R_i^{2/3}} = \dots = \frac{V_N n_N}{R_N^{2/3}} = \frac{V n}{R^{2/3}} \dots (4.14)$$

Where n = Equivalent roughness.

From Equ. (4.14),

$$\begin{aligned} \left(\frac{A_i}{A} \right)^{2/3} &= \frac{n_i P_i^{2/3}}{n P^{2/3}} \\ A_i &= A \frac{n_i^{3/2} P_i}{n^{3/2} P} \\ \sum A_i &= A = A \frac{\sum (n_i^{3/2} P_i)}{n^{3/2} P} \\ n &= \frac{(\sum n_i^{3/2} P_i)^{2/3}}{P^{2/3}} \dots (4.15) \end{aligned}$$

This equation gives a means of estimating the equivalent roughness of a channel having multiple roughness types in its perimeters

Table 4.3. Equations for equivalent Roughness Coefficient (adopt from K. Subramanya 2010)

No	Investigators	n_e	Concept
1	Horton (1933); Einstein (1934)	$= \left[\frac{1}{P} \sum (n_i^{3/2} P_i) \right]^{2/3}$	Mean Velocity is constant in all subareas
2	Pavloskii (1931), Muhlhofer(1933) Einstein and Banks (1950)	$= \left[\frac{1}{P} \sum (n_i^2 P_i) \right]^{1/2}$	Total resistance force F is sum of subarea resistance force, $\sum F_i$
3	Lotter (1932)	$= \frac{P R^{5/3}}{\sum \frac{P_i^{5/3}}{n_i}}$	Total discharge is sum of subarea discharge

4	Yen (1991)	$= \sum_P (n_i P_i)$	Total shear velocity is weighted sum of subarea shear velocity
---	------------	----------------------	--

Table 4.4: values of Manning's Roughness coefficient (adopt from ERA design manuals 2001)

Type of Channel and Description	Minimum	Normal	Maximum
EXCAVATED OR DREDGED			
a. Earth, straight and uniform			
1. Clean, recently completed	0.016	0.018	0.020
2. Clean, after weathering	0.018	0.022	0.025
3. Gravel, uniform section, clean	0.022	0.025	0.030
4. With short grass, few weeds	0.022	0.027	0.033
b. Earth, winding and sluggish			
1. No vegetation	0.023	0.025	0.030
2. Grass, some weeds	0.025	0.030	0.033
3. Dense Weeds or aquatic plants in deep channels	0.030	0.035	0.040
4. Earth bottom and rubble sides	0.025	0.030	0.035
5. Stony bottom and weedy sides	0.025	0.035	0.045
6. Cobble bottom and clean sides	0.030	0.040	0.050
c. Backhoe-excavated or dredged			
1. No vegetation	0.025	0.028	0.033
2. Light brush on banks	0.035	0.050	0.060
d. Rock cuts			
1. Smooth and uniform	0.025	0.035	0.040
2. Jagged and irregular	0.035	0.040	0.050
e. Channels not maintained, weeds and brush uncut			
1. Dense weeds, high as flow depth	0.050	0.080	0.120
2. Clean bottom, brush on sides	0.040	0.050	0.080
3. Same, highest stage of flow	0.045	0.070	0.110
4. Dense brush, high stage	0.080	0.100	0.140
NATURAL STREAMS			
1 Minor streams (top width at flood stage < 30 m)			
a. Streams on Plain			
1. Clean, straight, full stage, no rims or deep pools	0.025	0.030	0.033
2. Same as above, but more stones and weeds	0.030	0.035	0.040
3. Clean, winding, some pools and shoals	0.033	0.040	0.045
4. Same as above, but some weeds and stones	0.035	0.045	0.050
5. Same as above, lower stages, more ineffective slopes and sections	0.040	0.048	0.055
6. Same as 4, but more stones	0.045	0.050	0.060
7. Sluggish reaches, weedy, deep pools	0.050	0.070	0.080
8. Very weedy reaches, deep pools, or floodways with heavy stand of timber and underbrush	0.075	0.100	0.150
b. Mountain streams, no vegetation in channel, banks usually steep, trees and brush along banks submerged at high stages			
1. Bottom: gravel, cobbles, and few boulders	0.030	0.040	0.050
2. Bottom: cobbles with large boulders	0.040	0.050	0.070
2 Flood Plains			0
a. Pasture, no brush			
1. Short grass	0.025	0.030	0.035
2. High grass	0.030	0.035	0.050

Type of Channel and Description	Minimum	Normal	Maximum
b. Cultivated area			
1. No crop	0.020	0.030	0.040
2. Mature row crops	0.025	0.035	0.045
3. Mature field crops	0.030	0.040	0.050
c. Brush			
1. Scattered brush, heavy weeds	0.035	0.050	0.070
2. Light brush and trees in winter	0.035	0.050	0.060
3. Light brush and trees, in summer	0.040	0.060	0.080
4. Medium to dense brush, in winter	0.045	0.070	0.110
5. Medium to dense brush, in summer	0.070	0.100	0.160
d. Trees			
1. Dense willows, summer, straight	0.110	0.150	0.200
2. Cleared land with tree stumps, no sprouts	0.030	0.040	0.050
3. Same as above, but with heavy growth of sprouts			
4. Heavy stand of timber, a few down trees, little undergrowth, flood stage below branches	0.050	0.060	0.080
5. Same as above, but with flood stage reaching branches	0.080	0.100	0.120
3 Major Streams (top width at flood stage > 30 m). The n value is less than that for minor streams of similar description, because banks offer less effective resistance.	0.100	0.120	0.160
a. Regular section with no boulders or brush			
b. Irregular and rough section			
4 Various Open Channel Surfaces	0.025	--	0.060
a. Concrete	0.035	--	0.100
b. Gravel bottom with:			
Concrete	0.012-	0.020	
Mortared stone			
Riprap	0.020		
c. Natural Stream Channels			
Clean, straight stream	0.023		
Clean, winding stream	0.033		
Winding with weeds and pools			
With heavy brush and timber	0.030		
d. Flood Plains	0.040		
Pasture	0.050		
Field Crops	0.100		
Light Brush and Weeds			
Dense Brush	0.035		
Dense Trees	0.040		
	0.050		
	0.070		
	0.100		

Example 4.2: An earthen trapezoidal channel ($n = 0.025$) has a bottom width of 5.0 m, side slopes of 1.5 horizontal: 1 vertical and a uniform flow depth of 1.10 m. In an economic study to remedy excessive seepage from the canal two proposals, a) to line the sides only and, b) to line the bed only are considered. If the lining is of smooth concrete ($n = 0.012$), calculate the equivalent roughness in the above two cases.

Solution :

Earthen (n) = 0.025

B = 5.0m


m = 1.5

y = 1.10m

a). line the sides only

b). line the bed only

lining (n) = 0.012



Case a): Lining on the sides only,

For the bed $\rightarrow n_1 = 0.025$ and $P_1 = 5.0$ m.

For the sides $\rightarrow n_2 = 0.012$ and $P_2 = 2 \times 1.10 \times \sqrt{1 + 1.5^2} = 3.97$ m

$$P = P_1 + P_2 = 5.0 + 3.97 = 8.97 \text{ m}$$

$$n = \frac{\left(\sum n_i^{3/2} P_i \right)^{2/3}}{P^{2/3}} \quad n = \frac{\left[5.0 \times 0.025^{1.5} + 3.97 \times 0.012^{1.5} \right]^{2/3}}{8.97^{2/3}} = 0.020$$

Case b): Lining on the bottom only

$$P_1 = 5.0 \text{ m} \rightarrow n_1 = 0.012$$

$$P_2 = 3.97 \text{ m} \rightarrow n_2 = 0.025 \rightarrow P = 8.97 \text{ m}$$

$$n = \frac{\left(5.0 \times 0.012^{1.5} + 3.97 \times 0.025^{1.5} \right)^{2/3}}{8.97^{2/3}} = 0.018$$

UNIFORM FLOW COMPUTATION

The basic equations involved in the computation of uniform flow are the manning's and the continuity equation. From continuity equation $Q = AV$, if we substitute the velocity from the manning's formula we get the equation for discharge as

$$Q = \frac{1}{n} A R^{2/3} S_o^{1/2} \text{ ----- (4.16)}$$

$$Q = K \sqrt{S_o} \text{ ----- (4.17)}$$

Where $K = \frac{1}{n} A R^{2/3}$ is called the conveyance of the channel and express the discharge capacity of the channel per unit longitudinal slope. The term $nK = A R^{2/3}$ is also called the section factor for uniform flow computations.

The basic variables in uniform flow problems can be the discharge Q , velocity of flow V , normal depth y_0 , roughness coefficient n , channel slope S_0 and the geometric elements (e.g. B and side slope m for a trapezoidal channel). There can be many other derived variables accompanied by corresponding relationships. From among the above, the following five types of basic problems are recognized.

Table 4.5 Problem Types and the given and required variables in uniform flow

Problem Type	Given	Required
1	y_0, n, S_0 , Geometric elements	Q and V
2	Q, y_0, n , Geometric elements	S_0
3	Q, y_0, S_0 , Geometric elements	n
4	Q, n, S_0 , Geometric elements	y_0
5	Q, y_0, n, S_0 , Geometry	Geometric elements

Hydraulic Radius

Hydraulic radius plays a prominent role in the equations of open-channel flow and therefore, the variation of hydraulic radius with depth and width of the channel becomes an important consideration. This is mainly a problem of section geometry.




Figure on the relation of Hydraulic Radius with depth and width

Consider first the variation of hydraulic radius with depth in a rectangular channel of width B

$$A = By, P = B + 2y$$

$$R = \frac{A}{P} = \frac{By}{B + 2y}$$

$$R = \frac{B}{\frac{B}{y} + 2}$$

$$y = 0 \rightarrow R = 0$$

For $y \rightarrow \infty, R = \frac{B}{2}$

Therefore the variation of R with y is as shown in Fig (a) above. From this comes a useful engineering approximation:

for narrow deep cross-sections $R \approx B/2$.

Since any (nonrectangular) section when deep and narrow approaches a rectangle, when a channel is deep and narrow, the hydraulic radius may be taken to be half of mean width for practical applications.

Consider the variation of hydraulic radius with width in a rectangular channel of with a constant water depth y

$$R = \frac{By}{B + 2y}$$


$$R = \frac{y}{1 + \frac{2}{yB}}$$

$$B = 0 \rightarrow R = 0$$

$$B \rightarrow \infty, R \rightarrow y$$

From this it may be concluded that for **wide shallow rectangular cross-sections $R \approx y$** ; for rectangular sections the approximation is also valid if the section is wide and shallow, here the hydraulic radius approaches the mean depth.

Normal Depth



Area $A = By_o$

Wetted Perimeter $P = B + 2y_o$

Hydraulic Radius $R = A/P$

$$R = \frac{y_o}{1 + 2 \frac{y_o}{B}} \quad \text{----- (4.18)}$$

a). wide Rectangular Channel

As y_o/B , the aspect ratio of the channel decrease, $R \rightarrow y_o$. Such channels with large bed-widths as compared to their respective depths are known as **wide rectangular channels**. In these channels, the hydraulics radius approximates to the depth of flow.

Considering a unit width of a wide rectangular channel, $A = y_o$, $R = y_o$ and $B = 1.0$

$$\text{Discharge per unit width } Q/B = q = \frac{1}{n} y_o^{5/3} S_o^{1/2} \Rightarrow y_o = \left[\frac{qn}{\sqrt{S_o}} \right]^{3/5} \quad \text{----- (4.19)}$$

This approximation of a wide rectangular channel is found applicable to rectangular channels $y_o/B < 0.02$.

b). Rectangular Channels with $y_o/B \geq 0.02$

$$\text{For these channels } \frac{Qn}{\sqrt{S_o}} = AR^{2/3}, \text{ and } AR^{2/3} = \frac{(By_o)^{5/3}}{(B + 2y_o)^{2/3}} B^{8/3} \frac{(y_o/B)^{5/3}}{(1 + 2y_o/B)^{2/3}}$$


$$\frac{Qn}{\sqrt{S_o} B^{8/3}} = \frac{AR^{2/3}}{B^{8/3}} = \frac{(\eta_o)^{5/3}}{(1 + 2\eta_o)^{2/3}} = \phi(\eta_o) \quad \text{----- (4.20)}$$

Where $\eta_o = \frac{y_o}{B}$, Tables of $\phi(\eta_o)$ Vs η_o will provide a non-dimensional graphical aid for general

application. Since $\phi = \frac{Qn}{\sqrt{S_o} B^{8/3}}$, one can easily find y_o/B from this table for any combination of Q , n , S_o , and B in a rectangular channel.

Trapezoidal Channel

Following a procedure similar to the above, for a trapezoidal section of side slope m:1.



$$\text{Area} = A = (B + my_o)y_o$$

$$\text{Wetted Perimeter} = P = (B + 2y_o\sqrt{m^2 + 1})$$

$$\text{Hydraulic Radius} = \frac{A}{P} = \frac{(B + my_o)y_o}{(B + 2\sqrt{m^2 + 1}y_o)}$$

$$\frac{Qn}{\sqrt{S_o}} = \frac{AR^{2/3}}{\sqrt{S_o}} = \frac{(B + my_o)^{5/3} y_o^{5/3}}{(B + 2\sqrt{m^2 + 1}y_o)^{2/3}}$$


$$\frac{AR^{2/3}}{B^{8/3}} = \frac{Qn}{\sqrt{S_o} B^{8/3}} = \frac{(1 + m\eta_o)^{5/3} \eta_o^{5/3}}{(1 + 2\sqrt{m^2 + 1}\eta_o)^{2/3}} \phi(\eta_o, m) \quad (4.21)$$

Where $\eta_o = y_o/B$.

Equation (4.21) represent as curves or tables of ϕ vs η_o with m as the third parameter to provide a general normal depth solution aid. It may be noted $m=0$ is the case of rectangular.

Lined canal Section

Most lined channels and built-up channels can withstand erosion and reduce seepage. Exposed hard surface lining using materials, such as cement concrete, brick tiles, asphaltic concrete and stone masonry are the members of lined canal category and also carry large canal. Indian Standards (IS: 4745 -1968) consists of two standardized lined canal section (i.e., Trapezoidal and triangular with corners rounded off for discharge $> 55\text{m}^3/\text{sec}$ and $< 55\text{m}^3/\text{sec}$). Actually the triangular section is the limiting case of the standard lined trapezoidal section with bottom width (B) = 0.



Referring the above figure the full supply depth = normal depth at design discharge = y_o at normal depth

For standard trapezoidal case

$$\text{Area} = A = B y_o + m y_o^2 + y_o^2 \theta = (B + y_o \varepsilon) y_o \quad \text{where } \varepsilon = m + \theta = \left(m + \tan^{-1} \frac{1}{m} \right)$$

$$\text{Wetted perimeter} = P = B + 2m y_o + 2y_o \theta = B + 2y_o \varepsilon$$

$$\text{Hydraulics radius} = R = A/P = \frac{(B + y_o \varepsilon) y_o}{B + 2y_o \varepsilon}$$

By manning's formula

$$Q = \frac{1}{n} \left[\frac{(B + y_o \varepsilon)^{5/3} y_o^{5/3}}{(B + 2y_o \varepsilon)^{2/3}} \right] S_o^{1/2} \quad (4.22)$$

Non-dimensionalising the variables,

$$\frac{Q n \varepsilon^{5/3}}{S_o^{1/2} B^{8/3}} = \phi(\eta_o) = \frac{(1 + \eta_o)^{5/3} \eta_o^{5/3}}{(1 + 2\eta_o)^{2/3}} \quad (4.23)$$

For standard triangular case similarly we can drive

$$Q = \frac{1}{n} (\varepsilon y_o^2) (y_o/2)^{2/3} S_o^{1/2} \quad (4.24)$$

Example 4.3 A standard lined trapezoidal canal section is to be designed to convey 100m³/sec of flow. The side slope is to be 1.5H:1V and the manning's coefficient $n = 0.016$. The longitudinal slope of the bed is 1 in 5000m. If a bed width of 10m is preferred what would be the normal depth?

Solution	$\varepsilon = m + \tan^{-1}(1/m) = 1.5 + \tan^{-1}(1/1.5)$	Then $\eta_o = \frac{y_o \varepsilon}{B}$, which imply that
$Q = 100 \text{m}^3/\text{sec}$	$= 2.088$	
$m = 1.5$	$\phi = \frac{Q n \varepsilon^{5/3}}{S_o^{1/2} B^{8/3}} = \frac{100 \times 0.016 \times (2.088)^{5/3}}{(0.0002)^{1/2} (10.0)^{8/3}} = 0.8314$	$y_o = \frac{\eta_o B}{\varepsilon} = \frac{0.74 \times 10.0}{2.088}$
$n = 0.016$		$y_o = 3.554$
$S_o = 0.0002$	$\phi = \frac{(1 + \eta_o)^{5/3} \eta_o^{5/3}}{(1 + 2\eta_o)^{2/3}} = 0.8314$	
$B = 10 \text{m}$		
$y_o = ?$	By solving trial and error	
	$\eta_o = 0.74$	

The Hydraulic Efficient Channel Section

The *best hydraulic (the most efficient)* cross-section for a given Q , n , and S_0 is the one with a minimum excavation and minimum lining cross-section. $A = A_{\min}$ and $P = P_{\min}$. The minimum cross-sectional area and the minimum lining area will reduce construction expenses and therefore that cross-section is **economically the most efficient** one. In other case the best hydraulic cross-section for a given A , n , and S_0 is the cross-section that conveys **maximum discharge**. Thus the cross-section with the **minimum wetted perimeter** is the best hydraulic cross-section within the cross-sections with the same area since lining and maintenance expenses will reduce substantially.

$$V = \frac{Q}{A} \rightarrow \frac{Q}{A_{\min}} = V_{\max}$$

$$V = \frac{1}{n} S_0^{1/2} R^{2/3} = C \times R^{2/3}$$

$$V = V_{\max} \rightarrow R = R_{\max}$$

$$R = \frac{A}{P}$$

$$R = R_{\max} \rightarrow P = P_{\min}$$

$$Q = A \frac{1}{n} R^{2/3} S_0^{1/2}$$

$$Q = C' \times R^{2/3}$$


$$C' = \text{const}$$

$$Q = Q_{\max} \rightarrow R = R_{\max}$$

$$R = \frac{A}{P}$$

$$R = R_{\max} \rightarrow P = P_{\min}$$

Rectangular channel section



$$A = By = \text{Constant}$$

$$B = \frac{A}{y}$$

$$P = B + 2y = \frac{A}{y} + 2y$$

Since $P = P_{\min}$ for the best hydraulic section, taking the derivative of P with respect to y

$$\frac{dP}{dy} = \frac{\frac{dA}{dy} \times y - A}{y^2} + 2 = 0$$

$$\frac{A}{y^2} = 2 \rightarrow A = 2y^2 = By$$


$$B = 2y$$

The best rectangular hydraulic cross-section for a constant area is the one with $B = 2y$. The hydraulic radius of this cross-section is,

$$R = \frac{A}{P} = \frac{2y^2}{4y} = \frac{y}{2}$$

For all best hydraulic cross-sections, the hydraulic radius should always be $R = y/2$ regardless of their shapes.

Trapezoidal Channel Section



$$A = \frac{B + B + 2my}{y} \times y = (B + my)y$$

$$P = B + 2y\sqrt{1 + m^2}$$

$$B = \frac{A}{y} - my$$

$$P = \frac{A}{y} - my + 2y\sqrt{1 + m^2}$$

a). For a given side slope m , what will be the water depth y for best hydraulic trapezoidal cross-section?

For a given A , $P = P_{\min}$

$$\frac{dP}{dy} = 0, \frac{dA}{dy} = 0$$

The hydraulic radius R , channel bottom width B , and free surface width L may be found as,

$$\frac{dP}{dy} = \frac{\frac{dA}{dy}y - A}{y^2} - m + 2\sqrt{1 + m^2} = 0$$

$$\frac{A}{y^2} = -m + 2\sqrt{1 + m^2}$$

$$A = (2\sqrt{1 + m^2} - m)y^2$$

$$P = (2\sqrt{1 + m^2} - m)y - my + 2y\sqrt{1 + m^2}$$

$$P = 2y\sqrt{1 + m^2} - my - my + 2y\sqrt{1 + m^2}$$

$$P = 2y(2\sqrt{1 + m^2} - m)$$

$$R = \frac{A}{P} = \frac{(2\sqrt{1 + m^2} - m)y^2}{2y(2\sqrt{1 + m^2} - m)}$$

$$R = \frac{y}{2}$$

$$B = \frac{A}{y} - my = (2\sqrt{1 + m^2} - m)y - my$$

$$B = 2y(\sqrt{1 + m^2} - m)$$

$$L = B + 2my$$

$$L = 2y(\sqrt{1 + m^2} - m) + 2my$$

$$L = 2y\sqrt{1 + m^2}$$

b). For a given water depth y , what will be the side slope m for best hydraulic trapezoidal cross- section?

$$\begin{aligned}
 P &= P_{\min} \\
 \frac{dP}{dm} &= 0, \frac{dA}{dm} = 0 \\
 P &= \frac{A}{y} - my + 2y\sqrt{1+m^2} \\
 \frac{dP}{dm} &= \frac{\frac{dA}{dm}y - 0}{y^2} - y + 2y \frac{2m}{2\sqrt{1+m^2}} = 0 \\
 y &= \frac{2my}{\sqrt{1+m^2}} \rightarrow \frac{2m}{\sqrt{1+m^2}} = 1 \\
 4m^2 &= 1+m^2 \rightarrow 3m^2 = 1 \\
 m &= \frac{1}{\sqrt{3}} \\
 \tan \alpha &= \frac{1}{m} = \sqrt{3} \rightarrow \alpha = 60^\circ
 \end{aligned}$$

(4.44)

$$\begin{aligned}
 A &= \left(2\sqrt{1+m^2} - m\right)y^2 \\
 A &= \left(2\sqrt{1+\frac{1}{3}} - \frac{1}{\sqrt{3}}\right)y^2 \\
 A &= \left(\frac{2\sqrt{4}-1}{\sqrt{3}}\right)y^2 = \frac{3}{\sqrt{3}}y^2
 \end{aligned}$$

$$A = \sqrt{3}y^2$$

$$\begin{aligned}
 P &= 2y\left(2\sqrt{1+m^2} - m\right) \\
 P &= 2y\left(2\sqrt{1+\frac{1}{3}} - \frac{1}{\sqrt{3}}\right) \\
 P &= 2y\left(\frac{4-1}{\sqrt{3}}\right) = \frac{6y}{\sqrt{3}}
 \end{aligned}$$

$$P = 2y\sqrt{3}$$

$$B = \frac{A}{y} - my = \frac{\sqrt{3}y^2}{y} - \frac{1}{\sqrt{3}}y = \frac{3-1}{\sqrt{3}}y$$

$$B = \frac{2\sqrt{3}}{3}y = \frac{P}{3}$$

$$R = \frac{A}{P} = \frac{\sqrt{3}y^2}{2y\sqrt{3}} = \frac{y}{2}$$

The channel bottom width is equal one third of the wetted perimeter and therefore sides and channel width B are equal to each other at the best trapezoidal hydraulic cross-section. Since $\alpha = 60^\circ$, the cross-section is half of the hexagon.


Table 4.6 values of parameters in Efficient (best) hydraulic section

Channel Shape	A	P	B	R	L
Rectangle (half square)	$2y^2$	$4y$	$2y$	$\frac{y}{2}$	$2y$
Trapezoidal (half regular hexagon)	$\sqrt{3}y^2$	$2\sqrt{3}y$	$\frac{2}{\sqrt{3}}y$	$\frac{y}{2}$	$\frac{4}{\sqrt{3}}y$
Circular (semicircle)	$\frac{\pi}{2}y^2$	πy	-	$\frac{y}{2}$	$2y$
Triangle (vertex angle = 90°)	y^2	$2\sqrt{3}y$	-	$\frac{y}{2\sqrt{2}}$	$2y$

(A = Area, P = Wetted perimeter, B = Base width, R = Hydraulic radius, L = Water surface width)

Compound Sections

Some channel sections may be formed as a combination of elementary sections. Typically natural channels, such as rivers, have flood plains which are wide and shallow compared to the main channel. The figure below represents a simplified section of a stream with flood banks. Consider the compound section to be divided into subsections by arbitrary lines. These can be extensions of the deep channel boundaries as in figure. Assuming the longitudinal slope to be same for all subsections, it is easy to see that the subsections will have different mean velocities depending upon the depth and roughness of the boundaries. Generally, overbanks have larger size roughness than the deeper main channel. If the mean velocities V_i in the various subsections are known then the total discharge is $\sum V_i A_i$.



If the depth of flow is confined to the deep channel only ($y < h$), calculation of discharge by using Manning's equation is very simple. However, when the flow spills over the flood plain ($y > h$), the problem of discharge calculation is complicated as the calculation may give a smaller hydraulic radius for the whole stream section and hence the discharge may be underestimated. The following method of discharge estimation can be used. In this method, while calculating the wetted perimeter for the sub-areas, the imaginary divisions (FJ and CK in the Figure) are considered as boundaries for the deeper portion only and neglected completely in the calculation relating to the shallower portion.

1. The discharge is calculated as the sum of the partial discharges in the sub-areas; for e.g. units 1, 2 and 3 in Figure

$$Q_p = \sum Q_i = \sum V_i A_i$$

2. The discharge is also calculated by considering the whole section as one unit, (ABCDEFGH area in Figure), say Q_w .
3. The larger of the above discharges, Q_p and Q_w , is adopted as the discharge at the depth y .

Design of Irrigation Channels

For a uniform flow in a canal,

$$Q = \frac{1}{n} AR^{2/3} S_0^{0.5}$$

Where A and R are in general, functions of the geometric elements of the canal. If the canal is of trapezoidal cross-section,

$$Q = f(n, y_0, S_0, B, m) \quad \text{..... (4.25)}$$

Equ. (4.25) has six variables out of which one is a dependent variable and the rest five are independent ones. Similarly, for other channel shapes, the number of variables depends upon the channel geometry. In a channel design problem, the independent variables are known either explicitly or implicitly, or as inequalities, mostly in terms of empirical relationships. The canal-design practice given below is meant only for rigid-boundary channels, i.e. for lined and unlined non-erodible channels.

Canal Section

Normally a trapezoidal section is adopted. Rectangular cross-sections are also used in special situations, such as in rock cuts; steep chutes and in cross-drainage works. The side slope, expressed as m horizontal: 1 vertical, depends on the type of canal, (i.e. lined or unlined, nature and type of soil through which the canal is laid). The slopes are designed to withstand seepage forces under critical conditions, such as;

1. A canal running full with banks saturated due to rainfall,
2. The sudden drawdown of canal supply.

Usually the slopes are steeper in cutting than in filling. For lined canals, the slopes roughly correspond to the angle of repose of the natural soil and the values of m range from 1.0 to 1.5 and rarely up to 2.0. The slopes recommended for unlined canals in cutting are given in Table(4.7).

Table 4.7: Side slopes for unlined canals in cutting

Type of soil	m
Very light loose sand to average sandy soil	1.5 – 2.0
Sandy loam, black cotton soil	1.0 – 1.5
Sandy to gravel soil	1.0 – 2.0
Murom, hard soil	0.75 – 1.5
Rock	0.25 – 0.5

Longitudinal Slope

The longitudinal slope is fixed on the basis of topography to command as much area as possible with the limiting velocities acting as constraints. Usually the slopes are of the order of 0.0001. For lined canals a velocity of about 2 m/sec is usually recommended.

Roughness coefficient n

Procedures for selecting n are discussed and values of n can be taken from Table (4.4).

Permissible Velocities

Since the cost for a given length of canal depends upon its size, if the available slope permits, it is economical to use highest safe velocities. High velocities may cause scour and erosion of the boundaries. As such, in unlined channels the maximum permissible velocities refer to the velocities that can be safely allowed in the channel without causing scour or erosion of the channel material. In lined canals, where the material of lining can withstand very high velocities, the maximum permissible velocity is determined by the stability and durability of the lining and also on the erosive action of any abrasive material that may be carried in the stream. The permissible maximum velocities normally adopted for a few soil types and lining materials are given in Table (4.8).


Table 4.8 Permissible Maximum velocities

Nature of boundary	Permissible maximum velocity (m/sec)
Sandy soil	0.30 – 0.60
Black cotton soil	0.60 – 0.90
Hard soil	0.90 – 1.10
Firm clay and loam	0.90 – 1.15
Gravel	1.20
Disintegrated rock	1.50
Hard rock	4.00
Brick masonry with cement pointing	2.50
Brick masonry with cement plaster	4.00
Concrete	6.00
Steel lining	10.00

In addition to the maximum velocities, a minimum velocity in the channel is also an important constraint in the canal design. Too low velocity would cause deposition of suspended material, like silt, which cannot only impair the carrying capacity but also increase the maintenance costs. Also, in unlined canals, too low a velocity may encourage weed growth. The minimum velocity in irrigation channels is of the order of 0.30 m/sec.

Free Board

Free board for lined canals is the vertical distance between the full supply levels to the top of lining (Fig. 4.17). For unlined canals, it is the vertical distance from the full supply level to the top of the bank.



This distance should be sufficient to prevent overtopping of the canal lining or banks due to waves. The amount of free board provided depends on the canal size, location, velocity and depth of flow.

Width to Depth Ratio

The relationship between width and depth varies widely depending upon the design practice. If the hydraulically most-efficient channel cross-section is adopted,

$$m = \frac{1}{\sqrt{3}} \rightarrow B = \frac{2y_0}{\sqrt{3}} = 1.155y_0 \rightarrow \frac{B}{y_0} = 1.155$$

If any other value of m is use, the corresponding value of B/y_0 for the efficient section would be

$$\frac{B}{y_0} = 2 \left(2\sqrt{1+m^2} - m \right)$$

In large channels it is necessary to limit the depth to avoid dangers of bank failure. Usually depths higher than about 4.0 m are applied only when it is absolutely necessary. For selection of width and depth, the usual procedure is to adopt a recommended value.

UNIT-5

HYDRAULIC MACHINES

HYDRO-DYNAMIC FORCE OF JETS:

The liquid comes out in the form of a jet from the outlet of a nozzle, the liquid is flowing under pressure. If some plate, which may be fixed or moving, is placed in the path of the jet, a force is exerted by the jet on the plate. This force is obtained by Newton's second law of motion or from Impulse – Momentum equation.

$$F = ma$$

Thus the impact of jet means, the force exerted by the jet on a plate, which may be stationary or moving.

The following cases of impact of jet i.e. the force exerted by the jet on a plate will be considered.

1) Force exerted by the jet on a stationary plate, when

- a) Plate is vertical to the jet.
- b) Plate is inclined to the jet and
- c) Plate is curved

2) Force exerted by the jet on a moving plate, when

- a) Plate is vertical to the jet.
- b) Plate is inclined to the jet.
- c) Plate is curved.

a) FORCE EXERTED BY THE JET ON A STATIONARY VERTICAL PLATE:


Consider a jet of water coming out from the nozzle, strikes a flat vertical plate.

Let V = Velocity of jet.

d = Diameter of jet.

a = Area of cross-section of jet. $= \frac{\pi}{4} d^2$

The jet of water after striking the plate will move along the plate. But the plate is at right angles to the jet. Hence the jet after striking will be deflected through 90° .



Hence the component of the velocity of the jet, in the direction of jet, after striking will be zero.

The force exerted by the jet on the plate in the direction of jet,

F_x = Rate of change of momentum in the direction of force.

$$= \frac{\text{Initial momentum} - \text{Final momentum}}{\text{Time}}$$

$$= \frac{\text{Mass} \times \text{Initial velocity} - \text{Mass} \times \text{Final velocity}}{\text{Time}}$$

For deriving the above equation, we have taken initial velocity minus final velocity and not final velocity minus initial velocity. If the force exerted on the jet is to be calculated, then final velocity minus initial velocity is to be taken. But if the force exerted by the jet on the plate is to be calculated, then initial velocity minus final velocity is to be taken.

b) Force exerted by a jet on a stationary inclined Flat plate:

Let a jet of water coming out from the nozzle, strikes an inclined flat plate.


V = Velocity of jet in the direction of X

a = Area of cross-section of jet.

Mass of water per second striking the plate = $\rho a v$

If the plate is smooth and there is no loss energy due to impact of the jet, the jet will move over the plate after striking with a velocity equal to initial velocity.

with a velocity V . Let us find the force exerted by the jet on the plate in the direction normal to the plate. Let this force is represented by F_n .



of

i.e.

Then F_n = Mass of jet striking per second


$\times$ (Initial velocity of jet before striking in the direction of n

$-$ Final velocity of jet after striking in the direction of n)

c) Force exerted by a jet on a stationary Curved plate:

i) Jet strikes the curved plate at the centre:

The jet after striking the plate comes out with same velocity, if the plate is smooth and there is no loss of energy due to impact of the jet, in the tangential direction of the curved plate. The velocity at the out let of the plate can be resolved in to two components, one in the direction of the jet and other perpendicular to the direction of jet.



Component of velocity in the direction of jet

(-ve sign is taken as the velocity at out let is in the opposite direction of the jet of water coming out from nozzle.)

Component of velocity perpendicular to the jet

Force exerted by the jet in the direction of the jet

$$F_x = \text{Mass per sec} (V_{1x} - V_{2x})$$

Where V_{1x} = Initial velocity in the direction of jet = V

V_{2x} = Final velocity in the direction of jet

Similarly $F_y = \text{Mass per second} (V_{1y} - V_{2y})$

Where V_{1y} = Initial velocity in the direction of y = 0

V_{2y} = Final velocity in the direction of y

-ve sign means the force is acting in the downward direction.

In this case the angle of deflection of jet = $180^\circ - 0$


ii) Jet strikes the curved plate at one end tangentially when the plate is symmetrical:

Let the jet strikes the curved fixed plate at one end tangentially. Let the curved plate is symmetrical about x -axis. Then the angle made by the tangents at the two ends of the plate will be same.

Let V = Velocity of jet of water.

Angle made by the jet with x -axis at the inlet tip of the curved plate.

If the plate is smooth and loss of energy due to impact is zero, then the velocity of water at the outlet tip of the curved plate will be equal to V . The force exerted by the jet of water in the direction of x and y are



iii) Jet strikes the curved plate at one end tangentially when the plate is unsymmetrical:

When the curved plate is unsymmetrical about x -axis, then the angles made by tangents drawn at inlet and outlet tips of the plate with x -axis will be different.

Let Angle made by tangent at the inlet tip with x -axis.

Angle made by tangent at the outlet tip with x -axis

The two components of velocity at inlet are

FORCE EXERTED BY A JET ON MOVING PLATES

The following cases of the moving plates will be considered:

- Flat vertical plate moving in the direction of jet and away from the jet.
- Inclined plate moving in the direction of jet and
- Curved plate moving in the direction of jet or in the horizontal direction.

a) Force on flat vertical plate moving in the direction of jet:


Let a jet of water striking a flat vertical plate moving with a uniform velocity away from the jet.

Let V = Velocity of jet.

a = Area of cross-section of jet.

u = Velocity of flat plate.

In this case, the jet does not strike the plate with a velocity v , but it strikes with a relative velocity, which is equal to the absolute velocity of jet of water minus velocity of the plate.



Hence relative velocity of the jet with respect to plate = $V - u$

Mass of water striking the plate per second

∴ Force exerted by the jet on the moving in the direction of the plate

F_x = mass of water striking per second $\times$ (Initial velocity with which water strikes – Final velocity)

Since final velocity in the direction of jet is zero.

In this, case the work will be done by the jet on the plate, as the plate is moving. For stationary plates, the work done is zero.

∴ The work done per second by the jet on the plate

Time

$$= F_x \times u = \rho a (v - u)^2 \times u \text{ ----- (2)}$$

In the above equation (2), if the value of ρ for water is taken in S.I units (i.e. 1000 kg/m^3) the work done will be in $\frac{\text{Nm}}{\text{s}}$. The term $\frac{\text{Nm}}{\text{s}}$ is equal to Watt (W).

b) Force on inclined plate moving in the direction of jet:

Let a jet of water strikes an inclined plate, which is moving with a uniform velocity in the direction of jet.

Let V = Absolute velocity of water.

u = Velocity of plate in the direction of jet.

a = Cross-sectional area of jet

Angle between jet and plate.

Relative velocity of jet of water

The velocity with which jet strikes

Mass of water striking per second = $a(V - u)$


If the plate is smooth and loss of energy due to impact of the jet is assumed zero, the jet of water will leave the inclined plate with a velocity equal

The force exerted by the jet of water on the plate in the direction normal to the plate is given as

F_n = Mass striking per sec $\times$ (Initial velocity in the normal direction with which jet strikes – final velocity)

Work done per second by the jet on the plate

$$= F_x \times \text{Distance per second in the direction of } x$$



c) Force on the curved plate when the plate is moving in the direction of jet:

Let a jet of water strikes a curved plate at the centre of the plate, which is moving with a uniform velocity in the direction of jet.


Let V = absolute velocity of jet.

a = area of jet.

u = Velocity of plate in the direction of jet.

Relative velocity of jet of water or the velocity with which jet strikes the curved plate = $V - u$

If the plate is smooth and the loss of energy due to impact of jet is zero, then the velocity with which the jet will be leaving the curved vane = $(V - u)$



This velocity can be resolved into two components, one in the direction of jet and the other perpendicular to the direction of jet.

Component of the velocity in the direction of jet = $-(V - u) \cos \theta$

(-ve sign is taken as at the outlet, the component is in the opposite direction of the jet).

Component of velocity in the direction perpendicular to the direction of jet = $(V - u) \sin \theta$

$\therefore$ Mass of water striking the plate = velocity with which jet strikes the plate.

$$= (V - u)$$

$\therefore$ Force exerted by the jet of water on the curved plate in the direction of jet F_x

$$F_x = \text{Mass striking per sec} [\text{Initial velocity with which jet strikes the plate in the direction of jet} - \text{Final velocity}]$$

Work done by the jet on the plate per second


$$= F_x \times \text{Distance travelled per second in the direction of } x$$

d) Force exerted by a jet of water on an un-symmetrical moving Curved plate when Jet strikes tangentially at one of the tips:

Let a jet of water striking a moving curved plate tangentially, at one of its tips.

As the jet strikes tangentially, the loss of energy due to impact of the jet will be zero. In this case as plate is moving, the velocity with which the jet of water strikes is equal to the relative velocity of jet with respect to the plate. Also as the plate is moving in different direction of the jet, the relative velocity at inlet will be equal to the vector difference of velocity of jet and velocity of the plate at inlet.

The triangles ABD and EGH are called velocity



Velocity triangle at inlet: Take any point A and draw a line $AB = V_1$ in magnitude and direction which means line AB makes an angle ϕ with the horizontal line AD. Next draw a line $AC = u_1$ in magnitude. Join C to B. Then CB represents the relative velocity of the jet at inlet. If the loss of energy at inlet due to impact is zero, then CB must be in the tangential direction to the vane at inlet. From B draw a vertical line BD in the downward direction to meet the horizontal line AC produced at D.

Then $BD =$ Represents the velocity of flow at inlet =

$\phi_1 AD =$ Represents the velocity of whirl at inlet =

ϕ_1

$\angle BCD =$ Vane angle at inlet = ϕ

Velocity triangle at outlet: If the vane surface is assumed to be very smooth, the loss of energy due to friction will be zero. The water will be gliding over the surface of the vane with a relative velocity ϕ_1 and will come out of the vane with a relative velocity ϕ_2 . This means that the relative

velocity at outlet $\phi_2 = \phi_1$. The relative velocity at outlet should be in tangential direction to the vane at outlet.

Draw EG in the tangential direction of the vane at outlet and cut $EG = \phi_2$. From G, draw a line GF in the direction of vane at outlet and equal to u_2 , the velocity of vane at outlet. Join EF. Then EF represents the absolute velocity of the jet at outlet in magnitude and direction. From E draw a vertical line EH to meet the line GF produced at H.

Then, $EH =$ Velocity of flow at outlet. = ϕ_2 .

$FH =$ Velocity of whirl at outlet = ϕ_2

$\phi =$ Angle of vane at outlet

$\phi =$ Angle made by V_2 with the direction of motion of vane at outlet.

If vane is smooth and is having velocity in the direction of motion at inlet and outlet equal, then we have

$\phi_1 = \phi_2 = \phi =$ velocity of vane in the direction of motion and

$\phi_1 = \phi_2$

Now mass of water striking the vane per second $\phi \phi \phi_1$ (1)

Where $a =$ area of jet of water, $\phi_1 =$ Relative velocity at inlet.

$\therefore$ Force exerted by the jet in the direction of motion

$F_X =$ Mass of water striking per second $\times$ [Initial velocity with which jet strikes in the

direction of motion – Final velocity of jet in the direction of motion] ----- (2)

HYDRAULIC TURBINES

Turbines are defined as the hydraulic machines which convert hydraulic energy into mechanical energy. This mechanical energy is used in running an electric generator which is directly coupled to the shaft of the turbine. Thus mechanical energy is converted into electrical energy. The electric power which is obtained from the hydraulic energy is known as the Hydro-electric power.

Efficiency of a Turbine: The following are the important efficiencies of a turbine.

- a) Hydraulic Efficiency, η_h
- b) Mechanical Efficiency, η_m
- c) Volumetric Efficiency, η_v
- d) Overall Efficiency, η_o

a) Hydraulic Efficiency (η_h): It is defined as the ratio of power given by the water to the runner of a turbine (runner is a rotating part of a turbine and on the runner vanes are fixed) to the power supplied by the water at the inlet of the turbine. The power at the inlet of the turbine is more and this power goes on decreasing as the water flows over the vanes of the turbine due to hydraulic losses as the vanes are not smooth. Hence power delivered to the runner of the turbine will be less than the power available at the inlet of the turbine.

$$\eta_h = \frac{\text{Power delivered to the runner}}{\text{Power supplied at inlet}} = \frac{\text{R.P}}{\text{W.P}}$$

$$\text{R.P} = \text{Power delivered to the runner} = \frac{W}{g} \frac{[V_{w1} + V_{w2}] \times u}{1000} \quad \text{kW} \text{----- for Pelton Turbine}$$

$$= \frac{W}{g} \frac{[V_{w1} u_1 + V_{w2} u_2] \times u}{1000} \quad \text{kW} \text{----- Radial flow Turbine.}$$

$$\text{W.P} = \text{power supplied at inlet of turbine} = \frac{W \times H}{1000} \quad \text{kW}$$

Where W = weight of water striking the vanes of the turbine per second = $\rho g Q$

Q = Volume of water per second

V_{w1} = Velocity of whirl at inlet.

V_{w2} = Velocity of whirl at outlet

u = Tangential velocity of vane

u_1 = Tangential velocity of vane at inlet of radial vane.

u_2 = Tangential velocity of vane at outlet of radial vane.

H = Net head on the Turbine.

Power supplied at the inlet of the turbine in S I Units is known as Water Power.

$$W.P = \frac{\rho \times g \times Q \times H}{1000} \quad \text{K.W} \quad (\text{For water } \rho = 1000 \text{Kg/m}^3)$$

$$= \frac{1000 \times g \times Q \times H}{1000} = g \times Q \times H \quad \text{kW}$$

b) Mechanical Efficiency (η_m): The power delivered by the water to the runner of a turbine is transmitted to the shaft of the turbine. Due to mechanical losses, the power available at the shaft of the turbine is less than the power delivered to the runner of the turbine. The ratio of power available at the shaft of the turbine (Known as S.P or B.P) to the power delivered to the runner is defined as Mechanical efficiency.

$$\eta_m = \frac{\text{Power at the shaft of the turbine}}{\text{Power delivered by the water to the runner}} = \frac{S.P}{R.P}$$

c) Volumetric Efficiency (η_v): The volume of the water striking the runner of the turbine is slightly less than the volume of water supplied to the turbine. Some of the volume of the water is discharged to the tailrace without striking the runner of the turbine. Thus the ratio of the volume of the water supplied to the turbine is defined as Volumetric Efficiency.

$$\eta_v = \frac{\text{Volume of water actually striking the Runner}}{\text{Volume of water supplied to the Turbine}}$$

d) Overall Efficiency (η_o): It is defined as the ratio of power available at the shaft of the turbine to the power supplied by the water at the inlet of the turbine.

$$\eta_o = \frac{\text{Power available at the shaft of the turbine}}{\text{Power supplied at the inlet of the turbine}} = \frac{\text{Shaft power}}{\text{Water power}}$$

$$= \frac{S.P}{W.P} = \frac{S.P}{W.P} \times \frac{R.P}{R.P}$$

$$= \frac{S.P}{R.P} \times \frac{R.P}{W.P}$$

$$\eta_o = \eta_m \times \eta_h$$

If shaft power (S.P) is taken in kW, Then water power should also be taken in kW. Shaft power is represented by P.

Water power in $kW = \frac{\rho \times g \times Q \times H}{1000}$

Where $\rho = 1000 \text{Kg/m}^3$

$$\eta_o = \frac{\text{Shaft Power in kW}}{\text{Water Power in kW}} = \frac{P}{\frac{\rho \times g \times Q \times H}{1000}}$$

Where P = Shaft Power

CLASSIFICATION OF HYDRAULIC TURBINES:

The Hydraulic turbines are classified according to the type of energy available at the inlet of the turbine, direction of flow through the vanes, head at the inlet of the turbine and specific speed of the turbine. The following are the important classification of the turbines.

1. According to the type of energy at inlet:
 - (a) Impulse turbine and
 - (b) Reaction turbine
2. According to the direction of flow through the runner:
 - (a) Tangential flow turbine
 - (b) Radial flow turbine.
 - (c) Axial flow turbine
 - (d) Mixed flow turbine.
3. According to the head at inlet of the turbine:
 - (a) High head turbine
 - (b) Medium head turbine and
 - (c) Low head turbines.
4. According to the specific speed of the turbine:
 - (a) Low specific speed turbine
 - (b) Medium specific speed turbine
 - (c) High specific speed turbine.

If at the inlet of turbine, the energy available is only kinetic energy, the turbine is known as **Impulse turbine**. As the water flows over the vanes, the pressure is atmospheric from inlet to outlet of the turbine. If at the inlet of the turbine, the water possesses kinetic energy as well as pressure energy, the turbine is known as **Reaction turbine**. As the water flows through runner, the water is under pressure and the pressure energy goes on changing in to kinetic energy. The runner is completely enclosed in an air-tight casing and the runner and casing is completely full of water.

If the water flows along the tangent of runner, the turbine is known as **Tangential flow turbine**. If the water flows in the radial direction through the runner, the turbine is called **Radial flow turbine**. If the water flows from outward to inwards radially, the turbine is known as **Inward** radial flow turbine, on the other hand, if the water flows radially from inward to outwards, the turbine is known as **outward** radial flow turbine. If the water flows through the runner along the direction parallel to the axis of rotation of the runner, the turbine is called **axial flow** turbine. If the water flows through the runner in the radial direction but leaves in the direction parallel to the axis of rotation of the runner, the turbine is called **mixed flow** turbine.

PELTON WHEEL (Turbine)

It is a tangential flow impulse turbine. The water strikes the bucket along the tangent of the runner. The energy available at the inlet of the turbine is only kinetic energy. The pressure at the inlet and outlet of turbine is atmospheric. This turbine is used for high heads and is named after L.A. Pelton an American engineer.

The water from the reservoir flows through the penstocks at the outlet of which a nozzle is fitted. The nozzle increases the kinetic energy of the water flowing through the penstock. At the outlet of the nozzle, the water comes out in the form of a jet and strikes the buckets (vanes) of the runner. The main parts of the Pelton turbine are:

1. Nozzle and flow regulating arrangement (spear)
2. Runner and Buckets.
3. Casing and
4. Breaking jet

1. Nozzle and flow regulating arrangement: The amount of water striking the buckets (vanes) of the runner is controlled by providing a spear in the nozzle. The spear is a conical needle which is operated either by hand wheel or automatically in an axial direction depending upon the size of the unit. When the spear is pushed forward in to the nozzle, the amount of water striking the runner is reduced. On the other hand, if the spear is pushed back, the amount of water striking the runner increases.

2. Runner with buckets: It consists of a circular disc on the periphery of which a number of buckets evenly spaced are fixed. The shape of the buckets is of a double hemispherical cup or bowl. Each bucket is divided in to two symmetrical parts by a dividing wall, which is known as splitter.

The jet of water strikes on the splitter. The splitter divides the jet in to two equal parts and the jet comes out at the outer edge of the bucket. The buckets are shaped in such a way that the jet gets deflected through an angle of 160° or 170° . The buckets are made of cast Iron, cast steel, Bronze or stainless steel depending upon the head at the inlet of the turbine.

3. Casing: The function of casing is to prevent the splashing of the water and to discharge the water to tailrace. It also acts as safeguard against accidents. It is made of Cast Iron or fabricated steel plates. The casing of the Pelton wheel does not perform any hydraulic function.

4. Breaking jet: When the nozzle is completely closed by moving the spear in the forward direction, the amount of water striking the runner reduces to zero. But the runner due to inertia goes on revolving for a long time. To stop the runner in a short time, a small nozzle is provided, which directs the jet of water on the back of the vanes. This jet of water is called Breaking jet.

Velocity triangles and work done for Pelton wheel:

The jet of water from the nozzle strikes the bucket at the splitter, which splits up the jet into two parts. These parts of the jet, glide over the inner surfaces and comes out at the outer edge. The splitter is the inlet tip and outer edge of the bucket is the outlet tip of the bucket. The inlet velocity triangle is drawn at the splitter and outlet velocity triangle is drawn at the outer edge of the bucket.

Let

H = Net head acting on the Pelton Wheel

$$= H_g - h_f$$

Where H_g = Gross Head

$$h_f = \frac{4fLV^2}{D^* \times 2g}$$

Where D^* = diameter of penstock,


D = Diameter of wheel,

d = Diameter of Jet,

N = Speed of the wheel in r.p.m

Then V_1 = Velocity of jet at inlet

$$= \sqrt{2gH} \quad u = u_1 = u_2 = \frac{\pi DN}{60}$$



The Velocity Triangle at inlet will be a straight line where

$$V_{r1} = V_1 - u_1 = V_1 - u$$

$$V_{w1} = V_1 \quad \alpha = 0^\circ \quad \text{and} \quad \theta = 0^\circ$$

From the velocity triangle at outlet, we have

$$V_{r2} = V_{r1} \text{ and } V_{w2} = V_{r2} \cos \phi - u_2$$

The force exerted by the Jet of water in the direction of motion is

$$F_x = \rho a V_1 [V_{w1} + V_{w2}] \quad (1)$$

As the angle β is an acute angle, +ve sign should be taken. Also this is the case of series of vanes, the mass of water striking is $\rho a V_1$ and not $\rho a V_{r1}$. In equation (1) „a“ is the area of the jet $= \frac{\pi}{4} d^2$

Now work done by the jet on the runner per second

$$= F_x \times u = \rho a V_1 [V_{w1} + V_{w2}] \times u \quad \text{Nm/s}$$

$$\text{Power given to the runner by the jet} = \frac{\rho a V_1 [V_{w1} + V_{w2}] \times u}{1000} \text{ kW}$$

$$\begin{aligned}\text{Work done/s per unit weight of water striking/s} &= \frac{\rho a V_1 [V_{w1} + V_{w2}] \times u}{\text{Weight of water striking/s}} \\ &= \frac{\rho a V_1 [V_{w1} + V_{w2}] \times u}{\rho a V_1 \times g} = \frac{1}{g} [V_{w1} + V_{w2}] \times u \quad \text{---(3)}\end{aligned}$$

The energy supplied to the jet at inlet is in the form of kinetic energy

$$\therefore \text{K.E. of jet per second} = \frac{1}{2} m V^2 = \frac{1}{2} (\rho a V_1) \times V_1^2$$

$$\begin{aligned}\therefore \text{Hydraulic efficiency, } \eta_h &= \frac{\text{Work done per second}}{\text{K.E. of jet per second}} \\ &= \frac{\rho a V_1 [V_{w1} + V_{w2}] \times u}{\frac{1}{2} (\rho a V_1) \times V_1^2} \\ &= \frac{2 [V_{w1} + V_{w2}] \times u}{V_1^2} \quad \text{---(4)}\end{aligned}$$

$$\text{Now} \quad V_{w1} = V_1 \text{ and } V_{r1} = V_1 - u_1 = (V_1 - u)$$

$$\begin{aligned}\therefore V_{r2} &= (V_1 - u) \\ \text{And } V_{w2} &= V_{r2} \cos \phi - u_2\end{aligned}$$

$$\begin{aligned}&= V_1 \cos \phi - u \\ &= (V_1 - u) \cos \phi - u\end{aligned}$$

Substituting the values of V_{w1} and V_{w2} in equation (4)

$$\begin{aligned}\eta_h &= \frac{2 [V_1 + (V_1 - u) \cos \phi - u] \times u}{V_1^2} = \frac{2 [V_1 - u + (V_1 - u) \cos \phi] \times u}{V_1^2} \\ &= \frac{2 (V_1 - u) [1 + \cos \phi] u}{V_1^2} \quad \text{---(5)}\end{aligned}$$

The efficiency will be maximum for a given value of V_1 when

$$\frac{d}{du} (\eta_h) = 0 \text{ or } \frac{d}{du} \left[\frac{2u(V_1 - u)[1 + \cos \phi]}{V_1^2} \right] = 0$$

$$\text{Or } \frac{(1 + \cos \phi)}{V_1^2} \frac{d}{du} (2uV_1 - 2u^2) = 0$$

$$\text{Or } \frac{d}{du} [2uV_1 - 2u^2] = 0 \quad \left(\because \frac{1 + \cos \phi}{V_1^2} \neq 0 \right)$$

$$\text{Or } 2V_1 - 4u = 0 \quad \text{Or } u = \frac{V_1}{2} \quad \text{---(6)}$$

Equation (6) states that hydraulic efficiency of a Pelton wheel will be maximum when the velocity of the wheel is half the velocity of the jet water at inlet. The expression for maximum efficiency will be obtained by substituting the value of $u = \frac{V_1}{2}$ in equation (5)

$$\text{Max. } \eta_h = \frac{2 \left(V_1 - \frac{V_1}{2} \right) (1 + \cos \phi) \times \frac{V_1}{2}}{V_1^2}$$

$$= \frac{2 \times \frac{V_1}{2} (1 + \cos \phi) \frac{V_1}{2}}{V_1^2} = \frac{(1 + \cos \phi)}{2} \quad \text{---(7)}$$

RADIAL FLOW REACTION TURBINE:


In the Radial flow turbines water flows in the radial direction. The water may flow radially from outwards to inwards (i.e. towards the axis of rotation) or from inwards to outwards. If the water flows from outwards to inwards through the runner, the turbine is known as **inwards radial flow turbine**. And if the water flows from inwards to outwards, the turbine is known as **outward radial flow turbine**.

Reaction turbine means that the water at the inlet of the turbine possesses kinetic energy as well as pressure energy. As the water flows through the runner, a part of pressure energy goes on changing into kinetic energy. Thus the water through the runner is under pressure. The runner is completely enclosed in an air-tight casing and the runner is always full of water.

Main parts of a Radial flow Reaction turbine:

1. Casing
2. Guide mechanism
3. Runner and
4. Draft tube.

1. Casing: in case of reaction turbine, casing and runner are always full of water. The water from the penstocks enters the casing which is of spiral shape in which area of cross-section one of the casing goes on decreasing gradually. The casing completely surrounds the runner of the turbine. The water enters



the runner at constant velocity throughout the circumference of the runner.

2. Guide Mechanism: It consists of a stationary circular wheel all around the runner of the turbine. The stationary guide vanes are fixed on the guide mechanism. The guide vanes allow the water to strike the vanes fixed on the runner without shock at inlet. Also by suitable arrangement, the width between two adjacent vanes of guide mechanism can be altered so that the amount of water striking the runner can be varied.

3. Runner: It is a circular wheel on which a series of radial curved vanes are fixed. The surfaces of the vanes are made very smooth. The radial curved vanes are so shaped that the water enters and leaves the runner without shock. The runners are made of cast steel, cast iron or stain less steel. They are keyed to the shaft.

4. Draft - Tube: The pressure at the exit of the runner of a reaction turbine is generally less than atmospheric pressure. The water at exit can't be directly discharged to the tail race. A tube or pipe of gradually increasing area is used for discharging the water from the exit of the turbine to the tail race. This tube of increasing area is called draft-tube.

Inward Radial Flow Turbine: In the inward radial flow turbine, in which case the water from the casing enters the stationary guiding wheel. The guiding wheel consists of guide vanes which direct the water to enter the runner which consists of moving vanes. The water flows over the moving vanes in the inward radial direction and is discharged at the inner

diameter of the runner. The outer diameter of the runner is the inlet and the inner diameter is the outlet.

Velocity triangles and work done by water on runner:

Work done per second on the runner by water

$$\begin{aligned}
 &= \rho a V_1 [V_{w_1} u_1 \pm V_{w_2} u_2] \\
 &= \rho Q [V_{w_1} u_1 \pm V_{w_2} u_2] \quad \text{_____ (1)} \quad (\because a V_1 = Q)
 \end{aligned}$$

The equation represents the energy transfer per second to the runner.

Where V_{w_1} = Velocity of whirl at inlet

V_{w_2} = Velocity of whirl at outlet

u_1 = Tangential velocity at inlet

$$= \frac{\pi D_1 \times N}{60}, \quad \text{Where } D_1 = \text{Outer dia. Of runner,}$$

u_2 = Tangential velocity at outlet

$$= \frac{\pi D_2 \times N}{60}$$

Where D_2 = Inner dia. Of runner,

N = Speed of the turbine in r.p.m.

The work done per second per unit weight of water per second

$$\begin{aligned}
 &= \frac{\text{work done per second}}{\text{weight of water striking per second.}} \\
 &= \frac{\rho Q [V_{w_1} u_1 \pm V_{w_2} u_2]}{\rho Q \times g} \\
 &= \frac{1}{g} [V_{w_1} u_1 \pm V_{w_2} u_2] \quad \text{_____ (2)}
 \end{aligned}$$

Equation (2) represents the energy transfer per unit weight/s to the runner. This equation is known by **Euler's equation**.

In equation +ve sign is taken if β is an acute angle,

-ve sign is taken if β is an obtuse angle.

If $\beta = 90^\circ$ then $V_{w_2} = 0$ and work done per second per unit weight of water striking/s



$$\text{Work done} = \frac{1}{g} V_{w_1} u_1$$

$$\text{Hydraulic efficiency } \eta_h = \frac{R.P.}{W.P.} = \frac{\text{Power delivered to runner}}{\text{Power supplied at inlet}}$$

$$\begin{aligned}
 &= \frac{\frac{W}{1000 \times g} [V_{w_1} u_1 \pm V_{w_2} u_2]}{\frac{W \times H}{1000}} = \frac{(V_{w_1} u_1 \pm V_{w_2} u_2)}{gH} \quad \text{_____ (3)}
 \end{aligned}$$

Where R.P. = Runner Power i.e. power delivered by water to the runner

W.P. = Water Power



If the discharge is radial at outlet, then $V_{w_2} = 0$

$$\eta_h = \frac{V_{w_1} u_1}{gH}$$

Definitions:

The following terms are generally used in case of reaction radial flow turbines which are defined as:

1. Speed Ratio: The speed ratio is defined as $= \frac{u_1}{\sqrt{2gH}}$

Where u_1 = tangential velocity of wheel at inlet

2. Flow Ratio: The ratio of velocity of flow at inlet (V_{f_1}) to the velocity given $\sqrt{2gH}$ is known as the flow ratio.

$$= \frac{V_{f_1}}{\sqrt{2gH}}$$

Where H = Head on turbine

3. Discharge of the turbine: The discharge through a reaction radial flow turbine is

$$Q = \pi D_1 B_1 \times V_{f_1} = \pi D_2 B_2 \times V_{f_2}$$

Where D_1 = Dia of runner at inlet

D_2 = Dia of runner at outlet

B_1 = Width of the runner at inlet

B_2 = Width of runner at outlet

V_{f_1} = Velocity of flow at inlet

V_{f_2} = Velocity of flow at outlet

If the thickness of the vanes are taken into consideration then the area through which flow takes place is given by

$$= \pi D_1 - n \times t$$

Where n = Number of vanes and

t = Thickness of each vane

4. Head: The (H) on the turbine is given by


$$H = \frac{P_1}{\rho g} + \frac{V_1^2}{2g}$$

Where P_1 = Pressure at inlet

5. Radial Discharge: This means the angle made by absolute velocity with the tangent on the wheel is 90° and the component of whirl velocity is zero. The radial discharge at outlet means $\beta = 90^\circ$ and $V_{w_2} = 0$ while radial discharge at inlet means $\alpha = 90^\circ$ and $V_{w_1} = 0$

6. If there is no loss of energy when the water flows through the vanes then we have

$$H - \frac{V_2^2}{2g} = \frac{1}{g} [V_{w_1}u_1 \pm V_{w_2}u_2]$$



FRANCIS TURBINE:

The inward flow reaction turbine having radial discharge at outlet is known as Francis Turbine. The water enters the runner of the turbine in the radial direction at outlet and leaves in the axial direction at the inlet of the runner. Thus the Francis turbine is a mixed flow type turbine.

The velocity triangle at inlet and outlet of the Francis turbine are drawn in the same way as in case of inward flow reaction turbine. As in case of inward radial flow turbine. The discharge of Francis turbine is radial at outlet; the velocity of whirl at outlet (V_{w_2}) will be zero. Hence the work done by water on the runner per second will be


$$= \rho Q [V_{w_1}u_1]$$

The work done per second per unit weight of water striking/sec = $\frac{1}{g} [V_{w_1}u_1]$

Hydraulic efficiency $\eta_h = \frac{V_{w_1}u_1}{gH}$

Important relations for Francis turbines:

1. The ratio of width of the wheel to its diameter is given as $n = \frac{B_1}{D_1}$. The value of n varies from 0.10 to 0.40
2. The flow ratio is given as
Flow ratio = $\frac{V_{f_1}}{\sqrt{2gH}}$ and varies from 0.15 to 0.30
3. The speed ratio = $\frac{u_1}{\sqrt{2gH}}$ varies from 0.6 to 0.9



Outward radial Flow Reaction Turbine:

In the outward radial flow reaction turbine water from the casing enters the stationary guide wheel. The guide wheel consists of guide vanes which direct the water to enter the runner which is around the stationary guide wheel. The water flows through the vanes of the runner in the outward radial direction and is discharged at the outer diameter of the runner. The inner diameter of the runner is inlet and outer diameter is the outlet.

The velocity triangles at inlet and outlet will be drawn by the same procedure as adopted for inward flow turbine. The work done by the water on the runner per second, the horse power developed and hydraulic efficiency will be obtained from the velocity triangles. In this case as the inlet of the runner is at the inner diameter of the runner, the tangential velocity at inlet will be less than that of an outlet. i.e.

$$u_1 < u_2 \quad \text{As } D_1 < D_2 \text{ All}$$

the working conditions flow through the runner blades without shock. As such eddy losses which are inevitable in Francis and propeller turbines are almost completely eliminated in a Kaplan turbine.


The discharge through the runner is obtained as

$$Q = \frac{\pi}{4} (D_0^2 - D_b^2) \times V_{f_1}$$

Where D_0 = outer diameter of the runner

D_b = Diameter of the hub

V_{f_1} = Velocity of flow at inlet



Important points for Kaplan turbine:

1. The peripheral velocity at inlet and outlet are equal.

$$u_1 = u_2 = \frac{\pi D_0 N}{60}$$

Where D_0 = Outer diameter of runner.

2. Velocity of flow at inlet and outlet are equal.

$$V_{f_1} = V_{f_2}$$

3. Area of flow at inlet = Area of flow at outlet

$$= \frac{\pi}{4} (D_0^2 - D_b^2)$$

AXIAL FLOW REACTION TURBINE:

If the water flows parallel to the axis of the rotation shaft the turbine is known as axial flow turbine. If the head at inlet of the turbine is the sum of pressure energy and kinetic energy and during the flow of the water through the runner a part of pressure energy is converted into kinetic energy, the turbine is known as reaction turbine.

For axial flow reaction turbine, the shaft of the turbine is vertical. The lower end of the shaft is made longer known as “hub” or “boss”. The vanes are fixed on the hub and act as a runner for the axial flow reaction turbine. The important types of axial flow reaction turbines are:

1. Propeller Turbine
2. Kaplan Turbine




When the vanes are fixed to the hub and they are not adjustable, the turbine is known as propeller turbine. But if the vanes on the hub are adjustable, the turbine is known as Kaplan turbine. This turbine is suitable, where large quantity of water at low heads is available.

The main parts of the Kaplan turbine are:

1. Scroll casing
2. Guide vanes mechanism
3. Hub with vanes or runner of the turbine
4. Draft tube

Between the guide vanes and the runner, the water in the Kaplan turbine turns through a right angle into the axial direction and then passes through the runner. The runner of the Kaplan turbine has four or six or eight in some cases blades and it closely resembles a ship's propeller. The blades (vanes) attached to a hub or bosses are so shaped that water flows axially through the runner.

The runner blades of a propeller turbine are fixed but the Kaplan turbine runner blades can be turned about their own axis, so that their angle of inclination may be adjusted while the turbine is in motion. The adjustment of the runner blades is usually carried out automatically by means of a servomotor operating inside the hollow coupling of turbine and generator shaft. When both guide vane angle and runner blade angle may thus be varied a



high efficiency can be maintained over a wide range of operating conditions. i.e. even at part load, when a lower discharge is flowing through the runner a high efficiency can be attained in case of Kaplan turbine. The flow through turbine runner does not affect the shape of velocity triangles as blade angles are simultaneously adjusted, the water under all the working conditions flows through the runner blades without shock. The eddy losses which are inevitable in Francis and propeller turbines are completely eliminated in a Kaplan Turbine.

Working Proportions of Kaplan Turbine:

The main dimensions of Kaplan Turbine runners are similar to Francis turbine runner. However the following are main deviations,

- i. Choose an appropriate value of the ratio $n = \frac{d}{D}$, where d is hub or boss diameter and D is runner outside diameter. The value of n varies from 0.35 to 0.6

- ii. The discharge Q flowing through the runner is given by

$$Q = \frac{\pi}{4} (D^2 - d^2) V_f = \frac{\pi}{4} (D^2 - d^2) \psi \sqrt{2gH}$$

The value of flow ratio ψ for a Kaplan turbine is 0.7

- iii. The runner blades of the Kaplan turbine are twisted, the blade angle being greater at the outer tip than at the hub. This is because the peripheral velocity of the blades being directly proportional to radius. It will vary from section to section along the blade, and hence in order to have shock free entry and exit of water over the blades with angles varying from section to section will have to be designed.

DRAFT TUBE:

The draft tube is a pipe of gradually increasing area, which connects the outlet of the runner to the tail race. It is used for discharging water from the exit of the turbine to the tail race. This pipe of gradually increasing area is called a draft tube. One end of the draft tube is connected to the outlet of the runner and the other end is submerged below the level of water in the tail race. The draft tube in addition to save a passage for water discharge has the following two purposes also:

1. It permits a negative head to be established at the outlet of the runner and thereby increase the net head on the turbine. The turbine may be placed above the tail race without any loss of net head and hence turbine may be inspected properly.
2. It converts a large portion of the kinetic energy $\left(\frac{V_2^2}{2g} \right)$ rejected at the outlet of the turbine into useful energy. Without the draft tube the kinetic energy rejected at the turbine will go waste to the tail race.


Hence by using the draft tube, the net head on turbine increases. The turbine develops more power and also the efficiency of the turbine increases.

If a reaction turbine is not fitted with a draft tube, the pressure at the outlet of the runner will be equal to atmospheric pressure. The water from the outlet of the runner will discharge freely into the tail race. The net head on the turbine will be less than that of

a reaction turbine fitted with a draft tube. Also without draft tube the kinetic energy $\left(\frac{v_2^2}{2g}\right)$ rejected at the outlet of the will go water to the tail race.

Types of Draft Tube:

1. Conical Draft Tube
2. Simple Elbow Tubes
3. Moody Spreading tubes
4. Elbow Draft Tubes with Circular inlet and rectangular outlet



and moody spreading draft tubes are most efficient while simple elbow draft tube and elbow draft tubes with circular inlet and rectangular outlet require less space as compared to other draft tubes.

Draft tube theory: Consider a conical draft tube

H_s = Vertical height of draft tube above tail race

y = Distance of bottom of draft tube from tail race.

Applying Bernoulli's equation to inlet section 1-1 and outlet section 2-2 of the draft tube and taking section 2-2 a datum, we get

$$\frac{p_1}{\rho g} + \frac{v_1^2}{2g} + (H_s + y) = \frac{p_2}{\rho g} + \frac{v_2^2}{2g} + 0 + h_f \quad \text{-----(1)}$$

Where h_f = loss of energy between section 1-1 and 2-2.


But $\frac{p_2}{\rho g}$ = Atmospheric Pressure + $y = \frac{p_a}{\rho g} + y$

Substituting this value of $\frac{p_2}{\rho g}$ in equation (1) we get

$$\frac{p_1}{\rho g} + \frac{v_1^2}{2g} + (H_s + y) = \frac{p_a}{\rho g} + y + \frac{v_2^2}{2g} + h_f$$

$$\frac{p_1}{\rho g} + \frac{v_1^2}{2g} + H_s = \frac{p_a}{\rho g} + \frac{v_2^2}{2g} + h_f$$

$$\frac{p_1}{\rho g} = \frac{p_a}{\rho g} + \frac{v_2^2}{2g} + h_f - \frac{v_1^2}{2g} - H_s$$



Department of Mechanical Engineering, MRCET

_____ (2)

In equation (2) is less than atmospheric pressure.

$$\frac{p_1}{\rho g} = \frac{p_a}{\rho g} - H_s - \left[\frac{V_1^2}{2g} - \frac{V_2^2}{2g} - h_f \right]$$

Efficiency of Draft Tube: the efficiency of a draft tube is defined as the ratio of actual conversion of kinetic head in to pressure in the draft tube to the kinetic head at the inlet of the draft tube.

$$\eta_d = \frac{\text{Actual conversion of Kinetic head in to Pressure head}}{\text{Kinetic head at the inlet of draft tube}}$$

Let V_1 = Velocity of water at inlet of draft tube

V_2 = Velocity of water at outlet of draft tube

h_f = Loss of head in the draft tube

Theoretical conversion of Kinetic head into Pressure head in

$$\text{Draft tube} = \left[\frac{V_1^2}{2g} - \frac{V_2^2}{2g} \right]$$

$$\text{Actual conversion of Kinetic head into pressure head} = \left[\frac{V_1^2}{2g} - \frac{V_2^2}{2g} \right] - h_f$$

Now Efficiency of draft tube

$$\eta_d = \frac{\left[\frac{V_1^2}{2g} - \frac{V_2^2}{2g} \right] - h_f}{\frac{V_1^2}{2g}}$$

PROBLEMS

1. A pelton wheel has a mean bucket speed of 10m/s with a jet of water flowing at the rate of 700lt/sec under a head of 30 m. the buckets deflect the jet through an angle of 160° calculate the power given by the water to the runner and hydraulic efficiency of the turbine? Assume co-efficient of velocity=0.98

Given:

Speed of bucket $u = u_1 = u_2 = 10\text{m/s}$

Discharge $Q = 700\text{lt/sec} = 0.7\text{m}^3/\text{s}$


Head of water $H = 30\text{m}$

Angle deflection = 160°

$\therefore \text{Angle } \phi = 180 - 160 = 20^\circ$

Co-efficient of velocity $C_v = 0.98$

The velocity of jet $V_1 = C_v \sqrt{2gH} = 0.98 \sqrt{2 \times 9.81 \times 30} = 23.77\text{m/s}$



$$V_{r_2} = V_1 - u_1 = 23.77 - 10 = 13.77 \text{ m/s}$$

$$V_{w_1} = V_1 = 23.77 \text{ m/s}$$

From the outlet velocity triangle

$$V_{r_2} = V_{r_1} = \frac{13.77 \text{ m}}{s}$$

$$\begin{aligned} V_{w_2} &= V_{r_1} \cos \phi - u_2 \\ &= 13.77 \cos 20^\circ - 10 = 2.94 \text{ m/s} \end{aligned}$$

Work done by the jet/sec on the runner is given by equation

$$\begin{aligned} &= \rho a V_1 [V_{w_1} + V_{w_2}] \times u \\ &= 1000 \times 0.7 [23.77 + 2.94] \times 10 \\ &= 186970 \text{ Nm/s} \end{aligned}$$

$$\text{Power given to the turbine} = \frac{186970}{1000} = 186.97 \text{ kW}$$

The hydraulic efficiency of the turbine is given by equation

$$\eta_h = \frac{2[V_{w_1} + V_{w_2}] \times u}{V_1^2} = \frac{2[23.77 + 2.94] \times 10}{23.77 \times 23.77} = 0.9454$$

$$\text{Or} \quad = 94.54\%$$

2. A reaction turbine works at 450rpm under a head of 120m. its diameter at inlet is 120cm and flow area is 0.4 m^2 . The angles made by absolute and relative velocities at inlet are 20° and 60° respectively, with the tangential velocity. Determine

- Volume flow rate
- the power developed
- The hydraulic efficiency. Assume whirl at outlet is zero.

Given: Speed of turbine $N = 450 \text{ rpm}$

Head $H = 120 \text{ m}$

Diameter of inlet $D_1 = 120 \text{ cm} = 1.2 \text{ m}$

Flow area $\pi D_1 \times B_1 = 0.4 \text{ m}^2$

Angle made by absolute velocity $\alpha = 20^\circ$


Angle made by relative velocity $\theta = 60^\circ$

Whirl at outlet $V_{w_2} = 0$

Tangential velocity of the turbine at inlet

$$u_1 = \frac{\pi D_1 N}{60} = \frac{\pi \times 1.2 \times 450}{60} = 28.27 \text{ m/s}$$

From inlet triangle $\tan \alpha = \frac{V_{f_1}}{V_{w_1}}$



$$\tan 20^\circ = \frac{V_{f1}}{V_{w1}} = 0.364,$$

$$V_{f1} = 0.364V_{w1} \text{-----(1)}$$

Also $\tan \theta = \frac{V_{f1}}{V_{w1} - u_1} = \frac{0.364V_{w1}}{V_{w1} - 28.27} \quad (\because \tan \theta = \tan 60^\circ = 1.732)$

$$1.732 = \frac{0.364V_{w1}}{V_{w1} - 28.27}$$

$$0.364V_{w1} = 1.732(V_{w1} - 28.27)$$

$$0.364V_{w1} = 1.732V_{w1} - 28.27 \times 1.732$$

$$V_{w1}(1.732 - 0.364) = 48.96$$

$$V_{w1} = \frac{48.96}{1.732 - 0.364} = 35.79 \text{ m/s}$$

From equation (1) $V_{f1} = 0.364V_{w1} = 0.364 \times 35.79 = 13.027 \text{ m/s}$

i) Volume flow rate is given by equation as $Q = \pi D_1 B_1 V_{f1}$

$$Q = 0.4 \times 13.027 = 5.211 \text{ m}^3/\text{sec} \quad (\because \pi D_1 B_1 = 0.4 \text{ m}^2)$$

ii) Work done per second on the turbine is given by equation

$$= \rho Q [V_{w1} \times u_1]$$

$$= 1000 \times 5.211 [35.79 \times 28.27] = 5272.402 \text{ Nm/s}$$

Power developed in kW = $\frac{\text{work done per sec}}{1000} = \frac{5272.402}{1000} = 5272.402 \text{ kW}$

iii) The hydraulic efficiency is given by equation

$$\eta_h = \frac{V_{w1} \times u_1}{g \times H} = \frac{35.79 \times 28.27}{9.81 \times 120} = 0.8595$$

$$= 85.95\%$$

3. The internal and external diameters of an outward flow reaction turbine are 2m and 2.75m respectively. The turbine is running at 250rpm and the rate of flow of water through the turbine is 5m³/s. the width of the runner is constant at inlet and outlet is equal to 250mm. the head on the turbine is 150m. Neglecting the thickness of the vanes and taking discharge radial at outlet, determine:

i) Vane angle at inlet and outlet

ii) velocity of flow inlet and outlet

Given: Internal diameter $D_1 = 2\text{m}$
 External diameter $D_2 = 2.75\text{m}$
 Speed of turbine $N = 250\text{rpm}$
 Discharge $Q = 5\text{m}^3/\text{s}$


Width at inlet and outlet $B_1 = B_2 = 250\text{mm} = 0.25\text{m}$

Head $H = 150\text{m}$

Discharge at outlet = radial

$$\therefore V_{w2} = 0 \text{ and } V_{f2} = V_2$$

The tangential velocity of turbine at inlet and outlet



$$u_1 = \frac{\pi D_1 N}{60} = \frac{\pi \times 2 \times 250}{60} = 26.18 \text{ m/s}$$

$$u_2 = \frac{\pi D_2 N}{60} = \frac{\pi \times 2.75 \times 250}{60} = 36 \text{ m/s}$$

The discharge through the turbine is given by

$$V_{f_2} = \frac{Q}{\pi D_1 B_1} = \frac{5}{\pi \times 2.75 \times 0.25} = 2.315 \text{ m/s}$$

Using equation $H - \frac{V_2^2}{2g} = \frac{V_{w1}u_1}{g}$ ($\because V_{w2} = 0$)

But for radial discharge $V_2 = V_{f_2} = 2.315 \text{ m/s}$

$$150 - \frac{(2.315)^2}{2 \times 9.81} = \frac{V_{W1} \times 26.18}{9.81} \quad \text{Or} \quad 149.73 = \frac{V_{W1} \times 26.18}{9.81}$$

$$V_{w_1} = \frac{149.73 \times 9.81}{26.18} = 56.1 \text{ m/s}$$

i) Vane angle at inlet and outlet

From the inlet velocity triangle $\tan \theta = \frac{V_{f1}}{V_{w1} - u_1} = \frac{3.183}{56.1 - 26.18} = 0.1064$

$\therefore \theta = \tan^{-1} 0.1064 = 6.072^\circ$
 From outlet velocity triangle $\tan \theta = \frac{V_{f2}}{u_2} = \frac{2.315}{36} = 0.0643$ or $6^\circ 4.32'$

ii) Velocity of flow at inlet and outlet

∴ $\theta = \tan^{-1}(0.0643) = 3.68^\circ$ or $3^\circ 40.8'$
 $V_{f_1} = 3.183 \text{ m/s}$ and $V_{f_2} = 2.315 \text{ m/s}$

4. A Francis turbine with an overall efficiency of 75% is required to produce 148.25kW power. It is working under a head of 7.62m. The peripheral velocity = $0.26 \sqrt{2gh}$ and the radial velocity of flow at inlet is $0.96 \sqrt{2gh}$. The wheel runs at 150rpm and the hydraulic losses in the turbine are 22% of the available energy. Assuming radial discharge determine

i) The guide blade angle.

ii) The wheel vane angle at inlet

iii) The diameter of the wheel at inlet, and **iv)** Width of the wheel at inlet.

Given: Overall efficiency $\eta_o = 75\% = 0.75$

Head H=7.62rpm

Power Produced S.P. = 148.25kW

Speed N= 150rpm

Hydraulic losses = 22% of energy

Peripheral velocity $u_1 = 0.26\sqrt{2gh} = 0.26\sqrt{2 \times 9.81 \times 7.62} = 3.179\text{m/s}$

Discharge at outlet = Radial

$$V_{w_2} = 0 \quad V_{f_2} = V_2$$

The hydraulic efficiency

But ,

i) The guide blade angle i.e. From inlet velocity triangle

ii) The wheel angle at inlet

iii) The diameter of wheel at inlet (D_1)

Using relation

$$u_1 = \frac{\pi D_1 N}{60}$$

$$D_1 = \frac{60 \times u_1}{\pi \times N} = \frac{60 \times 3.179}{\pi \times 150} = 0.4047m$$

iv) Width of the wheel at inlet (B_1)

$$\eta_0 = \frac{SP}{WP} = \frac{148.25}{WP}$$

$$WP = \frac{W \times H}{1000} = \frac{\rho \times g \times Q \times H}{1000} = \frac{1000 \times 9.81 \times Q \times 7.62}{1000}$$

$$\eta_0 = \frac{148.25 \times 1000}{1000 \times 9.81 \times Q \times 7.62}$$

$$Q = \frac{148.25 \times 1000}{1000 \times 9.81 \times 7.62 \times \eta_0} = \frac{148.25 \times 1000}{1000 \times 9.81 \times 7.62 \times 0.75} = 2.644m^3/s \quad (\because \eta_0 = 75\%)$$

Using equation

$$Q = \pi D_1 B_1 \times V_{f_1}$$

$$2.644 = \pi \times 0.4047 \times B_1 \times 11.738$$

$$B_1 = \frac{2.644}{\pi \times 0.4047 \times 11.738} = 0.177m$$

5. A Kaplan turbine runner is to be designed to develop 7357.5kW shaft power. The net available head is 5.50m. Assume that the speed ratio is 2.09 and flow ratio is 0.68 and the overall efficiency is 60%. The diameter of boss is $\frac{1}{3}$ of the diameter of runner. Find the diameter of the runner, its speed and specific speed.

Given: Shaft power $P = 7357.5kW$

Head $H = 5.5m$

Speed ratio $= \frac{u_1}{\sqrt{2gH}} = 2.09$

$$\therefore u_1 = 2.09 \times \sqrt{2 \times 9.81 \times 5.5} = 21.71m/s$$

$$\text{Flow ratio} = \frac{V_{f_1}}{\sqrt{2gH}} = 0.68$$

$$\therefore V_{f_1} = 0.68 \times \sqrt{2 \times 9.81 \times 5.5} = 7.064 \text{ m/s}$$

Overall Efficiency $\eta_0 = 60\% = 0.60$

Diameter of boss $D_b = \frac{1}{3} \times D_0$

Using the relation $\eta_0 = \frac{\text{Shaft power}}{\text{water power}} = \frac{7357.5}{\rho g Q H}$

$$0.60 = \frac{7357.5 \times 1000}{1000 \times 9.81 \times Q \times 5.5}$$

Discharge $Q = \frac{7357.5 \times 1000}{1000 \times 9.81 \times 5.5 \times 0.60} = 227.27 \text{ m}^3/\text{s}$

Using equation for discharge

$$Q = \frac{\pi}{4} [D_0^2 - D_b^2] \times V_{f_1}$$

$$227.27 = \frac{\pi}{4} \left[D_0^2 - \left(\frac{D_0}{3} \right)^2 \right] \times V_{f_1}$$

$$227.27 = \frac{\pi}{4} \times \frac{8}{9} D_0^2 \times 7.064$$

$$D_0^2 = 227.27 \times \frac{4}{\pi} \times \frac{9}{8} \times \frac{1}{7.064}$$

$$D_0 = 6.788 \text{ m}$$

$$D_b = \frac{1}{3} D_0 = \frac{6.788}{3} = 2.262 \text{ m}$$

Using the relation $u_2 = \frac{\pi D_0 N}{60}$

$$N = \frac{60 \times u_1}{\pi D_0} = \frac{60 \times 21.71}{\pi \times 6.788} = 61.08 \text{ rpm}$$

($\because u_1 = u_2$) The specific speed

$$N_s = \frac{N \sqrt{P}}{H^{5/4}} = \frac{61.08 \times \sqrt{7357.5}}{(5.5)^{5/4}} = 622 \text{ rpm}$$

Geometric similarity

The geometric similarity must exist between the model and its proto type. the ratio of all corresponding linear dimensions in the model and its proto type are equal.

Let L_m = length of model

b_m = Breadth of model

D_m = Diameter of model

A_m = Area of model

V_m = Volume of model

And L_p, b_p, D_p, A_p, V_p = Corresponding values of the prototype.

For geometrical similarity between model and prototype, we must have the relation,

$$\frac{L_p}{L_m} = \frac{b_p}{b_m} = \frac{D_p}{D_m} = L_r$$

Where L_r is called scale ratio.

For area's ratio and volume's ratio the relation should be,

$$\frac{A_p}{A_m} = \frac{L_p \times b_p}{L_m \times b_m} = L_r \times L_r = L_r^2$$

$$\frac{V_p}{V_m} = \left(\frac{L_p}{L_m}\right)^3 = \left(\frac{b_p}{b_m}\right)^3 = \left(\frac{D_p}{D_m}\right)^3 = L_r^3$$

Performance of Hydraulic Turbines

In order to predict the behavior of a turbine working under varying conditions of head, speed, output and gate opening , the results are expressed in terms of quantities which may be obtained when the head on the turbine is reduced to unity. The conditions of the turbine under unit head are such that the efficiency of the turbine remains unaffected. The three important unit quantities are:

1. Unit speed,
2. Unit discharge, and
3. Unit power

1. Unit Speed: it is defined as the speed of a turbine working under a unit head. It is denoted by ' N_u '. The expression of unit speed (N_u) is obtained as:

Let N = Speed of the turbine under a head H

H = Head under which a turbine is working

u = Tangential velocity.

The tangential velocity, absolute velocity of water and head on turbine are related as:

$$u \propto V \quad \text{Where } V \propto \sqrt{H}$$

$$\propto \sqrt{H} \quad \text{_____ (1)}$$

Also tangential velocity (u) is given by

$$u = \frac{\pi DN}{60} \quad \text{Where } D = \text{Diameter of turbine.}$$

For a given turbine, the diameter (D) is constant

$$u \propto N \quad \text{Or } N \propto u \quad \text{Or } N \propto \sqrt{H} \quad (\because \text{From (1), } u \propto \sqrt{H})$$

$$\therefore N = K_1 \sqrt{H} \quad \text{_____ (2) \quad Where } K_1 \text{ is constant of proportionality.}$$

If head on the turbine becomes unity, the speed becomes unit speed or

$$\text{When } H = 1, N = N_u$$

Substituting these values in equation (2), we get

$$N_u = K_1 \sqrt{1.0} = K_1$$

Substituting the value of K_1 in equation (2)

$$N = N_u \sqrt{H} \quad \text{or } N_u = \frac{N}{\sqrt{H}} \quad \text{_____ (I)}$$

2. Unit Discharge: It is defined as the discharge passing through a turbine, which is working under a unit head (i.e. 1 m). It is denoted by ' Q_u ' the expression for unit discharge is given as:

Let H = head of water on the turbine

Q = Discharge passing through turbine when head is H on the turbine.

a = Area of flow of water

The discharge passing through a given turbine under a head 'H' is given by,

$$Q = \text{Area of flow} \times \text{Velocity}$$

But for a turbine, area of flow is constant and velocity is proportional to $\sqrt{H}$

$$Q \propto \text{velocity} \propto \sqrt{H}$$

Or
$$Q = K_2 \sqrt{H} \quad \text{----- (3)}$$

Where K_2 is constant of proportionality

If $H = 1, Q = Q_u$ (By definition)

Substituting these values in equation (3) we get

$$Q_u = K_2 \sqrt{1.0} = K_2$$

Substituting the value of K_2 in equation (3) we get

$$Q = Q_u \sqrt{H}$$

$$Q_u = \frac{Q}{\sqrt{H}} \quad \text{----- (II)}$$

3. Unit Power: It is defined as the power developed by a turbine working under a unit head (i.e. under a head of 1m). It is denoted by ' P_u '. The expression for unit power is obtained as:

Let H = Head of water on the turbine

P = Power developed by the turbine under a head of H

Q = Discharge through turbine under a head H

The overall efficiency (η_o) is given as

$$\eta_o = \frac{\text{Power developed}}{\text{Water power}} = \frac{P}{\frac{\rho g Q H}{1000}}$$

$$P = \eta_o \times \frac{\rho g Q H}{1000}$$

$$\propto Q \times H \propto \sqrt{H} \times H \quad (\because Q \propto \sqrt{H})$$

$$\propto H^{\frac{3}{2}}$$

$$P = K_3 H^{3/2} \quad \text{----- (4) Where } K_3 \text{ is a constant of proportionality}$$

When $H=1 \text{ m}, P = P_u$

$$\therefore P_u = K_3 (1)^{3/2} = K_3$$

Substituting the value of K_3 in equation (4) we get

$$P = P_u H^{\frac{3}{2}}$$

$$P_u = \frac{P}{H^{3/2}} \quad \text{----- (III)}$$

Use of Unit Quantities (N_u, Q_u, P_u):

If a turbine is working under different heads, the behaviour of the turbine can be easily known from the values of the unit quantities i.e. from the value of unit speed, unit discharge and unit power.

Let $H_1, H_2, H_3, \dots$ are the heads under which a turbine works,
 $N_1, N_2, N_3, \dots$ are the corresponding speeds,
 $Q_1, Q_2, Q_3, \dots$ are the discharge and
 $P_1, P_2, P_3, \dots$ are the power developed by the turbine.

Using equation I, II, III respectively,

$$\left. \begin{aligned} N_u &= \frac{N_1}{\sqrt{H_1}} = \frac{N_2}{\sqrt{H_2}} = \frac{N_3}{\sqrt{H_3}} \\ Q_u &= \frac{Q_1}{\sqrt{H_1}} = \frac{Q_2}{\sqrt{H_2}} = \frac{Q_3}{\sqrt{H_3}} \\ P_u &= \frac{P_1}{H_1^{3/2}} = \frac{P_2}{H_2^{3/2}} = \frac{P_3}{H_3^{3/2}} \end{aligned} \right\} \text{-----(IV)}$$

Hence, if the speed, discharge and power developed by a turbine under a head are known, then by using equation (IV) the speed, discharge, power developed by the same turbine at a different head can be obtained easily.

CHARACTERISTIC CURVES OF HYDRAULIC TURBINES:

Characteristic curves of a hydraulic turbine are the curves, with the help of which the exact behaviour and performance of the turbine under different working conditions can be known. These curves are plotted from the results of the tests performed on the turbine under different working conditions.

The important parameters which are varied during a test on turbine are:

- | | | |
|--------------|--|------------------|
| 1) Speed (N) | 2) Head (H) | 3) Discharge (Q) |
| 4) Power (P) | 5) Overall Efficiency (η_o) and | 6) Gate opening. |

Out of the above six parameters, three parameters namely speed (N), Head (H) and discharge (Q) are independent parameters.

Out of the three independent parameters, (N, H, Q) one of the parameter is kept constant (say H) and the variation of other two parameters with respect to any one of the remaining two independent variables (say N and Q) are plotted and various curves are obtained. These curves are called characteristic curves. The following are the important characteristic curves of a turbine.

1. Main Characteristic Curves or Constant Head Curves.
2. Operating Characteristic Curves or Constant Speed Curves.
3. Muschel Curves or Constant Efficiency Curves.

1. Main Characteristic Curves or Constant Head Curves:

These curves are obtained by maintaining a constant head and a constant gate opening (G.O.) on the turbine. The speed of the turbine is varied by changing the load on the turbine. For each value of the speed, the corresponding values of the power (P) and discharge (Q) are obtained. Then the overall efficiency (η_0) for each value of the speed is calculated. From these readings the values of unit speed (N_u), unit power (P_u) and unit discharge (Q_u) are determined. Taking N_u as abscissa, the values of Q_u , P_u , P and η_0 are plotted. By changing the gate opening, the values of Q_u and N_u are determined and taking N_u as abscissa, the values of Q_u , P_u and η_0 are plotted.






Fig. 18.35 Main characteristic curves for a Pelton wheel.



2. Operating Characteristic Curves or Constant Speed Curves:


These curves are plotted when the speed on the turbine is constant. In case turbines, the head is generally constant. As already discussed there are three independent parameters namely N , H and Q . For operating characteristics N and H are constant and hence the variation of power and the efficiency with respect to discharge Q are plotted. The power curve for the turbine shall not pass through the origin, because certain amount of discharge is needed to produce power to



overcome initial friction. Hence the power and efficiency curves will be slightly away from the origin on the x-axis, as to overcome initial friction certain amount of discharge will be required.

3. Constant Efficiency Curves or Muschel Curves or Iso - Efficiency Curves:

These curves are obtained from the speed vs. efficiency and speed vs. discharge curves for different gate openings. For a given efficiency from the N_u vs. η_0 curves there are two speeds. From the N_u vs. Q_u curves, corresponding to two values of speeds there are two values of discharge. Hence for a given efficiency there are two values of discharge for a particular gate opening. This means for a given efficiency there are two values of speeds and two values of discharge for a given gate opening. If the efficiency is maximum there is only one value. These two values of speed and two values of discharge. Corresponding to a particular gate opening are plotted. The procedure is repeated for different gate openings and the curves Q vs. N are plotted. The points having the same efficiencies are joined. The curves having the same efficiency



are called Iso-efficiency curves. These curves are helpful for determining the zone of constant efficiency and for predicating the performance of the turbine at various efficiencies.

For plotting the Iso-efficiency curves, horizontal lines representing the same efficiency are drawn on the $\eta_0 \sim N$ speed curves. The points at which these lines cut the efficiency curves at various gate opening are transferred to the corresponding $Q \sim N$ speed curves. The points having the same efficiency are then joined by smooth curves. These smooth curves represent the Iso-efficiency curves.

Cavitation : Cavitation is defined as the phenomenon of formation of vapour bubbles of a flowing liquid in a region, where the pressure of the liquid falls below its vapour pressure and the sudden collapsing of these vapour bubbles in a region of higher pressure. When the vapour bubbles collapse, a very high pressure is created. The metallic surfaces, above which these vapour bubbles collapse, is subjected to these high pressures, which cause pitting action on the surface. Thus cavities are formed on the metallic surface and also considerable noise and vibrations are produced.

Cavitation includes formation of vapour bubbles of the flowing liquid and collapsing of the vapour bubbles. Formation of vapour bubbles of the flowing liquid take place only whenever the pressure in any region falls below vapour pressure. When the pressure of the flowing liquid is less than its vapour pressure, the liquid starts boiling and the vapour bubbles are formed. These vapour bubbles are carried along with the flowing liquid to higher pressure zones, where these vapour condense and the bubbles collapse. Due to sudden collapsing of the bubbles on the metallic surface, high pressure is produced and metallic surfaces are subjected to high local stress. Thus the surfaces are damaged.

Precaution against Cavitation: The following are the Precaution against cavitation

- i. The pressure of the flowing liquid in any part of the hydraulic system should not be allowed to fall below its vapour pressure. If the flowing liquid is water, then the absolute pressure head should not be below 2.5m of water.
- ii. The special materials or coatings such as Aluminum-bronze and stainless steel, which are cavitation resistant materials, should be used.

Effects of Cavitation: the following are the effects of cavitation.

- i. The metallic surfaces are damaged and cavities are formed on the surfaces.
- ii. Due to sudden collapse of vapour bubbles, considerable noise and vibrations are produced.
- iii. The efficiency of a turbine decreases due to cavitation. Due to pitting action, the surface of the turbine blades becomes rough and the force exerted by the water on the turbine blades decreases. Hence, the work done by water or output horse power becomes less and efficiency decreases.

Hydraulic Machines Subjected to Cavitation: The hydraulic machines subjected to Cavitation are reaction turbine and centrifugal pumps.

Cavitation in Turbines: in turbines, only reaction turbines are subjected to cavitation. In reaction turbines the cavitation may occur at the outlet of the runner or at the inlet of the draft tube where the pressure is considerably reduced. (i.e. which may be below vapour pressure of the liquid flowing through the turbine) Due to cavitation, the metal of the runner vanes and draft tube is gradually eaten away, which results in lowering the efficiency of the turbine. Hence the cavitation in a reaction turbine can be noted by a sudden drop in efficiency. In order to determine whether cavitation will occur in any portion of a reaction turbine, the critical value of Thoma's cavitation factors σ is calculated.

$$\sigma = \frac{H_b - H_s}{H} = \frac{(H_{atm} - H_v) - H_s}{H},$$

Where H_b = Barometric pressure head in m of water,

H_{atm} = Atmospheric pressure head in m of water,

H_v = Vapour pressure head in m of water,

H_s =

Suction pressure at the outlet of reaction turbine in m of water or height of turbine runner above the tail water surface,


H = Net head on the turbine in m.

Surge Tank:

When the load on the generator decreases, the governor reduces the rate of flow of water striking the runner to maintain constant speed for the runner. The sudden reaction of rate of flow in the penstock may lead to water hammer in pipe due to which the pipe may burst. When the load on the generator increases the turbine requires more water. Surge tank and fore bays are usually employed to meet the above requirements. Surge tanks are employed in case of high head and medium head hydro power plants where the penstock is very long and fore bays are suitable for medium and low head hydro power plants where the length of penstock is short.


An ordinary surge tank is a cylindrical open topped storage reservoir, which is connected to the penstock at a point as close as possible to the turbine. The upper lip of the tank is kept well above the maximum water level in the supply reservoir. When the load on the turbine is steady and normal and there are no velocity variations in the pipe line there will be normal pressure gradient oaa_1 . The water surface in the surge tank will be lower than the reservoir surface by an amount equal to friction head loss in the pipe connecting reservoir and surge tank. When the load on the generator is reduced, the turbine gates are closed and the water moving towards the turbine has to move back ward. The rejected water is then stored in the surge tank, raising the pressure gradient. The retarding head so built up in the surge tank reduces the velocity of flow in the pipe line corresponding to the reduced discharge required by the turbine.

When the load on the generator increases the governor opens the turbine gates to increase the rate of flow entering the runner. The increased demand of water by the turbine is partly met by the water stored in the surge tank. As such the water level in the surge tank falls and falling pressure gradient is developed. In other words, the surge tank develops an accelerating head which increases the velocity of flow in the pipe line to a value corresponding to the increased discharge required by the turbine.



Water Hammer:

Consider a long pipe AB, connected at one end to a tank containing water at a height of H from the centre of the pipe. At the other end of the pipe, a valve to regulate the flow of water is provided. When the valve is completely open, the water is flowing with a



velocity, V in the pipe. If now the valve is suddenly closed, the momentum of the flowing water will be destroyed and consequently a wave of high pressure will be set up. This wave of high pressure will be transmitted along the pipe with a velocity equal to the velocity of sound wave and may create noise called knocking. Also this wave of high pressure has the effect of hammering action on the walls of the pipe and hence it is known as water hammer.

The pressure rise due to water hammer depends up on:

1. Velocity of flow of water in pipe.
2. The length of pipe.
3. Time taken to close the valve.
4. Elastic properties of the material of the pipe.

The following cases of water hammer in pipes will be considered.

1. Gradual closure of valve
2. Sudden closure of valve considering pipe in rigid
3. Sudden closer of valve considering pipe elastic.

1. Gradual Closure of Valve:

$$\text{Mass of water in pipe} = \rho \times \text{volume of water} = \rho \times A \times L$$

Where A = Area of cross-section of the pipe

L = Length of pipe

The valve is closed gradually in time „T“ seconds and hence the water is brought from initial velocity V to zero velocity in time seconds.

$$\therefore \text{Retardation of water} = \frac{\text{change of velocity}}{\text{Time}} = \frac{V-0}{T} = \frac{V}{T}$$

$$\therefore \text{Retarding force} = \text{Mass} \times \text{Retardation} = \rho AL \times \frac{V}{T} \quad (1)$$

If p is the intensity of pressure wave produced due to closure of the valve, the force due to pressure wave

$$= p \times \text{Area of pipe} = p \times A \quad (2)$$

Equating the two forces given by equation (1) & (2)

$$\rho AL \times \frac{V}{T} = p \times A$$

$$p = \frac{\rho LV}{T}$$

$$\text{Head of pressure} \quad H = \frac{p}{\rho g} = \frac{\rho LV}{\rho g \times T} = \frac{LV}{gT}$$

i) The valve closure is said to be gradual if $T > \frac{2L}{C}$

Where T = Time in sec, C = Velocity of Pressure wave

ii) The valve closure is said to be sudden if $T < \frac{2L}{C}$

Where C = Velocity of Pressure Wave

2) Sudden Closure of Valve and Pipe is Rigid:

In sudden closure of valve $T=0$, the increase in pressure will be infinite when wave of high pressure is created the liquid gets compressed to some extent and pipe material gets stretched. For a sudden closure of valve, the valve of T is very small and hence a wave of high pressure is created.

When the valve is closed suddenly, the kinetic energy of flowing water is converted in to strain energy of water if the effect of friction is neglected and pipe wall is assumed to be rigid.

$$\therefore \text{loss of kinetic energy} = \frac{1}{2} \times \text{mass of water in pipe} \times V^2 \\ = \frac{1}{2} \times \rho AL \times V^2$$

$$\text{Gain of strain energy} = \frac{1}{2} \left[\frac{p^2}{K} \right] \times \text{volum} = \frac{1}{2} \frac{p^2}{K} \times AL$$

Equating loss of Kinetic energy to gain of strain energy

$$\frac{1}{2} \times \rho AL \times V^2 = \frac{1}{2} \frac{p^2}{K} \times AL$$

$$p^2 = \frac{1}{2} \times \rho AL \times V^2 \times \frac{2K}{AL} = \rho KV^2$$

$$p = \sqrt{\rho KV^2} = V\sqrt{K\rho} = V\sqrt{\frac{K\rho^2}{\rho}}$$

$$p = \rho V \sqrt{\frac{K}{\rho}} \quad \left(\because \sqrt{\frac{K}{\rho}} = C \right)$$

$$p = \rho V \times C$$

Where C = velocity of pressure wave.

CENTRIFUGAL PUMPS

The hydraulic machines which convert the mechanical energy in to hydraulic energy are called pumps. The hydraulic energy is in the form of pressure energy. If the mechanical energy is converted in to pressure energy by means of centrifugal force acting on the fluid, the hydraulic machine is called centrifugal pump.

The centrifugal pump acts as a reversed of an inward radial flow reaction turbine. This means that the flow in centrifugal pumps is in the radial outward directions. The centrifugal pump works on the principle of forced vortex flow which means that when a certain mass of liquid is rotated by an external torque, the rise in pressure head of the rotating liquid takes place. The rise in pressure head at any point of the rotating liquid is proportional to the square of tangential velocity of the liquid at that point. (i.e. rise in pressure head = $\frac{v^2}{2g}$ or $\frac{\omega^2 r^2}{2g}$). Thus the outlet of the impeller, where radius is more, the rise in pressure head will be more and the liquid will be discharged at the outlet with a high pressure head. Due to this high pressure head, the liquid can be lifted to a high level.


The following are the main parts of a centrifugal pump.

1) Impeller. 2) Casing. 3) Suction pipe with foot valve and a strainer 4) Delivery pipe.

1. Impeller: The rotating part of a centrifugal pump is called impeller. It consists of a series of backward curved vanes. The impeller is mounted on a shaft which is connected to the shaft of an electric motor.

2. Casing: the casing of a centrifugal pump is similar to the casing of a reaction turbine. It is an air tight passage surrounding the impeller and is designed in such a way that the kinetic energy of the water discharged at the outlet of the impeller is converted in to pressure energy before the water leaves the casing and enters the delivery pipe. The following three types of the casing are commonly adopted.

- a) Volute b) Vortex
- c) Casing with guide blades




a) **Volute Casing:** It is the casing surrounding the impeller. It is of a spiral type, in which area of flow increases gradually. The increase in area of flow decreases the velocity of flow. The decrease in velocity increases the pressure of the water flowing through the casing. It has been observed that in case of volute casing, the efficiency of the pump increase slightly as a large amount of energy is lost due to the formation of eddies in this type of casing.

b) **Vortex Casing:** If a circular chamber is introduced between the casing and the impeller, the casing is known as vortex casing. By introducing the circular chamber, the loss of energy due to the formation of eddies is reduced to a considerable extent. Thus the efficiency of the pump is more than the efficiency when only volute casing is provided.

c) **Casing with guide blades:** in this type of casing the impeller is surrounded by a series of guide blades mounted on a ring known as diffuser. The guide vanes are designed in which way that the water from the impeller enters the guide vanes without shock.

Also the area of guide vanes increases thus reducing the velocity of flow through guide vanes and consequently increasing the pressure of the water. The water from the guide vanes then pass through the surrounding casing, which is in most of the cases concentric with the impeller.


3. **Suction pipe with a foot valve and a strainer:** A pipe whose one end is connected to the inlet of the pump and other end dips in to water in a sump is known as suction pipe. A foot valve which is a non-return valve or one-way type of valve is fitted at the lower end of the suction pipe. The foot valve opens only in the upward direction. A strainer is also fitted at the lower end of the suction pipe.



4. **Delivery pipe:** A pipe whose one end is connected to the outlet of the pump and the other end delivers the water at the required height is known as delivery pipe.

Work done by the centrifugal pump on water:

In the centrifugal pump, work is done by the impeller on the water. The expression for the work done by the impeller on the water is obtained by drawing velocity triangles at inlet and outlet of the impeller in the same way as for a turbine. The water enters the impeller radially at inlet for best efficiency of the pump, which means the absolute velocity of water at inlet makes an angle of 90° with the direction of motion of the impeller at inlet. Hence angle $\alpha = 90^\circ$ and $\phi_1 = 0$ for drawing the velocity triangles the same notations are used as that for turbines.



Let N = Speed of the impeller in r.p.m.

D_1 = Diameter of impeller at inlet

$$u_1 = \text{Tangential velocity of impeller at inlet} = \frac{\pi D_1 N}{60}$$

D_2 = Diameter of impeller at outlet

$$u_2 = \text{Tangential velocity of impeller at outlet} = \frac{\pi D_2 N}{60}$$

V_1 = Absolute velocity of water at inlet.

V_{r1} = Relative velocity of water at inlet

α = Angle made by absolute velocity V_1 at inlet with the direction of motion of vane

ϕ_1 = Angle made by relative velocity (V_{r1}) at inlet with the direction of motion of

vane And β , ϕ_2 , V_2 , V_{r2} , θ are the corresponding values at outlet.

As the water enters the impeller radially which means the absolute velocity of water at inlet is in the radial direction and hence angle $\alpha = 90^\circ$ and $\phi_1 = 0$.

A centrifugal pump is the reverse of a radially inward flow reaction turbine. But in case of a radially inward flow reaction turbine, the work done by the water on the runner per second per unit weight of the water striking per second is given by equation.

$$= \frac{1}{g} (u_1 V_{r1} - u_2 V_{r2})$$

$\therefore$ Work done by the impeller on the water per second per unit weight of water striking/second

$$= - \frac{1}{g} (u_1 V_{r1} - u_2 V_{r2})$$

$$\begin{aligned}
 &= -\frac{1}{\rho} \rho_1 v_1 - \rho_2 v_2 \\
 &= -\frac{1}{\rho} \rho_2 v_2 - \rho_1 v_1 \\
 &= -\frac{1}{\rho} \rho_2 v_2 \quad \text{--- (1)} \quad \because \rho_1 = 0
 \end{aligned}$$

Work done by the impeller on water per second

$$= \frac{W}{\rho} \times \rho_2 v_2$$

Where W = Weight of water = $\rho \times Q \times \rho$

Q = Volume of water

Q = Area $\times$ Velocity of flow

$$= \rho_1 v_1 \times \rho_1$$

$$= \rho_2 v_2 \times \rho_2$$

Where ρ_1 and ρ_2 are width of impeller at inlet and outlet and

ρ_1 And ρ_2 are velocities of flow at inlet and outlet

Head imparted to the water by the impeller or energy given by impeller to water per unit weight per second


$$= \frac{W}{\rho} \times \rho_2 v_2$$

MULTI- STAGE CENTRIFUGAL PUMPS:

If centrifugal pump consists of two or more impellers, the pump is called a multi-stage centrifugal pump. The impeller may be mounted on the same shaft or on different shafts. A multi- stage pump is having the following two important functions:

- 1) To produce a high head and 2) To discharge a large quantity of liquid.

If a high head is to be developed, the impellers are connected in series (or on the same shaft) while for discharging large quantity of liquid, the impellers (or pumps) are connected in parallel.



Multi-Stage Centrifugal Pumps for High Heads: For developing a high head, a number of impellers are mounted in series on the same shaft.

The water from suction pipe enters the 1st impeller at inlet and is discharged at outlet with increased pressure. The water with increased pressure from the outlet of the 1st impeller is taken to the inlet of the 2nd impeller with the help of a connecting pipe. At the outlet of the 2nd impeller the pressure of the water will be more than the water at the outlet of the 1st impeller. Thus if more impellers are mounted on the same shaft, the pressure at the outlet will be increased further.

Let n = Number of identical impellers mounted on the same shaft,

h = Head developed by each impeller.

Then total Head developed = $n \times h$

The discharge passing through each impeller is same.


Multi-Stage Centrifugal Pumps for High Discharge:

For obtaining high discharge, the pumps should be connected in parallel. Each of the pumps lifts the water from a common sump and discharges water to a common pipe to which the delivery pipes of each pump is connected. Each of the pumps is working against the same head.

Let n = Number of identical pumps
arranged in parallel.

Q = Discharge from one pump.

$\therefore$ Total Discharge = $n \times Q$




Performance Characteristic Curves of centrifugal pumps

The characteristic curves of a centrifugal pump are defined as those curves which are plotted from the results of a number of tests on the centrifugal pump. These curves are necessary to predict the behavior and performance of the pump, when the pump is working under different flow rate, head and speed. The following are the important characteristic curves for the pumps:

1. Main characteristic curves.
2. Operating characteristic curves and
3. Constant efficiency or Muschel curves.


1 Main Characteristic Curves: the main characteristic curves of a centrifugal pump consists of a head (Manometric head H_m) power and discharge with respect to speed. For plotting curves of Manometric head versus speed, discharge is kept constant. For plotting curves of discharge versus speed, Manometric head (H_m) is kept constant. For plotting curves power versus speed, Manometric head and discharge are kept constant.



2 Operating Characteristic Curves:

If the speed is kept constant, the variation of Manometric head, power and efficiency with respect to discharge gives the operating characteristics of the pump.

The input power curve for pumps shall not pass through the origin. It will be slightly away from the origin on the y-axis, as even at zero discharge some power is needed to overcome mechanical losses.



The head curve will have maximum value of head when the discharge is zero.


The output power curve will start from origin as at $Q=0$, output power P_{out} will be

zero. The efficiency curve will start from origin as at $Q=0$, $\eta = 0$. $\therefore \eta = \frac{P_{out}}{P_{in}}$

3 Constant Efficiency Curves:

For obtaining constant efficiency curves for a pump, the head versus discharge curves and efficiency v/s discharge curves for different speeds are used. By combining these curves

$\sim \eta \sim \text{constant}$



efficiency curves are obtained.


For plotting the constant efficiency curves (Iso– efficiency curves), horizontal lines representing constant efficiencies are drawn on the $\eta \sim Q$ curves. The points, at which these lines cut the efficiency curves at various speeds, are transferred to the corresponding $\eta \sim Q$ curves. The points having the same efficiency are then joined by smooth curves. These smooth curves represent the iso – efficiency curves.

For any pump installation, a distinction is made between the required NPSH and the available NPSH. The value of required NPSH is given by the pump manufacturer. This value can also be determined experimentally. For determining its value the pump is tested and minimum value of Δh is obtained at which the pump gives maximum efficiency without any noise. (i.e. cavitation free). The required NPSH varies with the pump design, speed of the pump and capacity of the pump.

When the pump is installed, the available NPSH is calculated from the above equation (2). In order to have cavitation free operation of centrifugal pump, the available NPSH should be greater than the required NPSH.

RECIPROCATING PUMPS

The mechanical energy is converted in to hydraulic energy (pressure energy) by sucking the liquid in to a cylinder in which a piston is reciprocating, which exerts the thrust on the liquid and increases its hydraulic energy (pressure energy) the pump is known as reciprocating pump.



A single acting reciprocating pump consists of a piston, which moves forwards and backwards in a close fitting cylinder. The movement of the piston is obtained by connecting the piston rod to crank by means of a connecting rod. The crank is rotated by means of an electric motor. Suction and delivery pipes with suction valve and delivery valve are connected to the cylinder. lves are one way valves or non-return

valves, which allow the water to flow in one direction only. Suction valve allows water from suction pipe to the cylinder which delivery valve allows water from cylinder to delivery pipe only.